Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ariete 2791

Ariete 2791 Jet Force Cyclonic Bagless Vacuum Cleaner User Manual

1. Introduction

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Ariete 2791 Jet Force Cyclonic Bagless Vacuum Cleaner. Please read these instructions carefully before using the appliance and retain them for future reference.

2. Safety Instructions

Always observe basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury.

- Ensure the power supply voltage matches the rating label on the appliance.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Unplug the vacuum cleaner from the power outlet when not in use, before cleaning, or before performing any maintenance.
- Do not use the appliance if the power cord or plug is damaged. Contact authorized service personnel for repair.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Do not vacuum flammable or combustible materials, hot ashes, or sharp objects.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- This appliance is intended for household use only.

3. Package Contents

Verify that all components are present in the packaging:

- Ariete 2791 Jet Force Main Unit
- Flexible Hose
- Telescopic Metal Tube

- Floor Nozzle
- Crevice Tool
- Small Brush Attachment



Figure 3.1: Included Accessories. This image displays the flexible hose, a telescopic metal tube, the main floor nozzle, a crevice tool, and a small brush attachment, which are all part of the standard package for the Ariete 2791 Jet Force vacuum cleaner.

4. Product Overview

Familiarize yourself with the main components of your vacuum cleaner:



Figure 4.1: Main Unit and Assembled Components. This image shows the red and black main vacuum unit with its transparent dustbin, connected to the flexible hose and the floor nozzle. The large wheels and the 'Jet Force' branding are visible.

- **Main Unit:** Contains the motor, cyclonic system, and dustbin.
- **Dustbin:** Transparent, removable container for collected dirt and dust.
- **Power Button:** Activates and deactivates the vacuum cleaner.
- **Cord Rewind Button:** Automatically retracts the power cord.
- **Handle:** For carrying the appliance.
- **Hose Connection:** Point where the flexible hose attaches to the main unit.
- **Flexible Hose:** Connects the main unit to the telescopic tube.
- **Telescopic Tube:** Adjustable length tube for extended reach.
- **Floor Nozzle:** Main attachment for cleaning floors and carpets.
- **Accessory Tools:** Crevice tool and small brush for specialized cleaning tasks.



Figure 4.2: Top View of Main Unit. This image provides a closer look at the top of the vacuum cleaner, highlighting the integrated carrying handle, the circular power button, and the rectangular cord rewind button.



Figure 4.3: Rear View with Power Cord. This image shows the back of the vacuum cleaner, where the power cord exits the unit. The exhaust filter area is also visible.

5. Setup

Follow these steps to assemble your Ariete 2791 Jet Force vacuum cleaner:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Attach Flexible Hose:** Insert the end of the flexible hose into the suction inlet on the main unit until it clicks securely into place.
3. **Connect Telescopic Tube:** Attach the wider end of the telescopic metal tube to the handle of the flexible hose.
4. **Attach Floor Nozzle:** Connect the floor nozzle to the other end of the telescopic tube. Ensure it is firmly attached.
5. **Power Cord:** Pull out the power cord to the desired length. The cord has a yellow marker indicating the maximum safe length and a red marker indicating the absolute maximum length. Do not pull beyond the red marker.
6. **Plug In:** Insert the power plug into a suitable electrical outlet.

6. Operating Instructions

To begin cleaning with your Ariete 2791 Jet Force vacuum cleaner:

1. **Power On:** Press the power button located on the main unit to start the vacuum cleaner.
2. **Adjust Telescopic Tube:** Adjust the length of the telescopic tube to a comfortable height for operation.
3. **Select Attachment:** Use the floor nozzle for general floor and carpet cleaning. For corners, crevices, or upholstery, detach the floor nozzle and attach the crevice tool or small brush directly to the telescopic tube or hose handle.
4. **Vacuuming:** Move the floor nozzle or attachment slowly over the surface to be cleaned to allow for effective dirt collection.
5. **Power Off:** After cleaning, press the power button again to turn off the vacuum cleaner.
6. **Cord Rewind:** Unplug the power cord from the outlet. Press the cord rewind button to automatically retract the power cord into the unit. Guide the cord to prevent whipping.

7. Maintenance

Regular maintenance ensures optimal performance and extends the life of your vacuum cleaner.

7.1. Emptying the Dustbin

The Ariete 2791 is a bagless vacuum cleaner with a 2.5-liter dustbin. Empty the dustbin when the dirt level reaches the 'MAX' indicator line.

1. Ensure the vacuum cleaner is unplugged from the power outlet.
2. Press the dustbin release button (usually located near the handle) and lift the dustbin from the main unit.
3. Position the dustbin over a waste bin.
4. Open the bottom lid of the dustbin to release the collected dirt.
5. Close the lid securely and reattach the dustbin to the main unit until it clicks into place.

7.2. Cleaning the Filters

The vacuum cleaner is equipped with a HEPA filter and other pre-motor filters. Regular cleaning of these filters is crucial for maintaining suction power and air quality.

1. **Pre-Motor Filters:** These are typically located inside or around the dustbin. Remove them and tap them gently to dislodge dust. If heavily soiled, they can be rinsed under cold running water. Ensure they are completely dry before reinserting.
2. **HEPA Filter:** The HEPA filter is usually located at the exhaust of the vacuum cleaner. Refer to the appliance's specific filter compartment. Remove the HEPA filter and tap it to remove dust. Do not wash the HEPA filter unless explicitly stated in the appliance's specific instructions, as washing can damage some HEPA filter types. Replace the HEPA filter periodically as recommended by the manufacturer (typically every 6-12 months, depending on usage).
3. Reassemble all filters and the dustbin before using the vacuum cleaner.

7.3. Cleaning the Exterior

Wipe the exterior surfaces of the vacuum cleaner with a soft, damp cloth. Do not use abrasive cleaners or solvents.

8. Troubleshooting

If you encounter issues with your Ariete 2791 Jet Force, refer to the following troubleshooting guide:

Problem	Possible Cause	Solution
No power	Not plugged in; power outlet fault; power button not pressed.	Check plug connection; test outlet with another appliance; press power button firmly.
Loss of suction	Dustbin full; filters clogged; hose/tube/nozzle blocked.	Empty dustbin; clean or replace filters; check and clear any blockages.
Unusual noise	Blockage in hose/nozzle; motor issue.	Check for and remove blockages. If noise persists, contact customer support.
Overheating	Clogged filters; blocked airflow.	Turn off and unplug. Allow to cool. Clean all filters and check for blockages.

9. Specifications

Technical details for the Ariete 2791 Jet Force Cyclonic Bagless Vacuum Cleaner:

- **Brand:** Ariete
- **Model:** 2791/5
- **Capacity:** 2.5 Liters
- **Wattage:** 210 watts
- **Noise Level:** 78 Decibels
- **Filter Type:** HEPA
- **Weight:** 6.2 Kilograms
- **Dimensions (L x W x H):** 52 x 34.8 x 31.6 cm
- **Cordless:** No

10. Warranty and Support

For warranty information, product support, or service inquiries, please refer to the warranty card included with your purchase or visit the official Ariete website. Keep your proof of purchase for warranty claims.

© 2025 Ariete. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07Q9P9QWJ

More documents and user manuals: **https://manuals.plus/**