

[Manuals.plus](#) /

› [YUANDI](#) /

› YUANDI Mini Digital Voice Recorder A8298 User Manual

YUANDI A8298

YUANDI Mini Digital Voice Recorder A8298 User Manual

Model: A8298

INTRODUCTION

This manual provides instructions for the YUANDI Mini Digital Voice Recorder, Model A8298. This compact device functions as both a professional voice recorder and a 16GB USB flash drive, offering up to 20 hours of continuous recording on a single charge and storing approximately 180 hours of audio. It is compatible with Windows, ME, LINUX, XP, and Mac operating systems.



Image: The YUANDI Mini Digital Voice Recorder, a compact device resembling a USB flash drive, shown held in hand. It features a silver metallic body with blue accents and a small red indicator light.

PRODUCT FEATURES

- **Dual Functionality:** Operates as both a digital voice recorder and a 16GB USB flash drive.
- **High Capacity:** 16GB memory stores approximately 180 hours of audio recordings.
- **Extended Battery Life:** Up to 20 hours of continuous recording on a full charge.
- **Wide Compatibility:** Supports Windows, ME, LINUX, XP, Mac, and Android OTG.
- **Simple Operation:** One-button recording activation.
- **WAV Audio Format:** Recordings saved in WAV format for broad compatibility.
- **MP3 Playback:** Functions as an MP3 player.



Image: An illustration highlighting the key features of the device, including its ability to record in WAV format, function as USB storage, perform voice recording, and offer an A-B repeat function for audio playback.

SETUP

1. **Initial Charge:** Before first use, fully charge the device. Connect the recorder to a USB port on your computer or a USB wall adapter. A full charge typically takes 1 to 2 hours.
2. **Power On:** To activate the device, slide the power switch to the "ON" position. Wait approximately 7 seconds for the device to initialize. The red indicator light will flash three times, indicating it is ready for operation.
3. **System Compatibility:** The device is compatible with Windows (ME, LINUX, XP), Mac, and Android OTG systems. For Mac users, VLC Media Player is recommended for audio file playback.

OPERATING INSTRUCTIONS

Voice Recording


1. **Start Recording:** Slide the power switch to the "ON" position. After the initial 7-second startup, the device will automatically begin recording. The red indicator light will flash three times and then turn off to ensure discreet recording.
2. **Stop Recording:** Slide the power switch to the "OFF" position. The device will save the current recording and power down.
3. **Recording Duration:** The device can record continuously for up to 20 hours on a full battery charge. The 16GB memory can store approximately 180 hours of audio.

Accessing and Managing Files

1. **Connect to Computer:** Plug the device into a USB port on your computer. It will be recognized as a removable disk.
2. **File Location:** Recorded audio files are saved in WAV format within the device's storage.
3. **Playback:** Open the WAV files using any standard media player on your computer. For Mac users, VLC Media Player is recommended.
4. **Data Transfer:** You can transfer, copy, or delete files from the device just like a regular USB flash drive.



During the recording, the indicator light goes out to protect privacy.



Connect USB interface to charge recording equipment and transmit data

Image: This image illustrates two key operational aspects: the top portion shows the device in a meeting setting, indicating that the indicator light turns off during recording for privacy. The bottom portion shows the device connected to a laptop's USB port, demonstrating its function for charging and data transfer.



Image: A collage demonstrating the versatility of the YUANDI Mini Digital Voice Recorder for various needs, such as recording during meetings, capturing notes in a car, recording phone conversations, and documenting lectures or ideas while working on a laptop.

MAINTENANCE

- Keep the device dry and away from extreme temperatures.
- Clean the exterior with a soft, dry cloth. Do not use liquid cleaners.
- Avoid dropping or subjecting the device to strong impacts.
- Regularly back up important recordings to your computer.

TROUBLESHOOTING

- **Device not turning on:** Ensure the battery is charged. Connect to a USB power source for 1-2 hours.

- **Cannot hear recordings:**

- Ensure the device was properly turned off to save the recording.
- Check your computer's volume settings.
- For Mac users, ensure VLC Media Player is installed and used for playback.
- Verify the audio files are present on the device when connected to a computer.

- **Device not recognized by computer:**

- Try a different USB port on your computer.
- Ensure the device is fully inserted into the USB port.
- Restart your computer.

SPECIFICATIONS

Brand	YUANDI
Model	A8298
Dimensions	7.49 x 2.21 x 0.99 cm
Weight	24 g
Memory Capacity	16 GB (approx. 180 hours recording)
Continuous Recording Time	Up to 20 hours
Charging Time	1 to 2 hours
Hardware Interface	USB
Battery Type	Lithium Polymer
Recording Format	WAV
Playback Format	MP3 (via computer)
Operating System Compatibility	Windows (ME, LINUX, XP), Mac, Android OTG
UPC	792990005348




Image: A visual representation of the device's recording capacity and battery life, highlighting its 16GB memory for approximately 180 hours of audio and up to 20 hours of continuous recording on a single charge.

WARRANTY AND SUPPORT

The YUANDI Mini Digital Voice Recorder comes with a 12-month warranty. Additionally, lifetime technical support is available for any product inquiries or assistance you may require.

For support, please contact us via email or by leaving a question on the product page where you purchased the item. We aim to respond to all inquiries promptly.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question