

Manuals.plus /
› Razor /
› Razor A5 Prime Kick Scooter for Kids Ages 8+ - Extra-Large Deck, 8" Urethane Wheels, Anodized Aluminum Frame, Anti-Rattle Technology, For Riders Up to 220 lbs User Manual

Razor 13013217

Razor A5 Prime Kick Scooter User Manual

Model: A5 Prime Scooter (13013217) | Brand: Razor

INTRODUCTION AND SAFETY GUIDELINES

This manual provides essential information for the safe and proper operation, maintenance, and care of your Razor A5 Prime Kick Scooter. Please read it thoroughly before first use and retain it for future reference. The Razor A5 Prime Kick Scooter is designed for riders aged 8 and up, with a maximum weight limit of 220 pounds (100 kg).

Safety First: Always wear appropriate safety gear, including a helmet, knee pads, and elbow pads. Ensure all fasteners are securely tightened before each ride. Ride in safe, open areas away from traffic and pedestrians. Avoid riding on wet or uneven surfaces.





The Razor A5 Prime Kick Scooter, featuring its sleek design and large wheels.

SETUP AND ASSEMBLY

Your Razor A5 Prime Kick Scooter comes mostly assembled. Follow these steps to prepare it for use:

1. Unfolding the Scooter:

Locate the folding mechanism near the front wheel. Press the release button or lever (refer to image) and carefully unfold the scooter until the T-bar clicks securely into place. Ensure the locking mechanism is fully engaged before riding.



A person demonstrating the unfolding process of the scooter.



Detailed view of the folding mechanism, showing how it locks into place.

2. Adjusting Handlebar Height:

Loosen the quick-release clamp on the T-bar stem. Adjust the handlebar to a comfortable height, typically around waist level when standing on the deck. Ensure the handlebar is aligned with the front wheel. Tighten the quick-release clamp firmly to secure the handlebar in position. The A5 Prime features easy-adjust handlebars to accommodate various rider heights.



Illustration of how to adjust the handlebar height for optimal comfort.

3. Folding for Storage/Transport:

To fold the scooter, reverse the unfolding process. Ensure the folding mechanism is fully engaged to keep the scooter compact for storage or transport. The anti-rattle technology helps maintain a smooth ride even after repeated folding.



A person demonstrating the folding process for compact storage.

OPERATING INSTRUCTIONS

The Razor A5 Prime Kick Scooter is designed for smooth and efficient urban commuting and recreational use.

- **Riding Stance:** Place one foot firmly on the deck, slightly forward. Use the other foot to push off the ground to gain momentum. Once moving, place both feet on the deck, one behind the other, or side-by-side if comfortable. The extra-large deck provides ample foot room.
- **Steering:** Lean gently in the direction you wish to turn. The scooter's design allows for responsive steering.
- **Braking:** The scooter features a rear-fender brake. To slow down or stop, press down firmly on the rear fender with your heel. Apply pressure gradually to avoid sudden stops.





A rider demonstrating the proper riding stance on the A5 Prime.



Detail of the rear wheel and the integrated fender brake system.

MAINTENANCE AND CARE

Regular maintenance ensures the longevity and safe operation of your scooter.

- **Cleaning:** Wipe down the scooter with a damp cloth after each use. Avoid using harsh chemicals or abrasive cleaners.
- **Wheel and Bearing Inspection:** Periodically check the wheels for wear and tear. Ensure the bearings spin freely. Replace worn wheels or bearings as needed. The A5 Prime features large 8-inch urethane wheels for a smooth ride.
- **Fastener Check:** Regularly inspect all bolts, nuts, and fasteners to ensure they are tight. Loose components can affect performance and safety. Pay particular attention to the handlebar clamp and folding mechanism.
- **Storage:** Store the scooter in a dry, cool place away from direct sunlight and moisture to prevent corrosion and material degradation.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Scooter rattles during ride.	Loose folding mechanism or handlebar clamp.	Ensure the folding mechanism knob is tightened securely. Check and tighten the handlebar quick-release clamp. The A5 Prime features anti-rattle technology to minimize this.

Problem	Possible Cause	Solution
Handlebar slides down during use.	Handlebar quick-release clamp is not tight enough.	Fully open the quick-release clamp, adjust the handlebar to the desired height, and then close the clamp firmly. If it still slips, the clamp may need adjustment or replacement.
Kickstand scrapes the ground.	Riding over uneven surfaces or design characteristic.	Be mindful of uneven terrain. This is a known characteristic for some riders due to the kickstand's placement.
Wheels do not spin freely.	Dirt/debris in bearings or worn bearings.	Clean around the wheel axles. If the issue persists, the wheel bearings may need cleaning, lubrication, or replacement.

SPECIFICATIONS

Feature	Detail
Brand	Razor
Model Name	A5 Prime Scooter
Color	Prime - Gunmetal Grey
Age Range (Description)	Kid (Ages 8+)
Weight Limit	220 Pounds (100 kg)
Product Dimensions (LxWxH)	36.2"L x 17.1"W x 40.2"H
Number of Wheels	2
Wheel Material	Polyurethane
Frame Material	Anodized Aluminum
Item Weight	11.2 Pounds
Handlebar Type	Adjustable
Wheel Size	200 Millimeters
Wheel Type	Solid
Brake Style	Rear Braking
Special Feature	Lightweight, Foldable, Anti-Rattle Technology

WARRANTY AND SUPPORT

Your Razor A5 Prime Kick Scooter comes with a 90-Day Manufacturer's Warranty. For warranty claims or technical support, please contact Razor USA, LLC directly.

For additional information and resources, you may refer to the official user manual PDF available online or visit the [Razor Brand Store](#).

International Disclaimer: This Razor product is produced for sale in the United States and Canada. Contact Razor for more details regarding Razor products that require service, were purchased in the United States or Canada, and are now outside the United States or Canada. On these products, which require service, consumers are responsible for all costs including shipping, resulting taxes, duties of replacement parts and local power adapters at the owner's expense.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07QBF1Y2X>

More documents and user manuals: <https://manuals.plus/>