

THERMOROSSI 6000-8000

Thermorossi Brazier Blade Instruction Manual for Stove Models 6000-8000

1. INTRODUCTION

This manual provides essential information for the proper use, installation, and maintenance of your original Thermorossi Brazier Blade. This component is designed as a replacement part for specific Thermorossi stove models. Please read this manual thoroughly before handling or installing the product to ensure safe and efficient operation.

2. SAFETY WARNINGS

Observe the following safety warnings to prevent injury or damage:

- Maintain appropriate distance from combustible materials when the stove is in operation.
- Use only approved fuel types for your stove model.
- Exercise caution during installation, use, and maintenance of the brazier blade and the stove.
- Always ensure the stove is completely cool and disconnected from power (if applicable) before performing any maintenance or part replacement.
- Wear appropriate protective gear, such as gloves, when handling the blade to avoid cuts or burns.

3. PRODUCT OVERVIEW

The Thermorossi Brazier Blade is a metal component designed for optimal combustion within compatible Thermorossi stoves. It is constructed from durable metal to withstand high temperatures and ensure longevity.



Image 1: Front view of the Thermorossi Brazier Blade, showing its rectangular shape and attachment points.



Image 2: Angled view of the brazier blade, highlighting its metallic finish and structural design.



Image 3: Side profile of the brazier blade, illustrating its thickness and the design of the attachment mechanisms.

4. COMPATIBILITY

This original Thermorossi Brazier Blade is compatible with the following stove models:

- Ecotherm 6000
- Ecotherm 6000 Thermocomfort
- Ecotherm 8000
- Ecotherm 8000 Thermocomfort
- Insert 60 (up to serial number 700112361)

Always verify the specific characteristics of your stove (brand, model, serial number) before purchasing or installing this replacement part. If you have any doubts, contact Thermorossi support with your stove's details and the product code.

5. INSTALLATION (SETUP)

The brazier blade is a critical component for the combustion process. Proper installation is essential for safety and

performance.

1. **Preparation:** Ensure your stove is completely cool and unplugged from any power source. Clear the combustion chamber of any ash or debris.
2. **Removal of Old Blade:** Carefully identify and remove the existing brazier blade. Consult your specific stove model's instruction manual for detailed steps on accessing and removing internal components.
3. **Installation of New Blade:** Position the new Thermorossi Brazier Blade in the designated slot or mounting points within the combustion chamber. Ensure it is securely seated and aligned according to your stove's manual.
4. **Verification:** Double-check that the blade is firmly in place and does not wobble. Close all access panels securely.

Important: Refer to your specific Thermorossi stove's instruction manual for detailed, model-specific installation procedures for replacement parts. Incorrect installation can lead to inefficient operation or safety hazards.

6. OPERATION

The brazier blade itself does not have operational controls. It functions as an integral part of your Thermorossi stove's combustion system. Once installed, the stove's normal operating procedures apply. For instructions on how to operate your stove, including starting, adjusting heat, and shutting down, please refer to the main instruction manual provided with your Thermorossi stove.

7. MAINTENANCE

Regular maintenance of the brazier blade helps ensure optimal performance and extends its lifespan.

- **Cleaning:** Periodically inspect the brazier blade for ash buildup or residue. When the stove is completely cool, gently brush off any accumulated debris using a non-abrasive brush.
- **Inspection:** During routine stove maintenance, visually inspect the blade for any signs of wear, warping, cracks, or damage. If significant damage is observed, the blade may need replacement.
- **Replacement:** The lifespan of the brazier blade depends on usage and fuel type. Replace the blade if it shows signs of severe degradation that could affect combustion efficiency or safety.

Always ensure the stove is cool and disconnected from power before performing any cleaning or inspection.

8. TROUBLESHOOTING

If you experience issues with your stove after replacing the brazier blade, consider the following:

- **Poor Combustion:** Ensure the blade is correctly installed and not obstructed by ash or debris. Verify that the air inlets in your stove are clear.
- **Unusual Noises:** Check if the blade is securely seated and not vibrating against other components.
- **Smoke or Odor:** This could indicate improper installation or a blockage. Immediately shut down the stove and re-inspect the blade and combustion chamber.

For any persistent issues, consult your stove's main instruction manual or contact a qualified technician or Thermorossi customer support.

9. SPECIFICATIONS

Brand	THERMOROSSI
-------	-------------

Material	Metal
Style	Traditional or Rustic
Finish Type	Lacquered
Shape	Rectangular
Package Dimensions	21.9 x 16.6 x 1.6 cm; 70 grams
ASIN	B07QBG1NHF

10. WARRANTY AND SUPPORT

Information regarding specific warranty details for this replacement part is not explicitly available. For warranty inquiries or technical support, please contact Thermorossi directly or the authorized dealer from whom you purchased the product. Thermorossi is committed to providing quality spare parts. We recommend keeping your purchase receipt as proof of purchase.

© 2023 Thermorossi. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

