CAT 82035

CAT Construction 15-inch Excavator Toy Instruction Manual

Model: 82035

1. Introduction

Thank you for choosing the CAT Construction 15-inch Excavator toy. This durable, push-powered toy is designed for imaginative play, allowing children to engage with realistic construction actions. Featuring articulated parts, this excavator is suitable for both indoor and outdoor environments, providing hours of entertainment for children aged 36 months to 8 years.

Safety Information:

No specific safety warnings are applicable beyond general toy safety guidelines. Ensure the toy is used under adult supervision, especially with younger children, to prevent misuse or accidents.

2. What's in the Box

Your package should contain the following item:

- 1 x CAT Construction 15-inch Excavator Toy



Image: The CAT Construction 15-inch Excavator toy, showcasing its yellow body, black wheels, and articulated arm with a scoop.

3. Setup

The CAT Construction Excavator toy comes pre-assembled and ready for play. No batteries or complex assembly are required.

1. **Unboxing:** Carefully remove the excavator from its packaging.
2. **Inspection:** Before first use, inspect the toy for any signs of damage or loose parts. If any issues are found, please contact customer support.
3. **Ready for Play:** The excavator is now ready for immediate use.

4. Operating Instructions

The CAT Construction Excavator is a push-powered toy designed for interactive play. Its articulated parts allow for realistic digging and scooping actions.

4.1 Moving the Excavator

The excavator features free-rolling wheels. Simply push the toy forward or backward on any flat surface to move it. It is suitable for various terrains, including sandboxes and outdoor play areas.



Image: A child playing with the CAT Excavator in a sandbox, demonstrating outdoor use.

4.2 Using the Articulated Arm and Scoop

The excavator's arm and scoop are designed to mimic real construction equipment. They can be manually adjusted to perform various actions:

- **Extend the Arm:** Gently pull the arm outwards from the main body to extend it.
- **Retract the Arm:** Push the arm inwards towards the main body to retract it.
- **Operate the Scoop:** The scoop can be tilted up and down to dig or dump materials. Use your hand to manipulate the scoop's position.

These movements allow for realistic digging, lifting, and dumping of sand, dirt, or other play materials.



Image: The CAT Excavator with its arm fully extended forward, ready for digging.



Image: The CAT Excavator with its arm retracted, suitable for transport or resting position.

5. Maintenance and Care

To ensure the longevity and optimal performance of your CAT Construction Excavator, follow these simple maintenance guidelines:

- **Cleaning:** After outdoor play, especially in sand or dirt, wipe the toy clean with a damp cloth. For stubborn dirt, a mild soap solution can be used. Rinse thoroughly and allow to air dry completely before storage.
- **Storage:** Store the toy in a clean, dry place away from direct sunlight and extreme temperatures when not in use.
- **Inspection:** Periodically check all moving parts and connections for wear or damage.

6. Troubleshooting

While the CAT Construction Excavator is designed for durability, you might encounter minor issues. Here are some common points and solutions:

6.1 Stiff Arm or Scoop Movement

Some users may find the articulated arm or scoop movements to be stiff initially. This is often due to the robust design intended for durability and holding positions during play.

- **Solution:** Continue to operate the arm and scoop gently. Over time, the joints may loosen slightly with regular use, making movements smoother. Avoid forcing the parts, as this could cause damage.
- **Cleaning Joints:** If stiffness is accompanied by grinding or resistance, check for sand, dirt, or debris lodged in the joints. Clean thoroughly as per the maintenance instructions.

7. Specifications

Feature	Detail
Model Number	82035
Product Dimensions	15 x 8 x 9 inches (38.1 x 20.32 x 22.86 cm)
Item Weight	1 pound (0.45 kg)
Recommended Age	36 months - 8 years
Material	Durable Plastic
Power Source	Push-powered (no batteries required)
Manufacturer	Funrise, Inc.



Image: The CAT Excavator with its key dimensions (length, width, height) indicated.

8. Warranty and Support

For information regarding warranty coverage or to obtain customer support for your CAT Construction Excavator, please refer to the manufacturer's official website or contact their customer service department directly. Keep your purchase receipt as proof of purchase.
Manufacturer: Funrise, Inc.
For further assistance, please visit the official CAT Toys website or contact your retailer.

© 2025 CAT Construction Toys. All rights reserved. CAT, CATERPILLAR, and their design and marks are registered trademarks of Caterpillar Inc.
Product Model: 82035

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question