

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [UN UNITEDTIME](#) /

> [UN UNITEDTIME Desk and table fan, Foldable Fans Portable Travel Fan Battery Operated or USB Powered,Adjustable Height,My Foldaway fan with remote Control Timer 4 Speed Settings \(White\)](#)

UN UNITEDTIME UT09

UN UNITEDTIME Foldable Fan User Manual

Model: UT09 | Brand: UN UNITEDTIME

1. INTRODUCTION

Thank you for choosing the UN UNITEDTIME Foldable Fan. This versatile device is designed to provide powerful and portable cooling wherever you need it. Its innovative foldable and adjustable design allows it to function as both a compact desk fan and a full-sized floor fan. With multiple speed settings, remote control, and a long-lasting rechargeable battery, it offers convenience and comfort for various environments.

2. KEY FEATURES

- **Portable & Adjustable:** Folded height of 3.7 x 7.76 inches, weighing 1.83lb. Adjustable height from 14.2 inches (desk fan) to 3.3 feet (floor fan).
- **Power Options:** Battery operated (7200mAh built-in rechargeable battery) or USB powered (Micro USB 5V/2A).
- **Speed Settings:** 4 speed settings (Gentle breeze, Fresh breeze, Strong wind, Natural wind mode).
- **Remote Control:** Full control within 5 meters, including power, speed, and timer.
- **Timer Function:** Set operation for 1H, 2H, 3H, or 4H.
- **Quiet Operation:** Designed for low noise levels.
- **Foldable Design:** Space-saving and easy to store.
- **Detachable Blade:** Convenient for cleaning.

3. PACKAGE CONTENTS

Please check the box for the following items:

- 1 x UN UNITEDTIME Foldable Fan (Model UT09)
- 1 x Micro USB Cable
- 1 x Remote Control
- 1 x User Manual

4. SETUP

4.1 Unfolding and Adjusting Height

The fan is designed for easy unfolding and height adjustment. Gently pull the fan head upwards from its compact base. The telescopic rod allows for smooth extension to your desired height, from a desktop fan to a floor-standing unit. Ensure the rod is securely locked in place after adjustment to maintain stability.

COOL ANYTIME, ANYWHERE

Foldaway for east carry Adjustable height

(106CM 41.7")

(41CM 16.1")

(12CM 4.7")

Light & portable

4 speeds

Adjustment angle

Low noise

7200mah large capacity battery

Folding storage

The advertisement features a central image of a fan in three height configurations: a compact desktop fan (12CM / 4.7"), a mid-height floor fan (41CM / 16.1"), and a tall floor fan (106CM / 41.7"). The fan is shown in black and red on the left, and in white on the right. Below the fan images is a row of six icons with corresponding text: a shopping bag for 'Light & portable', a bar chart for '4 speeds', a curved arrow for 'Adjustment angle', a speaker with an 'X' for 'Low noise', a battery icon for '7200mah large capacity battery', and a folded fan for 'Folding storage'.

Image: The fan demonstrating its adjustable height capabilities, from compact to fully extended.

5-24 hours



7200mAh



Image: The fan head can be tilted 180 degrees to direct airflow as needed.

4.2 Charging the Fan

Before first use, fully charge the fan. Connect the provided Micro USB cable to the charging port on the fan's base and plug the other end into a compatible USB power source (e.g., wall adapter, computer USB port). The charging indicator light will show the charging status. A full charge takes approximately 4 hours and provides 5-20 hours of operation depending on the speed setting.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off and Speed Settings

Press the power button located on the fan's base to turn it on. Each subsequent press will cycle through the 4 speed settings: Gentle breeze, Fresh breeze, Strong wind, and Natural wind mode. Pressing the

button after the highest speed will turn the fan off.



Image: Diagram illustrating the four distinct speed modes: Speed 1 (Gentle breeze), Speed 2 (Fresh breeze), Speed 3 (Strong wind), and Natural wind.

5.2 Using the Remote Control

The included remote control allows for convenient operation from a distance of up to 5 meters. The remote has dedicated buttons for power on/off, cycling through speed settings, and activating the timer function.

REMOTE CONTROL FUNCTION



Remote control makes cooling easier



Image: The remote control with buttons for power, wind speed control, and timing control.

5.3 Timer Function

Activate the timer function using the remote control. You can set the fan to automatically turn off after 1 hour, 2 hours, 3 hours, or 4 hours. This is ideal for use during sleep or when you need temporary cooling.

TIMER FUNCTION

Enjoy a comfortable cool every summer night



Image: Visual representation of the fan's timer function, allowing users to set it for 1, 2, 3, or 4 hours.

5.4 Official Product Video

Video: This official product video showcases the UN UNITEDTIME Foldable Fan in various colors and demonstrates its folding and unfolding capabilities, highlighting its portability and ease of use.

6. MAINTENANCE

6.1 Cleaning the Fan

The fan features a detachable blade design for easy cleaning. To clean, ensure the fan is turned off and unplugged. Gently twist the front cover counter-clockwise to remove it. Carefully detach the fan blades and wash them with water. Wipe the main unit with a soft, damp cloth. Ensure all parts are completely dry before reassembling. Reattach the blades and twist the front cover clockwise until it locks securely.



Image: Instructions showing how to detach the fan blade and front cover for thorough cleaning.

7. TROUBLESHOOTING

7.1 Fan Not Turning On

- Ensure the fan is fully charged or connected to a power source.
- Check if the power button on the base or remote control is pressed correctly.

7.2 Weak Airflow

- Increase the speed setting using the base button or remote.
- Check if the fan blades are clean and free from dust or debris.
- Ensure the fan head is properly tilted and positioned for optimal airflow.

7.3 Remote Control Not Working

- Ensure there are no obstructions between the remote and the fan.
- Check the remote control's battery and replace if necessary.

8. SPECIFICATIONS

Feature	Detail
Brand	UN UNITEDTIME
Model Name	UT09
Color	White
Product Dimensions	5"D x 5"W x 10"H (Folded)
Item Weight	2.2 pounds (approx. 1 kg)
Power Source	Battery Powered / Micro USB
Battery Capacity	7200mAh Lithium Ion (included)
Voltage	5 Volts
Speed Settings	4 (including Natural Wind)
Control Method	Remote / Push Button
Special Features	Adjustable Height, Foldable, Remote Control, Adjustable Tilt, Timer

9. WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official User Manual included in your package or visit the UN UNITEDTIME website. You can also find additional support resources and contact information through the retailer where you purchased the product.

User Manual (PDF):

<https://manuals.plus/m/e25d01371e3682882b7b49c8b68f79b9654f36d7a0b240d2085bd44ecdb248ae>