



Manuals.plus /

› JISULIFE /

› JISULIFE Handheld Mini Fan F8 User Manual

## JISULIFE F8

# JISULIFE Handheld Mini Fan F8 User Manual

Model: F8 | Brand: JISULIFE


## 1. INTRODUCTION

---

Thank you for choosing the JISULIFE Handheld Mini Fan F8. This versatile device combines a portable fan, a power bank, and a flashlight into one compact unit, designed to provide convenience and comfort in various situations. Please read this manual thoroughly before use to ensure proper operation and maintenance.

# Triple The Function, Zero The Hassle

 Cooling



 Charging



 Lighting




Image: The JISULIFE Handheld Mini Fan F8 highlighting its triple functionality: fan for cooling, power bank for charging devices, and an integrated flashlight for illumination.

## 2. PACKAGE CONTENTS

- JISULIFE Handheld Mini Fan F8 (Brown)

- USB-C Charging Cable
- Lanyard (pre-attached or included separately)
- User Manual (this document)

### **3. PRODUCT OVERVIEW**

---

Familiarize yourself with the components of your JISULIFE Handheld Mini Fan F8.



Image: The JISULIFE Handheld Mini Fan F8 displayed in both its compact, folded state and its extended, operational state, revealing the fan blades, USB-A output port, and USB-C input port.

### Key Components:

- **Fan Blades:** Soft, flexible blades for safety.
- **Power Button:** Controls fan speed and flashlight.
- **USB-C Input Port:** For charging the fan's internal battery.
- **USB-A Output Port:** For using the fan as a power bank to charge other devices.
- **Flashlight:** Integrated LED light at the base.
- **Folding Hinge:** Allows transformation between handheld and desktop modes.

## 4. SETUP

---

### 4.1 Initial Charging

Before first use, fully charge your JISULIFE Handheld Mini Fan F8. This ensures optimal battery performance and longevity.

1. Connect the provided USB-C charging cable to the fan's USB-C input port.
2. Connect the other end of the cable to a USB power adapter (e.g., phone charger, computer USB port) or a power bank.
3. The charging indicator lights will illuminate, typically blinking during charging and solid when fully charged.
4. A full charge usually takes 2-3 hours.

# USB-C Rechargeable Long-lasting Freshness



Image: The JISULIFE Handheld Mini Fan F8 connected to a USB-C charging cable, illustrating the charging process.

## 5. OPERATING INSTRUCTIONS

### 5.1 Transforming the Fan

The fan features a 3-stage transformable design for various uses:

- **Closed Mode:** For compact storage and protection of blades.
- **Handheld Mode (180° fold):** Extend the fan to a straight position for handheld use.
- **Desktop Mode (270° fold):** Fold the fan to create a stable base for desktop use.



Image: Visual guide demonstrating two methods to open the fan from its compact state: by using a small gap between the fan cover and main body, or by pressing the base near the USB connector to expose the top.

## 5.2 Fan Operation

To operate the fan:

1. **Power On/Speed 1:** Short press the power button once.
2. **Speed 2:** Short press the power button a second time.
3. **Power Off:** Short press the power button a third time.

The fan features touch-sensitive auto-stop for safety. The blades will instantly stop if touched.

# Designed With Care



## Touch-Sensitive Auto-Stop

The fan instantly stops when touched  
—no worries, no accidents

## Soft, Flexible Blades for Enhanced Safety

Gentle to the touch, safe for everyone



Image: A detailed view of the JISULIFE Handheld Mini Fan F8, illustrating its soft, flexible blades and the touch-sensitive auto-stop safety feature, where the fan stops instantly upon contact.

### 5.3 Power Bank Function

The fan can be used as a backup power bank to charge your mobile devices.

1. Connect your device's charging cable to the USB-A output port on the fan.
2. The fan will automatically begin charging your device.
3. Ensure the fan has sufficient charge for this function.

## 5.4 Flashlight Operation

To use the integrated flashlight:

1. **Turn On:** Long press the power button for approximately 2 seconds.
2. **Turn Off:** Long press the power button again for approximately 2 seconds.




Image: A close-up of the JISULIFE Handheld Mini Fan F8's power button, detailing its functions: short press for power on/off and fan speed adjustment, and long press to activate/deactivate the flashlight.

## 6. MAINTENANCE

### 6.1 Cleaning

- Ensure the fan is turned off before cleaning.
- Use a soft, dry cloth to wipe the exterior of the fan.
- For the fan blades, gently wipe them with a slightly damp cloth if necessary, then dry immediately.
- Do not use abrasive cleaners, alcohol, or harsh chemicals.
- Do not immerse the fan in water or any other liquid.

### 6.2 Storage

- Store the fan in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, charge the battery to approximately 50% every 3 months to preserve battery life.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not turn on.	Battery is depleted.	Charge the fan fully using the provided USB-C cable.
Fan speed is weak.	Low battery or incorrect speed setting.	Charge the fan. Press the power button to cycle to a higher speed setting.
Flashlight does not turn on.	Battery is depleted or incorrect button press.	Charge the fan. Ensure you are long-pressing the power button to activate the flashlight.
Cannot charge external device (power bank function).	Fan battery is low or cable issue.	Ensure the fan is fully charged. Try a different USB-A cable for your device.
Fan blades stop unexpectedly.	Safety auto-stop feature activated.	This is normal. The fan stops if the blades are touched. Remove any obstruction and restart the fan.

## 8. SPECIFICATIONS

Feature	Detail
Brand	JISULIFE
Model Name	F8
Color	Brown
Power Source	Battery Powered
Battery Type	1 Lithium Ion battery (included)
Working Hours	12-19 hours (depending on speed)
Charging Time	2-3 hours
Product Dimensions	1.46"D x 1.57"W x 4.72"H
Item Weight	4.4 ounces (126 Grams)
Noise Level	60 dB
Wattage	4 watts
Voltage	5V
Number of Blades	2
Blade Length	3 Inches
Control Method	Touch (Push Button)
Special Feature	3 IN 1 Pocket Fan with Flashlight and Power Bank Function

## 9. SAFETY INFORMATION

- Keep out of reach of children.
- Do not insert fingers or foreign objects into the fan blades while operating.

- Do not disassemble, repair, or modify the product yourself. Contact qualified personnel for service.
- Avoid exposing the fan to extreme temperatures, direct sunlight, or high humidity.
- Do not use the fan near water or in wet environments.
- Use only the provided charging cable or a certified equivalent.
- Dispose of the product and its battery responsibly according to local regulations.

## 10. WARRANTY AND SUPPORT

---

JISULIFE products are manufactured to high-quality standards. For information regarding warranty coverage, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official JISULIFE website. Please retain your proof of purchase for warranty claims.

For further assistance, you may contact JISULIFE customer support through their official channels.