

- Manuals.plus /
- › COMHOMA /
- › COMHOMA Recliner Chair User Manual

COMHOMA H7134-BROWN

COMHOMA Recliner Chair User Manual

MODEL: H7134-BROWN

Your Guide to Comfort and Relaxation

Introduction

Thank you for choosing the COMHOMA Recliner Chair. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure you get the most out of your new chair. Designed for ultimate comfort, this recliner features 360° swivel, rocking, reclining, heat, and massage functions, along with convenient cup holders and side pockets.



The COMHOMA Recliner Chair, designed for comfort and versatility.

Important Safety Information

WARNING:

This product has a maximum weight capacity of 400 pounds and is intended for adult use. When using the reclining, swivel, massage, and heating functions, ensure the chair is stable and does not tip over. Improper use may result in injury. Please refer to the user manual for detailed safety instructions.

Package Contents

Before assembly, please ensure all parts are present and undamaged. The package should include:

- Chair Base (with swivel mechanism)
- Backrest
- Seat Cushion
- Armrests (Left and Right, with cup holders)
- Power Adapter and Remote Control
- Assembly Hardware (screws, Allen wrench)
- Instruction Manual (PDF version available via [Installation Manual \(PDF\)](#))



SIZE
...



Refer to the dimension diagram for proper placement and fit.

Assembly Instructions

The COMHOMA Recliner Chair is designed for easy assembly. Follow these steps carefully:

1. Unpack all components from the box. Ensure no parts are missing or damaged.
2. Attach the side panels to the chair base. Ensure the brackets are properly aligned and secured.
3. Connect the electrical cables for the massage and heat functions. These are typically color-coded for easy matching.
4. Slide the backrest onto the pre-installed brackets on the chair base until it clicks securely into place.
5. Connect any remaining cables for the backrest.
6. Test the reclining mechanism by pulling the lever and applying pressure to the backrest.
7. Plug in the power adapter and test the heat and massage functions using the remote control.

For a visual guide, please watch the official assembly video:

Your browser does not support the video tag.

Official COMHOMA Recliner Showcase - Easy Setup video, demonstrating the unboxing and assembly process.

Another helpful video demonstrating assembly and features:

Your browser does not support the video tag.

Video showcasing the assembly and features of the Modern Leather Recliner with Heated Massage.

PRODUCT DETAILS



Detailed view of the recliner's components and construction.

Operating Instructions

Your COMHOMA Recliner Chair offers multiple functions for personalized comfort:

- **360° Swivel:** Effortlessly rotate the chair in any direction to face your desired view or join conversations.
- **Rocking Function:** Enjoy a gentle rocking motion for soothing relaxation.
- **Reclining:** Pull the side lever to extend the footrest and recline the backrest to your preferred angle. Apply pressure to the backrest to adjust further.
- **Heat and Massage:** Use the wired remote control to activate and customize the heat and massage functions. The remote allows you to select different massage modes (pulse, press, wave, auto), intensity levels (high, low), and target specific body areas (back, lumbar, thigh, leg). The heat function provides gentle warmth for added comfort.
- **Cup Holders & Side Pockets:** Keep your beverages secure in the integrated cup holders and store essentials like

remotes or magazines in the convenient side pockets.

ROCKING FUNCTION



110°-160°



Reading



Watching TV



Napping time

The rocking function allows for various comfortable positions.

Easy to use

message remote control



4 massage
Parts



5 massage
Modes



Heat function
For lumbar part



Vibration
Strength



Zero gravity
Regulation



360° Degrees
Swivel

The remote control provides easy access to heat and massage settings.

Watch this video for a demonstration of the heat and massage features:

Your browser does not support the video tag.

Video demonstrating the heat and massage functions of the recliner chair.

Maintenance

To ensure the longevity and appearance of your COMHOMA Recliner Chair, follow these simple maintenance guidelines:

- **Cleaning:** Wipe clean with a damp cloth. For tougher spots, use a mild soap solution and wipe dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Spills:** Blot spills immediately with a clean, dry cloth. Do not rub.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading and material degradation.

- **Moving the Chair:** When moving the chair, lift it rather than dragging to prevent damage to the base and flooring.

Troubleshooting

If you encounter any issues with your recliner, refer to the common problems and solutions below:

Problem	Possible Cause / Solution
Footrest difficult to lock/unlock	Ensure you are applying sufficient pressure to the footrest to engage/disengage the locking mechanism. Some models may require firm pressure.
Massage/Heat not working	Check if the power adapter is securely plugged into both the chair and a working electrical outlet. Ensure the remote control is properly connected to the chair's wiring.
Chair does not recline smoothly	Inspect the reclining mechanism for any obstructions or loose connections. Ensure the chair is on a level surface.
Unstable or wobbling	Verify that all assembly screws and brackets are tightened securely. Ensure the chair is placed on a flat, stable surface.

If the issue persists, please contact customer support.

Specifications

Feature	Detail
Brand	COMHOMA
Model Name	recliner chair (H7134-BROWN)
Color	Brown
Product Dimensions	37.4"D x 38.5"W x 40.94"H
Item Weight	99.5 pounds
Maximum Weight Recommendation	400 Pounds
Material	Foam (Fill Material), Leather (Furniture Finish)
Special Features	Reclining, Side Pocket, Adjustable Lumbar, Rocking, Ergonomic, Heated, Swivel, Durable, Breathable, Foot Rest
Back Style	Cushion Back
Furniture Base Movement	Swivel

Feature	Detail
FSC-Certified	Yes (wood)



Detailed dimensions of the recliner chair.

Warranty and Support

Your COMHOMA Recliner Chair comes with a 30-day easy return policy. For any product-related inquiries, technical assistance, or warranty claims, please contact COMHOMA customer support through the retailer where you purchased the product.

Additional protection plans may be available for purchase:

- 2-Year Protection Plan

- 3-Year Protection Plan
- Complete Protect (monthly plan)

For further details, please refer to the [Installation Manual \(PDF\)](#) or visit the official COMHOMA store page.

© 2025 COMHOMA. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07QGR7XYV>

More documents and user manuals: <https://manuals.plus/>