

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Spilay](#) /
- › [Spilay DIY Dollhouse Miniature Kit B29 Instruction Manual](#)

Spilay B29

Spilay DIY Dollhouse Miniature Kit B29 Instruction Manual

Model: B29

1. INTRODUCTION

This manual provides detailed instructions for assembling, operating, and maintaining your Spilay DIY Dollhouse Miniature Kit, Model B29. This 1:24 scale miniature model features a rotating mechanism, a music box, and a protective glass cover. It is designed for individuals aged 14 years and older.



Image 1.1: Fully assembled Spilay B29 Dollhouse Miniature with its protective glass cover, showcasing the multi-level interior and base.

2. SAFETY INFORMATION

- **Age Recommendation:** This kit is suitable for individuals aged 14 years and older due to small parts and the complexity of assembly.
- **Small Parts:** The kit contains small components that may pose a choking hazard. Keep out of reach of young children.
- **Adhesives:** Assembly requires silicone liquid glue (not included). Use in a well-ventilated area and follow the glue manufacturer's safety instructions. Avoid contact with skin and eyes.
- **Batteries:** Requires 3x LR44 batteries (not included). Insert batteries correctly, observing polarity. Do not mix old and new batteries or different types of batteries. Dispose of used batteries responsibly.
- **Sharp Edges:** Some components may have sharp edges. Handle with care during assembly.

3. PACKAGE CONTENTS

The Spilay DIY Dollhouse Miniature Kit B29 includes the following items:

- Pre-cut wooden pieces for the dollhouse structure and furniture.

- Fabric, paper, and other decorative materials.
- LED lighting components and wiring.
- Music box mechanism.
- Glass cover.
- English instruction manual.
- Small tools (tweezers, ruler, etc., may vary by package).

Note: Silicone liquid glue and 3x LR44 batteries are **not included** and must be purchased separately.

4. SETUP AND ASSEMBLY

Assembly of the Spilay B29 Dollhouse Miniature Kit requires patience and attention to detail. Follow the included English manual step-by-step for best results.

4.1 Preparation

- Unpack all components and verify against the parts list in the English manual.
- Gather necessary tools: silicone liquid glue, 3x LR44 batteries, scissors, tweezers, ruler, and a small screwdriver (if needed).
- Work on a clean, well-lit surface.

4.2 Wiring and Battery Installation

1. **Prepare Wires:** Trim each power wire (LED lamps) first. Twist the positive wires together and the negative wires together.
2. **Connect to Battery Box:** Open the power and test the LED lamps. Put power wires in the iron box as shown in the manual. Apply glue to the indicated position, then secure the upper part of the iron box. Ensure the transparent cover is not loosened by sticking it in the wrong position.
3. **Install Batteries:** Insert 3x LR44 batteries into the battery compartment, ensuring correct polarity.
4. **Secure Foundation:** Twist the foundation to align with the battery box position, allowing easy access to the switch.

Color English instruction



Image 4.1: Visual guide for connecting wires and installing batteries in the dollhouse base. This image illustrates the steps for preparing wires, connecting them to the battery box, and securing the foundation for the lighting and music functions.

4.3 Main Structure and Furniture Assembly

- Follow the detailed diagrams and instructions in the English manual to assemble the wooden structure of the dollhouse.
- Carefully cut out paper and fabric components and glue them to the designated areas to create miniature furniture and decorations.
- Pay close attention to the placement of each item as shown in the manual and reference images.

Color English instruction



(Place the articles as photo shown)



(Align the bayonet of transparent cover and groove position of iron box, whirl the transparent cover and fasten the iron box)

the internal scene will rotate



(Whirl the foundation, the melodious music begins to sound)
the internal scene will rotate

Image 4.2: Illustration showing the assembly of interior elements and the placement of miniature furniture and decorative items within the dollhouse structure.



Image 4.3: Close-up view of various miniature furniture pieces and decorative elements, such as a bed, desk, and bathroom fixtures, demonstrating the intricate details of the kit.



Image 4.4: Additional close-up showcasing different miniature rooms and their furnishings, including a study, bathroom, and bedroom, highlighting the variety of items to assemble.

4.4 Attaching the Glass Cover

- Once the main assembly is complete, align the bayonet of the transparent glass cover with the groove position on the iron box.
- Gently whirl the transparent cover to fasten it securely to the iron box. This protects the finished dollhouse kit.

5. OPERATING INSTRUCTIONS

After successful assembly, your Spilay B29 Dollhouse Miniature Kit can be operated as follows:

- **Lights:** Locate the switch on the battery box at the base of the dollhouse. Flip the switch to turn the LED lights on or off.
- **Music and Rotation:** Gently whirl the foundation of the dollhouse. The melodious music will begin to play, and the internal scene of the dollhouse will rotate.

Color English instruction



(Place the articles as photo shown)



(Align the bayonet of transparent cover and groove position of iron box, whirl the transparent cover and fasten the iron box)

the internal scene will rotate



(Whirl the foundation, the melodious music begins to sound)
the internal scene will rotate

Image 5.1: Demonstrates how to activate the rotating mechanism and music box by whirling the dollhouse foundation.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to gently wipe the glass cover and exterior surfaces. Avoid using abrasive cleaners or excessive moisture.
- **Dusting:** For interior dusting, use a soft brush or compressed air to carefully remove dust from miniature components.
- **Battery Replacement:** When the lights dim or the music/rotation stops, replace the 3x LR44 batteries. Ensure correct polarity during replacement.
- **Storage:** Store the dollhouse in a dry, cool place away from direct sunlight to prevent fading or damage to materials.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Lights do not turn on.	<ul style="list-style-type: none"> ◦ Batteries are dead or incorrectly inserted. ◦ Wiring connection is loose or incorrect. ◦ Switch is off. 	<ul style="list-style-type: none"> ◦ Replace batteries, ensuring correct polarity. ◦ Check all wire connections as per Section 4.2. ◦ Ensure the power switch is in the "ON" position.
Music or rotation does not work.	<ul style="list-style-type: none"> ◦ Batteries are dead or incorrectly inserted. ◦ Foundation not whirled correctly. ◦ Music box mechanism is stuck. 	<ul style="list-style-type: none"> ◦ Replace batteries, ensuring correct polarity. ◦ Ensure the foundation is whirled firmly to activate the mechanism. ◦ Gently check for any obstructions around the rotating parts.
Missing or damaged parts during assembly.	Manufacturing defect or shipping damage.	Contact Spilay customer support immediately (see Section 9).

8. SPECIFICATIONS

Model Number	B29
Brand	Spilay
Scale	1:24
Finished Product Dimensions (LxWxH)	Approximately 11 x 11 x 18 cm (4.33 x 4.33 x 7.08 inches)
Item Weight	Approximately 318 g (0.7 lbs)
Material Type(s)	Wood, Cloth, Paper, Glass
Recommended Age	14 years and up
Batteries Required	3x LR44 (not included)

9. WARRANTY AND SUPPORT

The Spilay Dollhouse Miniature Kit B29 has undergone careful inspection before delivery to ensure all accessories are complete and no parts are missing. If you encounter any questions or issues during assembly or operation, please contact Spilay customer support. They will assist you in resolving any problems as quickly as possible. For support, please refer to the contact information provided with your purchase or on the official Spilay website.