

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [KitchenAid](#) /

› [KitchenAid 2-Speed Hand Blender Instruction Manual \(Model B07QHQB2L9\)](#)

KitchenAid B07QHQB2L9

KitchenAid 2-Speed Hand Blender Instruction Manual

Model: B07QHQB2L9

INTRODUCTION

The KitchenAid 2-Speed Hand Blender is designed for quick and easy blending, pureeing, and crushing of various ingredients. Its compact design and powerful motor make it ideal for preparing smoothies, soups, hummus, dressings, sauces, and more. This manual provides essential information to ensure safe and efficient use of your appliance.

Key Features

- **8" Blending Arm with Fixed S-Blade:** Designed to quickly blend smoothies, soups, hummus, and more.
- **Soft Grip Handle:** Offers a non-slip and comfortable grip during operation.
- **3-Cup BPA-Free Blending Jar with Lid:** Convenient for small blending jobs and storage.
- **2 Speed Settings:** Provides versatility for different blending tasks.

SETUP

Before first use, ensure all packaging materials are removed. Wash the blending arm and blending jar with warm, soapy water, then rinse and dry thoroughly. The main motor body should be wiped clean with a damp cloth.

Assembly

1. Align the blending arm with the motor body.
2. Twist the blending arm clockwise until it locks securely into place. You should feel a click or a firm connection.
3. Ensure the blending arm is fully attached before plugging in the appliance.





Image: KitchenAid 2-Speed Hand Blender with its detachable blending arm and 3-cup blending jar.

OPERATING INSTRUCTIONS

Always ensure the appliance is unplugged before attaching or detaching any parts.

Blending

1. Prepare your ingredients and place them in a suitable container, such as the included blending jar or a deep pot.
2. Plug the hand blender into a power outlet.
3. Submerge the blending arm into the ingredients before pressing the power button to prevent splashing.
4. Press and hold the power button located on the handle to start blending.
5. Adjust the speed setting (1 or 2) using the dial on top of the motor body, if desired.
6. Move the blending arm up and down and in circular motions to ensure all ingredients are thoroughly blended to your desired consistency.
7. Release the power button to stop the appliance.
8. Unplug the hand blender from the power outlet after use.





Image: Close-up of the KitchenAid 2-Speed Hand Blender, highlighting the power button and speed dial.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your KitchenAid Hand Blender.

Cleaning

1. Always unplug the appliance before cleaning.
2. Detach the blending arm from the motor body by twisting it counter-clockwise.
3. The blending arm and blending jar are dishwasher safe (top rack recommended) or can be washed by hand with warm, soapy water. Rinse thoroughly.
4. Wipe the motor body with a damp cloth. Do not immerse the motor body in water or other liquids.
5. Ensure all parts are completely dry before reassembling or storing.

TROUBLESHOOTING

If you encounter any issues with your KitchenAid Hand Blender, please refer to the following common solutions:

- **Appliance does not turn on:** Ensure the hand blender is securely plugged into a working power outlet and the blending arm is correctly attached to the motor body.
- **Ingredients are not blending smoothly:** Ensure the blending arm is fully submerged. Try adjusting the speed setting or moving the blending arm more thoroughly through the ingredients.
- **Excessive splashing:** Always submerge the blending arm into the ingredients before starting the appliance. Avoid lifting the blending arm above the liquid level while operating.

For further assistance, please contact KitchenAid customer support.

SPECIFICATIONS

Feature	Detail
Brand	KitchenAid
Model Number	B07QHQB2L9
Color	Aqua Sky
Product Dimensions	4.4"D x 12.6"W x 4.3"H
Material	Stainless Steel (Blade)
Included Components	8" Blending arm with fixed s-blade, 3 cup blending jar with lid
Power Source	Corded Electric
Wattage	180 watts
Number of Speeds	2
Voltage	220 Volts
Material Type Free	BPA Free
Dishwasher Safe	No (Motor body), Yes (Blending arm, blending jar)
Item Weight	2.58 Pounds

WARRANTY AND SUPPORT

This KitchenAid 2-Speed Hand Blender comes with a **1-year manufacturer's warranty**. For warranty claims, product support, or any inquiries, please refer to the contact information provided in your product packaging or visit the official KitchenAid website.