

Wacom CTL6100WLK0

Wacom Intuos CTL6100WLK0 Creative Pen Tablet User Manual

Model: CTL6100WLK0

INTRODUCTION

The Wacom Intuos Bluetooth pen tablet is designed for individuals beginning their journey in digital drawing, painting, or photo editing on Mac or PC. This device offers wireless connectivity via Bluetooth or a direct connection using the included USB cable. It features a lightweight, pressure-sensitive pen and a design focused on user comfort and precision. The tablet is compatible with various creative software applications.



Image: The Wacom Intuos tablet and pen, surrounded by illustrations of digital art tools and creative concepts.

PRODUCT OVERVIEW

Package Contents

Verify that all items are present in the package:

- Wacom Intuos Pen Tablet (Medium, Black)
- Wacom Pen 4K (pressure-sensitive, battery-free)
- PVC-free USB cable with cable tidy and L-shaped connector
- 3 extra standard nibs (located inside the pen)
- Nib removal tool (on end of pen)
- Quickstart guide
- Regulation sheet

Plug in and you're good to go

Intuos is compatible with MacOS, and Windows. Internet access is needed to download driver. Chromebook's are plug-and-play, no driver install needed.



M E D I U M

Included in the Box

Wacom Intuos, Medium
Wacom Pen 4K
6.6 ft USB cable
3 replacement nibs



I N T U O S

Image: Contents of the Wacom Intuos package, including the tablet, pen, USB cable, and replacement nibs, along with compatible operating systems.

Key Features

- **Connectivity:** Bluetooth and USB for flexible connection options.
- **Pressure Sensitivity:** 4096 levels for precise control and natural drawing experience.
- **Battery-Free Pen:** The Wacom Pen 4K operates without batteries, ensuring continuous use.
- **Customizable ExpressKeys:** Four customizable buttons on the tablet for shortcuts.
- **Active Area:** 8.5 inches x 5.3 inches for the Medium model.

A natural drawing experience



**BATTERY
FREE PEN**



**PEN
BUTTONS**



The ergonomic design and light weight pen sits comfortably in your hand, providing both precision and control.

I N T U O S

Image: A user interacting with the Wacom Intuos tablet using the Wacom Pen 4K, emphasizing the pen's ergonomic design and functionality.

SETUP

1. Driver Installation

For Windows and macOS, an internet connection is required to download and install the latest Wacom drivers. Visit the official Wacom website for driver downloads specific to your operating system and tablet model.

Chromebook users can connect the tablet directly; no driver installation is required as it is plug-and-play.

2. Connecting via USB

1. Connect the L-shaped end of the included USB cable to the port on your Wacom Intuos tablet.
2. Connect the other end of the USB cable to an available USB port on your computer.
3. The tablet will power on automatically.

- **Hovering:** Hold the pen slightly above the tablet surface to move the cursor without making contact.
- **Pen Buttons:** The pen features two customizable buttons. By default, these often function as right-click and scroll/pan, but their functions can be changed in the Wacom Tablet Properties software.

Customizing ExpressKeys

The four ExpressKeys located on the top of your tablet can be assigned to various functions, such as keyboard shortcuts, mouse clicks, or navigation commands. To customize them:

1. Open the Wacom Tablet Properties software on your computer.
2. Navigate to the "ExpressKeys" tab.
3. Select each ExpressKey and choose the desired function from the available options.



Make it yours

Work your way by customizing the ExpressKeys and pen buttons to speed up workflow.

I N T U O S


Image: The customizable ExpressKeys on the Wacom Intuos tablet, designed to speed up workflow.

Software Integration

The Wacom Intuos tablet is compatible with most creative applications. It also includes access to downloadable software such as Corel Painter Essentials (drawing/painting), Corel AfterShot (photo-editing), and Clip Studio Paint Pro (comic/manga, 2-year license). Ensure your software is up-to-date for the best experience.

Software to suit you

Purchase includes software for:
DIGITAL DRAWING & PAINTING
PHOTO EDITING
VISUAL EFFECTS



In addition to working as your mouse, the Wacom Intuos works with most creative applications and other software.

I N T U O S

Image: Examples of creative work possible with the Wacom Intuos and compatible software.

MAINTENANCE

Replacing Pen Nibs

The Wacom Pen 4K comes with three extra standard nibs stored inside the pen itself. Nibs wear down with use and should be replaced when they become too short or sharp, or if they affect drawing performance.

1. Unscrew the end of the pen to access the spare nibs.
2. Use the nib removal tool (integrated into the pen's end) to gently pull out the old nib.
3. Insert a new nib firmly into the pen until it clicks into place.
4. Replace the pen's end cap.

Cleaning the Tablet and Pen

- Use a soft, lint-free cloth, slightly dampened with water, to clean the tablet surface and pen.
- Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the device.
- Ensure the tablet is disconnected from power before cleaning.

TROUBLESHOOTING

- **Tablet not responding:**

- Check USB cable connection or Bluetooth pairing status.
- Ensure the tablet is powered on.
- Restart your computer.
- Verify that the Wacom drivers are correctly installed and up-to-date.

- **Pen not working:**

- Check if the nib is properly inserted or needs replacement.
- Ensure the pen is within the active area of the tablet.
- Test the pen in Wacom Tablet Properties to check its functionality.

- **Bluetooth connection issues:**

- Ensure the tablet is fully charged (if applicable, though this model's pen is battery-free, the tablet itself might have a battery for Bluetooth).
- Unpair and re-pair the tablet with your computer.
- Reduce distance between tablet and computer, and remove potential interference sources.

SPECIFICATIONS

Brand: Wacom

Model: CTL6100WLK0

Connectivity Technology: Bluetooth, USB

Pressure Sensitivity: 4096 Levels

Operating System Compatibility: OS X 10.11 El Capitan and above, Windows 7 and above, Chromebook (plug-and-play)

Compatible Devices: Personal Computer

Active Surface Area: 8.5 inches x 5.3 inches (Medium size)

Item Dimensions (L x W): 10.4"L x 7.8"W

Item Weight: 14.5 Ounces

Color: Black

Pen: Wacom Pen 4K (battery-free)



Image: Physical dimensions of the Wacom Intuos Medium tablet.

WARRANTY AND SUPPORT

Warranty Information

This Wacom Intuos tablet comes with a **1-year manufacturer warranty**. Please retain your proof of purchase for warranty claims. For detailed terms and conditions, refer to the regulation sheet included in your package or visit the official Wacom website.

Customer Support

For further assistance, technical support, or to access additional resources such as updated drivers and tutorials, please visit the official Wacom support website. You can also find contact information for customer service there.

Wacom Official Website: www.wacom.com