

Hemudu HT1001BP

Hemudu HT1001BP TV Floor Stand Instruction Manual

Model: HT1001BP

1. INTRODUCTION

Thank you for choosing the Hemudu HT1001BP TV Floor Stand. This manual provides detailed instructions for the safe and proper assembly, operation, and maintenance of your new TV stand. Please read all instructions carefully before installation and retain this manual for future reference.

This TV floor stand is designed to support LCD, LED, and OLED televisions ranging from 19 to 43 inches, with a maximum weight capacity of 45 kg. It features adjustable height, swivel, and tilt functions to optimize your viewing experience.

2. SAFETY INFORMATION

- **Weight Capacity:** Do not exceed the maximum weight capacity of 45 kg (99 lbs). Overloading can result in serious injury or property damage.
- **TV Size:** This stand is suitable for TVs between 19 and 43 inches. Ensure your TV falls within this range.
- **VESA Compatibility:** Verify your TV's VESA mounting pattern (distance between mounting holes on the back of the TV) is compatible with the stand (75x75mm, 100x100mm, 200x100mm, 200x200mm).
- **Assembly:** Follow all assembly instructions carefully. If you have any doubts, consult a qualified professional.
- **Stability:** Ensure the stand is placed on a stable, level surface. Do not place heavy objects on the stand's base.
- **Children:** Keep children away from the stand during assembly. Do not allow children to climb on or play with the stand or attached TV.
- **Damage:** Do not use the stand if any parts are damaged or missing. Contact customer support for replacement parts.

3. PACKAGE CONTENTS

Before assembly, please verify that all components are present and undamaged. Refer to the parts list in your included assembly guide. Typical components include:

- Main support column
- Tempered glass base
- TV mounting bracket
- Various screws, washers, and spacers for TV attachment
- Assembly hardware (bolts, nuts, tools)
- Cable management clips



Image 3.1: This image illustrates the dimensions of the stand and various VESA mounting patterns (75x75mm, 100x100mm, 200x100mm, 200x200mm) supported by the TV mounting bracket. It also indicates the maximum weight capacity of 45 kg.

4. SPECIFICATIONS

Feature	Specification
Model Number	HT1001BP

It is recommended to have two people for assembly to ensure safety and ease of installation. Please lay out all parts on a soft, clean surface to prevent scratches.

5.1. Base Assembly

1. Attach the main support column to the tempered glass base using the provided bolts and tools. Ensure all connections are secure.
2. Verify the non-slip feet are properly attached to the bottom of the glass base for stability.

5.2. TV Mounting Bracket Assembly

1. Attach the TV mounting bracket to the main support column. This step often involves selecting the initial height setting. The stand offers 16 levels of height adjustment, with some adjustments made during initial assembly and others post-installation.
2. Secure the bracket firmly to the column using the designated screws and locking mechanisms.



Image 5.1: This image demonstrates the 16 levels of height adjustment available for the TV stand. It shows how the height can be set during initial assembly and further fine-tuned after the TV is mounted.

5.3. Attaching the TV

1. Carefully place your TV face down on a soft, clean surface.
2. Identify the VESA mounting holes on the back of your TV.
3. Select the appropriate screws, washers, and spacers from the provided hardware kit that match your TV's VESA pattern and depth.
4. Attach the TV mounting arms (part of the bracket) to the back of your TV. Ensure they are securely fastened but do not overtighten.
5. With assistance, carefully lift the TV and hook the mounting arms onto the main TV mounting bracket on the stand.
6. Secure the TV to the bracket using the safety screws or locking mechanisms to prevent accidental dislodgement.



Image 5.2: This image illustrates the stand's design, allowing it to fit discreetly behind a TV console, saving space and offering a clean, drill-free assembly solution.

6. OPERATING INSTRUCTIONS

6.1. Height Adjustment

The stand offers 16 levels of height adjustment. Some adjustments are made during the initial assembly by choosing the mounting holes on the main column. For minor post-installation adjustments, loosen the securing knob on the back of the TV mounting bracket, slide the TV to the desired height, and re-tighten the knob firmly.

6.2. Swivel Adjustment

The TV can be swiveled up to ± 50 degrees (100 degrees total) to achieve optimal viewing angles from different positions in the room. Gently grasp the sides of your TV and rotate it to the desired angle. The swivel mechanism is designed for smooth movement.



Image 6.1: This image visually explains the ± 50 degree swivel function, allowing users to easily adjust the TV's orientation for comfortable viewing from various seating arrangements.

6.3. Tilt Adjustment

The TV can be tilted from +10 degrees (upward) to -15 degrees (downward). To adjust the tilt, locate the tilt adjustment knobs or bolts on the sides of the TV mounting bracket. Loosen them slightly, adjust the TV to the desired tilt angle, and then re-tighten them securely to lock the position.



Image 6.2: This image demonstrates the tilt functionality, allowing the TV to be angled upwards by +10 degrees or downwards by -15 degrees for glare reduction or ergonomic viewing.

7. CABLE MANAGEMENT

The Hemudu HT1001BP TV Floor Stand includes cable management clips to help organize and conceal unsightly cables. After connecting all necessary cables to your TV and devices, gather them neatly along the main support column. Use the provided clips to secure the cables to the column, guiding them down towards the base. This helps maintain a clean and organized appearance.



SOLIDLY CONSTRUCTED & STURDY TV STAND

Image 7.1: This image highlights key features including the integrated cable management system, the durable tempered glass base, and the non-slip feet designed for enhanced stability.

8. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the stand. For the tempered glass base, a mild glass cleaner can be used. Avoid abrasive cleaners or solvents that may damage the finish.
- **Inspection:** Periodically check all bolts and screws to ensure they remain tight and secure. Re-tighten if necessary.
- **Stability Check:** Regularly verify the stand's stability, especially after moving it or adjusting the TV.

9. TROUBLESHOOTING

9.1. TV is not stable or wobbles

- Ensure all assembly bolts and screws are securely tightened.
- Verify the stand is placed on a flat, level, and stable surface.
- Check that the TV's weight and VESA pattern are within the stand's specifications.

9.2. Difficulty adjusting height, swivel, or tilt

- For height adjustment, ensure the securing knob is sufficiently loosened before attempting to slide the TV.
- For tilt adjustment, ensure the tilt knobs/bolts are loosened before adjusting the angle, and re-tighten them afterward.
- Ensure no cables are obstructing the movement of the TV or stand components.

9.3. Missing parts or damaged components

- Review the package contents list. If parts are missing or damaged, do not proceed with assembly.
- Contact Hemudu customer support for assistance and replacement parts.

10. WARRANTY AND SUPPORT

This Hemudu product is backed by a manufacturer's warranty. Please refer to the warranty card included with your purchase or visit the official Hemudu website for detailed warranty terms and conditions. For technical support, replacement parts, or any inquiries regarding your TV floor stand, please contact Hemudu customer service through the retailer where the product was purchased or via the contact information provided on the official Hemudu website.