

[Manuals.plus](#) /

› [Iseebiz](#) /

› Iseebiz Automatic Pet Feeder with Camera and App Control (Model V6)

Iseebiz V6

Iseebiz Automatic Pet Feeder with Camera and App Control

Model: V6

Brand: Iseebiz

INTRODUCTION

Thank you for purchasing the Iseebiz Automatic Pet Feeder. This device is designed to provide scheduled meals for your pet, offering convenience and peace of mind. With remote control via a smartphone application, a built-in camera, and two-way audio, you can monitor and interact with your pet from anywhere. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance and safety.

SAFETY PRECAUTIONS

- Always ensure the feeder is placed on a stable, level surface to prevent tipping.
- Do not immerse the main unit in water. The main unit contains electronic components and should only be wiped with a damp cloth.
- Use only the provided AC adapter. If using batteries, ensure they are correctly installed and replaced when necessary.
- Keep the power cord away from pets to prevent chewing, which could lead to electric shock. An anti-chew tube is included for added protection.
- This feeder is designed for dry pet food only. Do not use wet food, canned food, or treats.
- Regularly inspect the feeder for any damage or blockages.
- Keep out of reach of children.

PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- Iseebiz Automatic Pet Feeder (Main Unit)
- Food Tray
- AC Power Adapter
- USB Power Cable (3 meters)
- Anti-Chew Tube for Power Cable
- User Manual (this document)

セット内容



ACアダプタ



取扱説明書



電源線
3M



噛み防止
チューブ



Figure 1: Package Contents. The image displays the main feeder unit, an AC adapter, a 3-meter USB power cable, a blue anti-chew tube, and the user manual.

PRODUCT OVERVIEW

Familiarize yourself with the main components of your Iseebiz Automatic Pet Feeder.



Figure 2: Front view of the Iseebiz Automatic Pet Feeder. This image shows the overall design of the feeder, including the food bowl at the bottom, the main body with a camera lens, and control buttons.

- **Lid:** Transparent lid for easy food level monitoring.
- **Food Tank:** 5-liter capacity for dry pet food.
- **Main Unit:** Houses the motor, electronics, camera, and control panel.
- **Food Tray:** Detachable tray where food is dispensed.
- **Camera:** For remote monitoring and two-way audio communication. Features automatic night vision and a 135° wide-angle view.
- **Control Panel:** Buttons for manual feeding and settings.
- **Infrared Sensor:** Located at the food outlet to prevent overfilling and blockages.

SETUP

1. Power Connection:

Connect the AC adapter to the feeder and plug it into a wall outlet. For backup power during outages, install 3 D-size batteries (not included) in the battery compartment at the bottom of the unit. It is recommended to use both AC power and batteries for reliable operation.

Note: Use the provided anti-chew tube to protect the power cable from pet damage.

2. Fill Food Tank:

Open the lid and pour dry pet food into the food tank. Ensure the food is suitable for automatic feeders (kibble size should be appropriate to prevent jamming).

3. Place Food Tray:

Attach the food tray securely to the main unit's base.

APP INSTALLATION AND CONNECTION

The Iseebiz Automatic Pet Feeder requires the "Iseefeedr" app for full functionality. The app is compatible with iOS 7 and Android 4.4 or later.

1. Download the App:

Search for "Iseefeedr" in your smartphone's app store (iOS App Store or Google Play Store) and download the latest version. The app is free to download.



Figure 3: Iseefeedr App Icon. The icon shows a pet bowl with a bone and a Wi-Fi signal, indicating app control.

2. Connect to Wi-Fi:

Follow the in-app instructions to connect the feeder to your home Wi-Fi network. Ensure your smartphone is connected to a 2.4GHz Wi-Fi network during the setup process.

3. Remote Operation:

Once connected, you can remotely control the feeder, view live camera feed, and communicate with your pet from anywhere using the app.

おススメの理由は？



📶 スマホ遠隔操作で安心

- *スマホがあれば設定は家でも外でもOK。タイマー
- *設定しておけば、ごはんが遅くなる心配無し！



6食まで自動&手動給餌

- 毎日最大6食・約5g単位・20段階
- 専用アプリで自動給餌も手動給餌することもできます。



音声録音&水洗い可能

- *衛生のために、一か月おきに掃除してください。
- *「こはんだよ〜」とペット達が一目散に給餌器まで駆け寄せ



赤外線センサーが搭載

- モーター保護+過剰供給防止
- 給餌を止めて詰まりを避けます。



「エコ」給電経済的

- *コンセント電源と電池両方対応可能
- *停電対策として電池とコンセント両方入れることをお勧めします。

噛み防止用チューブ付属

電線が噛まれて電気事故が起きる心配はありますか。

*電線が噛まれ電気事故になることを防止できます。

*出力定格はDC5V-1Aです。



Figure 4: Remote Monitoring via App. A hand holds a smartphone showing the live camera feed from the feeder, with a pet visible in the background, demonstrating remote interaction.

OPERATING INSTRUCTIONS

Automatic Feeding Schedule

Set up a customized feeding schedule for your pet through the Lseefeeder app.

- You can program up to 6 meals per day.
- Each meal can be set from 1 to 20 portions. One portion is approximately 5 grams.
- The timer function ensures your pet is fed at regular intervals, helping to prevent overeating or hunger.

スマホで遠隔操作&双方向音声

スマホで遠隔操作することができて、外出先でも留守番のペットの様子を見ながら話しかけ、ペットをちゃんと守ります。
(自動暗視 / 135°ワイドアングル対応)

最大8人
ログインOK!
家族みんなで
シェアできる



Figure 5: Setting Feeding Schedule. The image shows the feeder next to a smartphone displaying the app interface for setting up daily meal times and portion sizes.

Manual Feeding

You can dispense food manually at any time using the app. This allows you to provide extra food or skip the next scheduled meal as needed.

Voice Recording

Record a 10-second voice message that will play automatically at each feeding time. This can help call your pet to their meal and provide comfort.

6食まで自動給餌&手動給餌可

毎日6食までタイマー式設定できて出張対策や残業の時、ペットの肥満や空腹を防止できます。アプリで手動給餌も可能です。



Figure 6: Voice Recording Feature. The feeder is shown with a speech bubble indicating a voice message, and a cat approaching, illustrating the voice prompt feature.

Camera Features

- **Live View:** Monitor your pet in real-time through the built-in camera.
- **Two-Way Audio:** Speak to your pet and hear their responses.
- **Night Vision:** Automatic night vision ensures clear monitoring even in low-light conditions.
- **Wide-Angle Lens:** The 135° wide-angle lens provides a broad view of the feeding area.

Infrared Sensor and Self-Protection

The feeder is equipped with an infrared sensor at the food outlet. This sensor automatically adjusts the feeding amount to prevent food from overflowing the tray. If an abnormal accumulation of food is detected in the tray, the sensor will stop dispensing to prevent blockages and ensure smooth operation.

MAINTENANCE

Regular cleaning is essential for your pet's health and the feeder's longevity. Clean the feeder at least once a month.



Figure 7: Detachable Parts for Cleaning. The image illustrates how the lid, food tank, and food tray can be easily removed for washing, while the main unit should be wiped.

- **Washable Parts:** The lid, food tank, and food tray are detachable and can be washed with water and mild detergent. Ensure they are completely dry before reassembling.
- **Main Unit:** The main unit contains electronic components and should not be washed with water. If it gets dirty, wipe it clean with a damp cloth.
- **Food Outlet:** Periodically check and clean the food outlet to prevent food residue buildup.

TROUBLESHOOTING

If you encounter issues with your feeder, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Feeder not dispensing food.	No power; food tank empty; food jammed; infrared sensor blocked.	Check power connection/batteries; refill food tank; clear any food blockages; clean the infrared sensor.
Cannot connect to Wi-Fi or app.	Incorrect Wi-Fi password; feeder too far from router; 5GHz Wi-Fi network used; app not updated.	Verify Wi-Fi password; move feeder closer to router; ensure you are connecting to a 2.4GHz network; update the "Iseefeed" app.
Camera feed is unclear or unavailable.	Poor Wi-Fi signal; camera lens dirty; app issue.	Improve Wi-Fi signal strength; clean the camera lens; restart the app or feeder.
Voice recording quality is poor.	Microphone interference; recording environment noise.	Record in a quiet environment; ensure no obstructions near the microphone.

If the problem persists after trying these solutions, please contact customer support.

SPECIFICATIONS

Feature	Detail
Model	V6
Capacity	5 Liters
Material	ABS Plastic
Dimensions (L x W x H)	41.5 cm x 24.5 cm x 23.5 cm
Weight	2.64 kg
Feeding Schedule	Up to 6 meals/day
Portion Size	1-20 portions (approx. 5g per portion)
Voice Recording	Max 10 seconds
Camera Features	135° wide-angle, automatic night vision, two-way audio
Power Supply	AC Adapter (DC5V-1A) / 3 x D-size Batteries (backup)
App Compatibility	iOS 7+, Android 4.4+
Target Species	Cats, Dogs (suitable for large breeds)

WARRANTY AND SUPPORT

For any product defects, questions, or assistance, please contact Iseebiz customer support via email. Refer to the contact information provided with your purchase or on the official Iseebiz website.

Please retain your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07QJCRLMR>

More documents and user manuals: <https://manuals.plus/>