

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Teka](#) /

› [Teka TR 6415 60cm Vitroceramic Hob User Manual](#)

Teka 40239043

Teka TR 6415 60cm Vitroceramic Hob User Manual

Model: TR 6415 (40239043) | Brand: Teka

INTRODUCTION

This manual provides essential information for the safe and efficient use of your new Teka TR 6415 60cm Vitroceramic Hob. Please read these instructions carefully before installation and operation, and keep them for future reference.

IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This appliance is intended for household use only.
- Ensure proper ventilation around the appliance.
- Do not store flammable materials on or near the hob.
- The hob surface remains hot after use; avoid touching until cooled.
- Overheated fats and oils can ignite very quickly.

- Do not use steam cleaners.

INSTALLATION AND SETUP

The Teka TR 6415 vitroceramic hob is designed for built-in installation. Ensure that the installation is carried out by a qualified technician in accordance with local regulations and standards.

Required Cut-out Dimensions

For proper installation, the countertop requires a specific cut-out.




Figure 1: Installation dimensions. The hob measures 600mm (width) x 510mm (depth) x 63mm (height). The required built-in cut-out dimensions are 560mm (width) x 490mm (depth).

Electrical Connection

The appliance operates on 230 Volts and has a maximum wattage of 6300 watts. The electrical connection must be performed by a qualified electrician, ensuring compliance with all relevant electrical safety standards.

OPERATING INSTRUCTIONS

Your Teka TR 6415 vitroceramic hob features a touch control panel for easy and precise operation.

Control Panel Overview




Figure 2: The hob's cooking zones and touch control panel. The panel includes controls for power levels, timer, and security blocking.

Turning On/Off

To turn on the hob, touch the main power symbol on the control panel. To turn off, touch and hold the main power symbol until the display turns off.

Adjusting Heat Levels

Each cooking zone has independent controls. Select the desired cooking zone by touching its corresponding control. Then, adjust the heat level using the '+' and '-' symbols. There are 9 electric power levels available.

Using the Cooking Time Programmer

The hob features an independent programmer for each cooking zone. To set a cooking time, select the zone, then activate the timer function and adjust the duration using the '+' and '-' controls. The zone will automatically switch off once the set time has elapsed.

Security Blocking (Child Lock)

To activate the security blocking feature, touch and hold the lock symbol on the control panel. This prevents accidental operation, especially by children. To deactivate, touch and hold the lock symbol again until it unlocks.

Residual Heat Indicator

After a cooking zone has been used, the residual heat indicator (usually an 'H' symbol) will illuminate on the display. This indicates that the surface is still hot and caution should be exercised. The indicator will turn off once the zone has cooled.

down to a safe temperature.

CARE AND MAINTENANCE

Regular cleaning and proper maintenance will ensure the longevity and optimal performance of your vitroceramic hob.

Cleaning the Hob Surface

- Always ensure the hob is cool before cleaning.
- Use a soft cloth or sponge with a non-abrasive cleaner specifically designed for ceramic or glass hobs.
- For stubborn stains, use a hob scraper designed for ceramic surfaces, holding it at a shallow angle.
- Wipe off any spills immediately, especially sugary liquids, to prevent them from burning onto the surface.
- Avoid using abrasive pads, harsh chemicals, or steam cleaners, as these can damage the glass ceramic surface.

General Care Tips

- Do not drag pots and pans across the hob surface to prevent scratches.
- Avoid dropping heavy or sharp objects on the hob, as this can cause cracks.
- Ensure the bottom of cookware is clean and dry before placing it on the hob.

TROUBLESHOOTING

This section provides solutions to common issues you might encounter with your hob. If the problem persists, contact a qualified service technician.

Problem	Possible Cause	Solution
Hob does not turn on	No power supply; Security blocking activated.	Check power connection; Deactivate security blocking.
Cooking zone not heating	Incorrect power level selected; Overheat protection activated.	Increase power level; Allow zone to cool down.
Display shows 'H'	Residual heat indicator.	This is normal. The zone is still hot.
Hob makes unusual noises	Normal operation sounds (e.g., fan); Loose cookware.	Ensure cookware is stable; If persistent or loud, contact service.

TECHNICAL SPECIFICATIONS

Feature	Specification
Brand	Teka
Model	TR 6415 (40239043)
Type	Vitroceramic Hob
Number of Cooking Zones	4

Feature	Specification
Zone 1 (High Light)	Ø 210 mm
Zone 2 (High Light)	Ø 180 mm
Zone 3 & 4 (High Light)	Ø 145 mm (x2)
Power Levels	9 electric power levels
Control Type	Touch Control Panel
Special Features	Cooking Time Programmer, Independent Zone Programmer, Security Blocking, Residual Heat Indicator
Frame Type	Bevelled Glass Frame
Product Dimensions (HxWxD)	6.3 x 60 x 51 cm (63x600x510mm)
Built-in Dimensions (WxD)	560 x 490 mm
Voltage	230 Volts
Wattage	6300 watts
Fuel Type	Electric
Material Type	Glass Ceramic
Item Weight	8.5 Kilograms

WARRANTY AND SUPPORT

Your Teka TR 6415 Vitroceramic Hob comes with a **1-year manufacturer warranty**. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical support, or service inquiries, please contact Teka customer service or your authorized dealer. Keep your purchase receipt as proof of purchase.

For further assistance, please refer to the official Teka website or contact their customer support channels.