

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [IKEA](#) /
- › [IKEA Hemnes Nightstand Instruction Manual](#)

**IKEA 003.742.97**

# IKEA Hemnes Nightstand Instruction Manual

Brand: IKEA | Model: 003.742.97

## PRODUCT OVERVIEW

The IKEA Hemnes Nightstand in White is a versatile piece of furniture designed for various uses, primarily as a bedside table. It features a smooth-running drawer and an open shelf for convenient storage. Its compact design makes it suitable for spaces where a full-sized nightstand might be too large.



Image: Front view of the IKEA Hemnes Nightstand in white, featuring a single drawer with a dark knob and an open lower shelf.

## SAFETY INFORMATION

---

### Important Safety Precautions:

- Always use two people when assembling this product to avoid injury.
- Be cautious when handling heavy and large components to prevent strain or damage.
- Always follow the assembly instructions carefully to ensure the stability and safety of the product.

## FEATURES

---

- Smooth running drawer with pull-out stop.
- Coordinates with other furniture in the Hemnes Series.
- Compact and sturdy design suitable for various spaces.
- Open lower shelf for additional storage or display.



Image: Close-up view of the nightstand's drawer, showing its interior and the smooth-running mechanism.

## SETUP AND ASSEMBLY

---

The IKEA Hemnes Nightstand is designed for easy home assembly. Please ensure all parts are present before beginning. A screwdriver is recommended for assembly.

1. Unpack all components and verify against the parts list provided in the packaging.
2. Attach the legs to the top panel using the provided hardware.
3. Secure the lower shelf to the legs.
4. Assemble the drawer components and install the drawer into its runners.
5. Attach the drawer knob.
6. Place the nightstand in its desired location.



Image: The nightstand positioned next to a bed, showcasing its use as a bedside table with a lamp and books.

## OPERATING INSTRUCTIONS

The Hemnes Nightstand is straightforward to use:

- **Drawer Use:** Pull the knob to open the drawer. The pull-out stop prevents the drawer from being accidentally pulled out completely. Push to close.
- **Shelf Use:** The open lower shelf can be used to store books, magazines, or decorative items.
- **Top Surface:** The top surface provides space for a lamp, alarm clock, or other personal items.

## MAINTENANCE

---

To keep your Hemnes Nightstand in optimal condition:

- Wipe clean using a damp cloth and a mild cleaner.
- Wipe dry with a clean cloth immediately after cleaning to prevent moisture damage.
- Avoid using abrasive cleaners or harsh chemicals, as these can damage the finish.

## TROUBLESHOOTING

---

Common issues and their solutions:

- **Wobbly Nightstand:** Ensure all screws and fasteners are tightened securely. Check that the nightstand is placed on a level surface.
- **Drawer Sticking:** Check the drawer runners for any obstructions or debris. Ensure the drawer is correctly aligned on its tracks.
- **Surface Scratches:** Minor scratches can sometimes be touched up with furniture repair pens or appropriate paint. For deeper damage, consult a furniture repair specialist.

## SPECIFICATIONS

---

Attribute	Detail
Brand	IKEA
Model Name	003.742.97
Color	White
Product Dimensions	14.25"D x 30.94"W x 2.44"H
Material Type	Fiberboard, Acrylic paint, Solid pine, Particleboard, Laminate (melamine), Solid beech
Number of Drawers	1
Tools Recommended For Assembly	Screw Driver

## WARRANTY AND SUPPORT

For warranty information or product support, please refer to the official IKEA website or contact IKEA customer service directly. Keep your proof of purchase for any warranty claims.