

Saved from manuals.plus.

Open the live page for links to other documents and user manuals.

[Manuals.plus](#) /

› [Prominence Home](#) /

› Prominence Home Benton 52-Inch LED Flush Mount Ceiling Fan Instruction Manual

Prominence Home 50853-01

Prominence Home Benton 52-Inch LED Flush Mount Ceiling Fan Instruction Manual

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Prominence Home Benton 52-inch LED Flush Mount Ceiling Fan. Please read all instructions carefully before beginning installation to ensure safe and proper operation. Keep this manual for future reference.



The Prominence Home Benton 52-inch ceiling fan with light installed in a living room setting, showcasing its matte black finish and integrated light.

SAFETY INFORMATION

Your Prominence Home Benton ceiling fan is designed and manufactured to meet high safety standards. Adherence to these guidelines is crucial for safe installation and operation.

- Always disconnect power at the circuit breaker before installation or servicing.
- Ensure all electrical connections comply with local codes and ordinances.
- Mount the fan only to an outlet box marked "Acceptable for Fan Support of 35 lbs (15.9 kg) or less."
- Do not operate the fan with damaged blades or housing.
- Keep hands, clothing, and other objects clear of the fan blades during operation.

Code Compliant

Our products are designed with **YOU** in mind.



Our products have been safety tested to ensure the ceiling fan you are installing in your home or business will not present a safety hazard.



This product is safety tested and designed to comply with ETL, DOE, CA CEPA, CARB, and CEC regulations, ensuring it meets stringent safety and energy efficiency standards.

SETUP AND INSTALLATION

The Prominence Home Benton ceiling fan is designed for flush mount installation, ideal for rooms with lower ceilings. Proper installation ensures optimal performance and safety.

Room Size Recommendation

Select the appropriate fan size based on your room dimensions for effective air circulation.



PROMINENCE HOME



FIND THE FAN THAT IS BEST FIT FOR YOUR SPACE

Use the guide below for best location of your ceiling fan



SMALL ROOM

Less than 8 ft. x 10 ft.
Fan size up to 32 in.



MEDIUM ROOM

Up to 12 ft. x 14 ft.
Fan Size up to 32 in. - 48 in.



LARGE ROOM

Up to 12 ft. x 18 ft.
Fan Size up to 48 in. - 58 in.


This guide illustrates recommended fan sizes for different room dimensions: Small Room (less than 8 ft. x 10 ft., fan size up to 32 in.), Medium Room (up to 12 ft. x 14 ft., fan size up to 48 in.), and Large Room (up to 12 ft. x 18 ft., fan size up to 58 in.). The Benton 52-inch fan is suitable for large rooms.

Product Dimensions

Understand the physical dimensions of your ceiling fan for proper placement and clearance.

Product Dimensions

Find the fan that is the best fit for your space



The diagram shows the fan has a 52-inch blade span and measures 12.3 inches from the ceiling to the bottom of the light kit, indicating a low-profile flush mount design.

Reversible Blades

The fan features five reversible blades, offering two distinct finish options to match your decor.



PROMINENCE HOME

BENTON

52" INDOOR LED CEILING FAN

Bring contemporary style and year-round comfort to your home



Matte Black



Gray Cedar



REVERSIBLE BLADES

Choose between two different blade finishes to pick the style that best complements your home

The Benton 52-inch indoor LED ceiling fan offers reversible blades with Matte Black on one side and Gray Cedar on the other, allowing you to choose the style that best complements your home.

For detailed step-by-step installation instructions, please refer to the separate installation guide included in your product packaging. Ensure all components are securely fastened before operating the fan.

OPERATING INSTRUCTIONS

Your Prominence Home Benton ceiling fan is equipped with pull chains for easy control of fan speed and lighting, along with a reversible motor for year-round comfort.

Fan Speed and Light Control

The fan and light are controlled independently using two pull chains. One pull chain controls the fan's three speeds, and the other controls the integrated LED light kit.

52
INCH

BENTON

INDOOR CEILING FAN Matte Black Motor Finish



HUGGER

LOW PROFILE MOUNTING



PULL CHAIN

ADJUST LIGHT | FAN SPEED



5 BLADE FAN

REVERSIBLE | DUAL FINISH



3000K

COLOR TEMPERATURE

The Benton 52-inch indoor ceiling fan features pull chains for adjusting both the light and the fan speed, along with 5 reversible blades and a 3000K LED light.

Reversible Motor Function

The fan features a 3-speed reversible motor, allowing you to change the direction of airflow for optimal comfort in different seasons.


- **Summer Mode:** Downward airflow creates a cooling effect.
- **Winter Mode:** Upward airflow circulates warm air trapped near the ceiling, helping to reduce heating costs.



PROMINENCE HOME

REVERSIBLE MOTOR

Warm in winter, cool in summer



This diagram shows the reversible motor function: in winter, blades push air upwards to balance indoor heating, and in summer, they push air downwards for strong, rapid cooling.

Integrated LED Light Kit

The fan includes an integrated LED light kit with a frosted glass cover, providing efficient and comfortable illumination.

- **Light Output:** 800 lumens
- **Color Temperature:** 3000K (warm light)
- **Bulbs:** 1 E26 / A15 bulb included.



PROMINENCE HOME



FROSTED INTEGRATED GLOBE LIGHT KIT

1 E26 / A15 bulbs included



3000K
Color Temperature

The frosted integrated globe light kit includes one E26/A15 bulb, providing 3000K color temperature light.

MAINTENANCE

Regular maintenance helps ensure the longevity and optimal performance of your ceiling fan.

- **Cleaning:** Periodically clean the fan blades and motor housing with a soft, damp cloth. Avoid using abrasive cleaners that could damage the finish.
- **Tightening Screws:** Check all screws on the fan blades and mounting hardware annually to ensure they are secure.
- **Light Bulb Replacement:** If the LED bulb needs replacement, ensure the power is off before changing. Use a compatible E26/A15 LED bulb.

TROUBLESHOOTING

If you encounter issues with your ceiling fan, refer to the following common troubleshooting tips. For problems not listed here, please contact customer support.

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; loose wire connections; motor switch off.	Check circuit breaker and wall switch. Ensure all wire connections are secure. Verify the motor's direction switch is fully engaged.
Fan is noisy	Loose motor housing screws; loose blade attachment screws; unbalanced blades.	Tighten all screws on the motor housing. Ensure blade screws are tight. Check for bent blades or use a balancing kit if necessary.
Light does not work	Loose wire connection in light kit; faulty bulb; no power to light kit.	Check light kit wiring. Replace the bulb with a new, compatible E26/A15 LED bulb. Ensure the light pull chain is activated.

SPECIFICATIONS

Detailed technical specifications for the Prominence Home Benton 52-inch LED Flush Mount Ceiling Fan.

- **Model Name:** Benton
- **Model Number:** 50853-01
- **Brand:** Prominence Home
- **Color:** Matte Black
- **Electric Fan Design:** Ceiling Fan
- **Power Source:** Corded Electric
- **Style:** Traditional
- **Product Dimensions:** 52"D x 52"W x 12.32"H
- **Room Type:** Bedroom, Dining Room, Living Room
- **Mounting Type:** Ceiling Mount (Flush Mount)
- **Controller Type:** Pull Chain Control
- **Number of Speeds:** 3
- **Noise Level:** 45 Decibels
- **Wattage:** 55.7 watts
- **Number of Blades:** 5
- **Air Flow Capacity:** 3723.62 Cubic Feet Per Minute
- **Speed:** 159 RPM
- **Voltage:** 120 Volts (AC)
- **Indoor Outdoor Usage:** Indoor Only
- **Material:** Alloy Steel
- **Light Type:** Integrated LED (3000K, 800 Lumens)
- **Included Components:** Blades, Bulbs, Motor, Pull-Chains
- **Item Weight:** 15.34 Pounds
- **UPC:** 671961508531

WARRANTY AND SUPPORT

Your Prominence Home Benton ceiling fan comes with a limited lifetime warranty. For specific details regarding warranty coverage, please refer to the warranty card included with your product or visit the official Prominence Home website.

For technical assistance, replacement parts, or any questions not covered in this manual, please contact Prominence Home customer support. Contact information can typically be found on the product packaging or the brand's official website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07QKP8FPF>

More documents and user manuals: <https://manuals.plus/>