

[Manuals.plus](#) /

› [IKEA](#) /

› IKEA Poäng Armchair User Manual

IKEA 191.977.61

IKEA Poäng Armchair User Manual

Model: 191.977.61

PRODUCT OVERVIEW

The IKEA Poäng Armchair is designed for comfort and durability, featuring a unique bentwood frame that provides comfortable resilience. Its high back offers excellent neck support, making it an ideal choice for relaxation in any living space.



Image: Front view of the IKEA Poäng Armchair, showcasing its medium brown bentwood frame and Hillared beige fabric cushions.

This armchair is constructed with a molded layer-glued wood veneer frame, stained and finished with clear acrylic lacquer. The chair cushion is composed of a blend of cotton, polyester, viscose/rayon, and linen, with polyurethane foam and polyester wadding for optimal comfort. The headrest also features polyurethane foam and non-woven polyester fabric.

SETUP AND ASSEMBLY

The IKEA Poäng Armchair requires assembly. Please refer to the detailed assembly instructions included with your product packaging for step-by-step guidance. Ensure all components are present before

beginning assembly. Tools required for assembly are typically minimal and often included or commonly available household items.



Image: Technical drawing illustrating the dimensions of the Poäng Armchair, including depth (32.25"), width (26"), and height (39.37").

For optimal stability and safety, ensure all screws and fittings are tightened securely. Periodically check and re-tighten as necessary.

OPERATING INSTRUCTIONS

The Poäng Armchair is designed for comfortable seating and relaxation. Its unique frame provides a gentle, natural bounce, adapting to your body's movements for enhanced comfort. The high back and integrated headrest offer excellent support for your neck and head.

- **Seating:** Sit comfortably in the chair, allowing the layer-glued bent beech frame to provide its characteristic resilience.

- **Neck Support:** Utilize the high back and headrest for optimal neck and head support, especially during extended periods of sitting.
- **Pairing with Ottoman:** For even greater comfort and relaxation, the armchair can be used in conjunction with a compatible Poäng ottoman (sold separately).



Image: The Poäng Armchair paired with a matching ottoman, demonstrating a complete relaxation setup in a room.




Image: A detailed view of the Poäng Armchair's headrest, highlighting the texture and padding of the Hillared beige fabric.

MAINTENANCE AND CARE

Proper care will extend the life and appearance of your Poäng Armchair.

- **Frame Care:** Wipe the wooden frame clean with a damp cloth. Dry thoroughly.
- **Cushion Care:** The fabric cushions can be cleaned according to the care label instructions. For general maintenance, vacuum regularly. If the cushion covers are removable (indicated by a zipper), they may be machine washable or dry cleanable depending on the fabric composition.
- **Spills:** Immediately blot any spills with a clean, dry cloth. Avoid rubbing, which can spread the stain.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading of the fabric and wood finish.



Image: A close-up shot of a zipper on the Poäng Armchair cushion, indicating that the cover may be removable for cleaning.

TROUBLESHOOTING

Most issues with the Poäng Armchair can be resolved with simple checks.

- **Squeaking Noises:** If the chair makes squeaking noises, check all assembly screws and re-tighten them. Ensure the frame is on a level surface.
- **Loose Cushions:** If cushions feel loose, ensure they are properly seated within the frame.
- **Stability Issues:** Verify that the chair is placed on a flat, stable surface. Check all connections for tightness.

If problems persist, please contact IKEA customer support.

SPECIFICATIONS

Brand	IKEA
Model Name	191.977.61

Color	Medium Brown (frame), Hillared Beige (cushion)
Product Dimensions	32.25"D x 26"W x 39.37"H
Item Weight	23 pounds
Frame Material	Molded layer-glued wood veneer (Beech)
Cushion Composition	55% Cotton, 25% Polyester, 12% Viscose/Rayon, 8% Linen (cover); Polyurethane foam, Polyester wadding (filling)
Back Style	Curved Bentwood High Back
Special Features	Arm Rest, Cushion Availability
Product Care Instructions	Wipe Clean (frame)
Indoor/Outdoor Usage	Indoor
UPC	304369290202

WARRANTY AND SUPPORT

The IKEA Poäng Armchair comes with a **10-Year limited warranty**. Please retain your proof of purchase for warranty claims.

For further assistance, spare parts, or detailed product information, please visit the official IKEA website or contact IKEA customer service directly. You can find contact details on your purchase receipt or on the IKEA official website.