

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Bauknecht](#) /
- › [Bauknecht DBAH 65 LM X Cooker Hood Instruction Manual](#)

Bauknecht DBAH 65 LM X

Bauknecht DBAH 65 LM X Cooker Hood Instruction Manual

Model: DBAH 65 LM X

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your Bauknecht DBAH 65 LM X cooker hood. Please read these instructions carefully before using the appliance and retain them for future reference.



Figure 1: Front view of the Bauknecht DBAH 65 LM X cooker hood, showcasing its sleek design and control panel.

2. SAFETY INFORMATION

Always adhere to the following safety guidelines to prevent injury or damage to the appliance:

- Ensure the appliance is correctly installed by a qualified professional.
- Do not allow children to operate the appliance unsupervised.

- Regularly clean the grease filters to maintain optimal performance and prevent fire hazards.
- Do not flambé under the cooker hood.
- Ensure adequate ventilation in the room when the cooker hood is used simultaneously with appliances burning gas or other fuels.
- Disconnect the appliance from the power supply before any cleaning or maintenance.

3. SETUP AND INSTALLATION

The Bauknecht DBAH 65 LM X cooker hood is designed for installation in a flat screen top cabinet. It is suitable for both exhaust and circulation operation, offering flexibility for various kitchen setups.

3.1 Dimensions and Mounting

Refer to the diagram below for precise dimensions required for installation. The unit measures approximately 28.2 cm (depth) x 59.8 cm (width) x 39.6 cm (height).




Figure 2: Detailed technical drawing showing the dimensions of the cooker hood for accurate installation planning.

3.2 Electrical Connection

The appliance operates on 220 Volts. Ensure the electrical installation complies with local regulations and is performed by a qualified electrician.

3.3 Ventilation System

This cooker hood supports both exhaust (ducting air outside) and circulation (filtering and recirculating air) modes. The choice of mode depends on your kitchen's ventilation capabilities. For exhaust operation, a duct with a diameter of 150mm is typically used.



Figure 3: The Bauknecht DBAH 65 LM X cooker hood seamlessly integrated into a kitchen cabinet, demonstrating its flat screen design.

4. OPERATING INSTRUCTIONS

The cooker hood features intuitive controls for ease of use.

4.1 Control Panel

The appliance is operated via a short-lift button control panel, typically located on the front edge of the hood. This panel allows you to manage the fan speed and lighting.




Figure 4: A closer look at the control buttons and the integrated LED lighting of the cooker hood.

4.2 Fan Speed Settings

The cooker hood offers three distinct power levels to effectively remove cooking fumes and odors. Select the appropriate speed based on the intensity of cooking.

1. **Level 1:** For light cooking, simmering, or minimal odors.
2. **Level 2:** For standard cooking, such as frying or boiling.
3. **Level 3:** For heavy cooking, grilling, or strong odors.

4.3 LED Lighting

The integrated LED lighting (2 x 3 Watt) provides illumination for your cooking area. Activate or deactivate the lights using the dedicated button on the control panel.

5. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your cooker hood.

5.1 Cleaning Grease Filters

The cooker hood is equipped with baffle filters designed to trap grease. These filters should be cleaned regularly, typically every 2-4 weeks depending on usage, to prevent grease buildup and maintain airflow efficiency. Refer to the product's full manual for specific cleaning instructions, which usually involve washing them by hand or in a

dishwasher.

5.2 Replacing Carbon Filters (Circulation Mode Only)

If your cooker hood is operating in circulation mode, it will require activated carbon filters (not included) to remove odors. These filters cannot be washed and must be replaced periodically, typically every 3-6 months, depending on usage.

5.3 Cleaning the Exterior

Clean the exterior surfaces of the cooker hood with a soft cloth and a mild, non-abrasive cleaning agent. Avoid using harsh chemicals or abrasive materials that could damage the finish.

6. TROUBLESHOOTING

Should you encounter any issues with your cooker hood, consult the following basic troubleshooting guide:

- **No power:** Check the power supply, circuit breaker, and ensure the appliance is properly plugged in.
- **Poor suction:** Clean or replace grease filters. If in circulation mode, check and replace carbon filters. Ensure no obstructions in the ducting (for exhaust mode).
- **Excessive noise:** Check for loose components or obstructions in the fan. Ensure the filters are correctly installed.
- **Lights not working:** Check if the LED bulbs need replacement. Ensure the light switch is activated.

For more complex issues or if the problem persists, contact Bauknecht customer support or a qualified service technician.

7. SPECIFICATIONS

Key technical specifications for the Bauknecht DBAH 65 LM X cooker hood:

Feature	Specification
Model	DBAH 65 LM X
Brand	Bauknecht
Product Dimensions (HxWxD)	39.6 x 59.8 x 28.2 cm
Item Weight	1 kg
Voltage	220 Volts
Wattage	85.8 kWh (Annual Energy Consumption)
Number of Speeds	3
Light Source Type	LED (2 x 3 Watt)
Filter Type	Baffle
Ventilation Type	Both (Exhaust and Circulation)
Noise Level	Min. 48 - Max. 62 dB/A
Energy Efficiency Class	D

7.1 Energy Efficiency Label

The energy efficiency label provides information on the appliance's energy consumption and performance.



Figure 5: The official energy label indicating the energy efficiency class (D) and annual energy consumption (85.8 kWh/annum).

8. WARRANTY AND SUPPORT






For warranty information, product registration, or technical support, please refer to the official Bauknecht website or contact their customer service department. Keep your purchase receipt as proof of purchase.

Bauknecht Customer Service: www.bauknecht.eu/service

© 2025 Bauknecht. All rights reserved.

Related Documents - DBAH 65 LM X

<div><div>EN: Instruction for use FR: Mode d'emploi DE: Betriebsanleitung IT: Istruzioni per l'uso NL: Gebruiksaanwijzingen</div><div></div></div>	<div><div>Bauknecht Range Hood Installation and User Manual</div><div>Comprehensive guide for installing, operating, and maintaining your Bauknecht range hood (model BHVS 61F LT DP K). Includes safety instructions, technical specifications, and troubleshooting.</div></div>
<div><div>EN: Instruction for use FR: Mode d'emploi DE: Betriebsanleitung IT: Istruzioni per l'uso NL: Gebruiksaanwijzingen</div><div></div></div>	<div><div>Bauknecht BHVS 91F LT DP K Kitchen Hood Installation and User Manual</div><div>This document provides comprehensive installation, safety, maintenance, and operating instructions for the Bauknecht BHVS 91F LT DP K kitchen hood. Includes diagrams and troubleshooting tips.</div></div>
<div><div>DE: Betriebsanleitung EN: Instructions for use FR: Mode d'emploi IT: Istruzioni per l'uso ES: Instrucciones de uso RU: Инструкция по эксплуатации</div><div></div></div>	<div><div>Bauknecht Range Hood: Installation, Operation, and Maintenance Manual</div><div>Comprehensive user and installation manual for Bauknecht range hoods, covering safety, operation, maintenance, troubleshooting, and technical specifications. Available in multiple languages.</div></div>

<div data-bbox="124 159 236 224"><p>DE Betriebsanleitung EN Instructions for use FR Mode d'emploi NL Gebruiksaanwijzingen IT Istruzioni per l'uso ES Instrucciones de uso RU Инструкция по эксплуатации CS Návod k použití</p></div> <div data-bbox="124 293 210 315"></div>	<div data-bbox="341 176 948 206">Bauknecht Range Hood Installation and User Manual</div> <div data-bbox="341 217 1377 286"><p>This comprehensive guide provides essential information for the installation, operation, and maintenance of your Bauknecht range hood, ensuring safe and efficient use.</p></div>
<div data-bbox="124 436 304 698"><div data-bbox="124 436 304 459"><p>Quick guide</p><p>EN</p></div><div data-bbox="124 468 304 560"><p>PRODUCT DESCRIPTION</p></div><div data-bbox="124 577 304 698"><p>CONTROL PANEL DESCRIPTION</p></div><div data-bbox="193 685 236 698"></div></div>	<div data-bbox="341 409 857 439">Bauknecht Oven User Manual & Quick Guide</div> <div data-bbox="341 450 1469 719"><p>Discover how to make the most of your Bauknecht oven with this comprehensive user manual and quick guide. It details product features, control panel functions, and essential operating procedures. Explore a wide range of cooking functions, including manual settings, specialized programs like My Menu, and advanced techniques such as steam cooking. The guide also provides practical advice on using accessories, detailed cooking tables for various dishes, and step-by-step instructions for cleaning and maintenance. For optimal performance and support, users are encouraged to register their appliance.</p></div>
<div data-bbox="124 779 304 1041"></div>	<div data-bbox="341 857 844 887">Bauknecht BKSI 18VS2 دليل المستخدم لجهاز</div> <div data-bbox="341 898 1469 967"><p>يقدم إرشادات مفصلة حول الاستخدام الآمن، الصيانة، التنظيف، Bauknecht BKSI 18VS2 دليل شامل لجهاز واستكشاف الأخطاء وإصلاحها لضمان الأداء الأمثل.</p></div>