

ADLER AD4125

ADLER AD4125 Juicer User Manual

Model: AD4125 | Brand: ADLER

1. INTRODUCTION

Thank you for choosing the ADLER AD4125 Juicer. This functional 1000W juicer is designed to efficiently extract fresh juice from fruits and vegetables, supporting a healthy diet. Its robust design, including a stainless steel strainer, ensures high-quality juice free from solid particles. Please read this manual carefully before first use to ensure safe and optimal operation of your appliance.

2. IMPORTANT SAFETY INSTRUCTIONS

- Always ensure the appliance is properly assembled and the safety lock is engaged before operation. The juicer will not turn on if not correctly installed.
- Do not immerse the motor unit in water or any other liquid.
- Keep hands and utensils out of the feeding tube during operation to prevent injury. Always use the food pusher provided.
- Unplug the juicer from the power outlet before cleaning, disassembling, or when not in use.
- This appliance is for household use only. Do not use outdoors.
- Do not operate the juicer if the power cord or plug is damaged, or if the appliance malfunctions or has been damaged in any way.
- Keep the appliance out of reach of children.

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your ADLER AD4125 Juicer:

- Motor Unit (Base)
- Pulp Container (2.5 L capacity)
- Juice Collector/Lid
- Stainless Steel Sieve/Strainer
- Feeding Tube (75 mm extra-large)
- Food Pusher
- Safety Locking Bar
- Juice Jug (1.5 L capacity)
- Control Dial (OFF, Speed I, Speed II)



Figure 3.1: Overview of the ADLER AD4125 Juicer and its accessories.



Figure 3.2: Detail of the stainless steel sieve, designed to filter juice effectively.

4. SETUP

1. Place the motor unit on a stable, flat, and dry surface.
2. Insert the pulp container into its designated position on the motor unit.
3. Place the stainless steel sieve firmly into the juice collector. Ensure it is securely seated.
4. Position the juice collector/lid assembly onto the motor unit, aligning it correctly.
5. Lower the safety locking bar until it clicks into place, securing all components. The juicer will not operate if the locking bar is not properly engaged.
6. Place the juice jug under the juice spout.



Figure 4.1: The juicer fully assembled and ready for use.

5. OPERATING INSTRUCTIONS

1. Wash fruits and vegetables thoroughly. For the 75mm extra-large feeding tube, many whole fruits like apples can be juiced without pre-cutting. For larger or harder items, cut them into smaller pieces that fit the feeding tube. Remove pits/seeds from fruits like peaches, cherries, etc.

2. Ensure the juice jug is in place under the spout and the pulp container is correctly positioned.
3. Plug the juicer into a suitable power outlet.
4. Turn the control dial to the desired speed: **Speed I** for softer fruits and vegetables, or **Speed II** for harder produce.
5. Gradually feed the prepared fruits or vegetables into the feeding tube. Use the food pusher to gently guide them down. Do not force the produce, as this can damage the motor.
6. Fresh juice will flow into the juice jug, and pulp will be collected in the pulp container.
7. Once juicing is complete, turn the control dial to the **OFF (0)** position and unplug the appliance.



6. CLEANING AND MAINTENANCE

Regular cleaning ensures the longevity and hygiene of your juicer. Many parts are dishwasher safe for convenience.

1. Always unplug the juicer before cleaning.
2. Disassemble the juicer by releasing the safety locking bar and removing the juice collector/lid, sieve, and pulp container.
3. Rinse all removable parts (pulp container, juice collector/lid, sieve, food pusher, juice jug) under running water immediately after use to prevent pulp from drying and sticking.
4. For thorough cleaning, these parts can be washed in warm, soapy water or placed in the dishwasher. Use the provided cleaning brush for the sieve to remove any stubborn pulp.
5. Wipe the motor unit with a damp cloth. Never immerse the motor unit in water.
6. Ensure all parts are completely dry before reassembling or storing the juicer.



Figure 6.1: Juicer with included juice jug and cleaning brush.

7. TROUBLESHOOTING

- **Juicer does not turn on:** Check if the power cord is securely plugged in. Ensure all components are correctly assembled and the safety locking bar is fully engaged. The appliance has a safety interlock system.
- **Motor stops during operation:** The juicer may have overheated due to continuous use or overloading. Turn off the appliance, unplug it, and let it cool down for at least 15-20 minutes before resuming. Reduce the amount of produce fed at once.
- **Pulp is wet:** This can happen with very soft or overripe fruits. Ensure you are using the correct speed setting for the produce. For optimal juice extraction, use fresh, firm fruits and vegetables.

- **Excessive vibration or noise:** Ensure the juicer is placed on a stable, flat surface. Check that the sieve is correctly seated and not damaged.

8. SPECIFICATIONS

Brand	ADLER
Model Number	AD4125
Color	Black
Power	1000 W
Juice Jug Capacity	1.5 Liters
Pulp Container Capacity	2.5 Liters
Feeding Tube Diameter	75 mm
Material	High-quality Stainless Steel (strainer)
Product Dimensions	38 x 26 x 43 cm
Item Weight	4.22 Kilograms
Voltage	420 Volt (Note: This voltage seems unusually high for a household appliance. Please verify with product labeling.)

9. WARRANTY AND SUPPORT

For warranty information, product support, or service inquiries, please refer to the warranty card included with your purchase or contact the retailer where the product was purchased. You may also visit the official ADLER website for further assistance.


For general inquiries, you can visit the ADLER store on Amazon:[ADLER Store](#)

Related Documents - AD4125




Adler AD 4132 Juicer: User Manual, Safety Instructions, and Operation Guide

Comprehensive user manual for the Adler AD 4132 juicer, covering safety instructions, operating procedures, cleaning, maintenance, and technical specifications in multiple languages.



ADLER AD 4009 Citrus Juicer User Manual

User manual and safety instructions for the ADLER AD 4009 Citrus Juicer. Learn how to safely operate, clean, and maintain your citrus juicer.



Adler AD 4012 Citrus Juicer User Manual

Comprehensive user manual for the Adler AD 4012 citrus juicer, detailing safety instructions, usage, maintenance, and technical specifications in multiple languages.



Adler AD 4123 Juicer User Manual

Comprehensive user manual for the Adler AD 4123 juicer, covering safety instructions, device description, assembly, operation, cleaning, and technical data. Available in multiple languages.



Adler AD 7328 Pedestal Fan User Manual and Instructions

Get detailed user manual and operating instructions for the Adler AD 7328 pedestal fan. Learn about safety conditions, assembly, operation modes, cleaning, and technical specifications.



[Adler AD 2112 Hair Curler User Manual](#)

Comprehensive user manual for the Adler AD 2112 hair curler, providing safety instructions, operating guidelines, and maintenance tips in multiple languages.