

[manuals.plus](#) /

› [CYBORIS](#) /

› [CYBORIS 16GB MP3 Bluetooth Headphones User Manual](#)

## CYBORIS SM-828

# CYBORIS 16GB MP3 Bluetooth Headphones

Model: SM-828

## INTRODUCTION

Thank you for choosing the CYBORIS 16GB MP3 Bluetooth Headphones. These versatile headphones are designed for active lifestyles, featuring IPX7 waterproofing, built-in 16GB memory for MP3 playback, and Bluetooth connectivity. This manual provides detailed instructions to help you get the most out of your device.



Image: The CYBORIS 16GB MP3 Bluetooth Headphones, showcasing their sleek design and water-resistant coating.

## KEY FEATURES

- **IPX7 Professional Waterproof:** Designed to withstand sweat, splashes, and even submersion, making them ideal for swimming and intense workouts.
- **Built-in 16GB Memory:** Store up to thousands of songs directly on the headphones, allowing for music playback without a connected device.
- **Dual Play Mode:** Seamlessly switch between Bluetooth streaming and built-in MP3 player mode.
- **Hi-Fi Audio Quality:** Features API-X audio encoding and CVC6.0 noise reduction for clear, high-resolution sound.
- **Long Battery Life:** Enjoy extended playback time with a large capacity battery and efficient Bluetooth 4.1 connectivity.
- **Lightweight and Comfortable:** Weighing only 20g with a flexible, ergonomic design for secure and comfortable wear during long periods.

# TWO PLAY MODE

32GB build-in memory supports  
up to 10000 songs play.

Switch between Bluetooth and MP3 mode  
just press the middle.

BT Play

B.T  
Wireless



MP3 Play

32G  
RAM



Image: Illustration of the two play modes: Bluetooth Play and MP3 Play, highlighting the 16GB built-in memory.



Image: A diagram showing various features like IPX7 Waterproof, Bluetooth 5.3, Hi-Fi Sound, Built-in Microphone, and Battery Display.

## SETUP

### 1. Charging the Headphones

Before first use, fully charge your headphones. Connect the included USB charging cable to the charging port on the headphones and the other end to a USB power adapter (not included) or a computer USB port. The LED indicator will show charging status and turn off when fully charged.

# Large capacity battery

Accompany you all day

Large capacity battery + low power Bluetooth 5.0  
+ multi-directional low energy design + 2 hours full charge

**15<sub>H</sub>**  
Playback

**250<sub>mAh</sub>**  
Battery

**360<sub>H</sub>**  
Long standby

**2<sub>H</sub>**  
Full charge



\*The playback time will be slightly different due to factors such as volume and usage environment.

Image: An illustration of the large capacity battery, indicating 15 hours playback, 250mAh battery, 360 hours standby, and 2 hours full charge time.

## 2. Bluetooth Pairing

1. Ensure the headphones are powered off.
2. Press and hold the Multi-function button until the LED indicator flashes red and blue alternately, indicating pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
4. Select "CYBORIS SM-828" (or similar name) from the list.
5. Once connected, the LED indicator will flash blue slowly.

## 3. Loading MP3 Files (for built-in memory)

To use the built-in MP3 player, you need to transfer audio files to the headphones' internal memory.

1. Connect the headphones to your computer using the USB charging cable.
2. The headphones will appear as a removable disk drive on your computer.

3. Drag and drop your desired MP3, WMA, WAV, FLAC, or APE audio files into the headphone's storage folder.
4. Safely eject the removable disk from your computer before disconnecting the cable.



Image: A close-up showing the internal memory chip, indicating the built-in 16GB memory for storing music.

## OPERATING INSTRUCTIONS

### Basic Controls

Button/Action	Function
Power Button (Long Press)	Power On/Off
Multi-function Button (Short Press)	Play/Pause, Answer/End Call
Volume + (Short Press)	Increase Volume
Volume - (Short Press)	Decrease Volume
Volume + (Long Press)	Next Track
Volume - (Long Press)	Previous Track
Multi-function Button + Volume - (Simultaneous Press)	Switch between Bluetooth and MP3 mode

### Switching Playback Modes

The headphones support both Bluetooth streaming and standalone MP3 playback. To switch between these modes, simultaneously press the Multi-function button and the Volume - button. The headphones will indicate the current mode via voice prompt or LED indicator.



# DUAL MODE PLAYBACK



Connect to wireless  
device playback



The headset comes with 32GB of RAM,  
and it's enough to bring it when you're exercising.

Image: Visual representation of the dual mode playback feature, showing connectivity to a wireless device and the built-in 16GB RAM for exercise.

## MAINTENANCE

- **Cleaning:** Wipe the headphones with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Exposure:** While IPX7 waterproof, it is recommended to rinse the headphones with fresh water after exposure to chlorinated or saltwater and allow them to dry completely before charging.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge regularly, even if not in use for extended periods.

# IPX7 PROFESSIONAL WATERPROOF

100% protect your headphones against sweat  
ordinary splashing, and rain  
Enjoy music anywhere anytime



Image: A person in a pool, demonstrating the IPX7 professional waterproof feature of the headphones, suitable for swimming.

## TROUBLESHOOTING

- **Headphones won't turn on:** Ensure the battery is charged. Connect to a power source and try again.
- **Cannot pair with Bluetooth device:** Make sure the headphones are in pairing mode (flashing red and blue). Ensure Bluetooth is enabled on your device and it's within range. Try restarting both devices.
- **No sound from MP3 player:** Check if the volume is turned up. Ensure audio files are in a supported format (MP3, WMA, WAV, FLAC, APE) and properly transferred to the internal memory.



- **Sound quality is poor:** Ensure the headphones are fully charged. Check for interference from other wireless devices. For Bluetooth, ensure you are within range of your connected device.
- **Headphones fall out during activity:** Ensure you are using the correct size ear tips for a secure fit. Adjust the ear hooks for optimal stability.

## SPECIFICATIONS

Feature	Detail
Model Number	SM-828
Brand	CYBORIS
Connectivity Technology	Bluetooth 4.1 (4G)
Wireless Communication Technology	Bluetooth
Built-in Memory	16GB
Waterproof Rating	IPX7
Battery Composition	Lithium-ion
Item Weight	20 Grams
Material	Plastic
Headphone Jack	USB (for charging and data transfer)
Form Factor	In-Ear

## WARRANTY AND SUPPORT

CYBORIS products are designed for durability and performance. For warranty information and technical support, please refer to the contact details provided with your purchase or visit the official CYBORIS website. Please retain your proof of purchase for any warranty claims.

