

[Manuals.plus](#) /

› [Paladone](#) /

› Paladone Call of Duty Monkey Bomb Alarm Clock User Manual (Model PP4898COD)

## Paladone PP4898COD

# Paladone Call of Duty Monkey Bomb Alarm Clock

Model: PP4898COD - User Manual

---

## 1. INTRODUCTION

---

Thank you for purchasing the Paladone Call of Duty Monkey Bomb Alarm Clock. This unique alarm clock combines functionality with iconic Call of Duty design. Please read this manual carefully to ensure proper setup and operation of your device.



Image 1.1: The Paladone Call of Duty Monkey Bomb Alarm Clock. This image shows the alarm clock from the front, featuring the monkey figure with cymbals and a digital LED display showing '12:15'. A power cord is visible at the back.

## 2. PACKAGE CONTENTS

---

- 1 x Paladone Call of Duty Monkey Bomb Alarm Clock
- 1 x USB Power Cable (integrated)
- This User Manual




Image 2.1: The Paladone Call of Duty Monkey Bomb Alarm Clock in its retail box. The packaging features Call of Duty branding and displays the alarm clock inside.

### 3. SETUP

1. **Unpacking:** Carefully remove the alarm clock from its packaging. Retain the packaging for future storage or transport.
2. **Power Connection:** Connect the integrated USB power cable to a suitable USB power adapter (not included) and plug it into a wall outlet. The LED display will illuminate.
3. **Battery Installation (Optional for Backup):** This device does not include batteries. For backup power during outages, insert 3 x AAA batteries (not included) into the battery compartment located on the underside of the unit. Ensure correct polarity (+/-).

## 4. OPERATING INSTRUCTIONS

### 4.1 Setting the Time

1. Press and hold the **TIME SET** button (usually located on the back or bottom) until the hour digits begin to flash.
2. Press the **HOUR** button repeatedly to adjust the hour. Pay attention to AM/PM indicators if present.
3. Press the **MINUTE** button repeatedly to adjust the minutes.
4. Press **TIME SET** again to confirm and exit time setting mode.

### 4.2 Setting the Alarm

1. Press and hold the **ALARM SET** button until the alarm hour digits begin to flash.
2. Press the **HOUR** button repeatedly to adjust the alarm hour.
3. Press the **MINUTE** button repeatedly to adjust the alarm minutes.
4. Press **ALARM SET** again to confirm the alarm time.
5. To activate the alarm, press the **ALARM ON/OFF** button. An alarm indicator (e.g., a small icon) should appear on the display.

### 4.3 Snooze Function

When the alarm sounds (the monkey's cymbals will clash), press the large **SNOOZE** button (often located on top of the unit) to temporarily silence the alarm for approximately 9 minutes. The alarm will sound again after the snooze period.

### 4.4 Turning Off the Alarm

To turn off the alarm completely, press the **ALARM ON/OFF** button. The alarm indicator on the display will disappear, confirming the alarm is deactivated.

## 5. MAINTENANCE

- **Cleaning:** Wipe the alarm clock with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Placement:** Place the alarm clock on a stable, flat surface away from direct sunlight, heat sources, and moisture.
- **Battery Replacement:** If using backup batteries, replace them annually or when the display dims during a power outage.

## 6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Display is blank or dim.	No power or loose connection.	Ensure the USB power cable is securely connected to a power adapter and wall outlet. Check if backup batteries are depleted if applicable.
Alarm does not sound.	Alarm not activated or set incorrectly.	Verify the alarm time is set correctly and the alarm function is turned ON (check for alarm indicator on display).

Problem	Possible Cause	Solution
Time is incorrect.	Time not set or power interruption.	Reset the current time following the instructions in Section 4.1. If power was interrupted, ensure backup batteries are fresh.

## 7. SPECIFICATIONS

---

- **Model Number:** PP4898COD
- **Brand:** Paladone
- **Power Source:** USB (DC 5V)
- **Backup Power:** 3 x AAA Batteries (not included)
- **Item Weight:** Approximately 540 Grams
- **GTIN:** 05055964723743

## 8. WARRANTY AND SUPPORT

---

Paladone products are manufactured to the highest standards. For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Paladone website. Please retain your proof of purchase for any warranty claims.

For further assistance, please contact Paladone customer service.