Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Hunter /
- > Hunter 52-inch Contemporary Brushed Nickel Indoor Ceiling Fan User Manual

Hunter 52-inch Contemporary Brushed Nickel Indoor Ceiling Fan

Hunter 52-inch Contemporary Ceiling Fan User Manual

Model: Brushed Nickel Indoor Ceiling Fan with Light Kit and Remote Control

INTRODUCTION

This manual provides comprehensive instructions for the safe installation, operation, and maintenance of your Hunter 52-inch Contemporary Brushed Nickel Indoor Ceiling Fan. Please read all instructions carefully before beginning installation and retain this manual for future reference.



Image: The Hunter 52-inch Contemporary Brushed Nickel Ceiling Fan, showcasing its five light grey oak/grayed walnut reversible blades, integrated light kit, and accompanying remote control.

SETUP AND INSTALLATION

Proper installation is crucial for the safe and efficient operation of your ceiling fan. It is recommended that installation be performed by a qualified electrician.

Mounting Options

The fan features an Installer's Choice three-position mounting system, allowing for standard, low, or angled mounting to suit your room's requirements.

- Standard Mounting: Utilizes a 4-inch downrod (included).
- Low Profile Mounting: Requires a 2-inch downrod (not included).
- Angled Mounting: Requires a 36-inch downrod (not included) for sloped ceilings.




Image: A diagram illustrating the fan dimensions for various mounting configurations: Low Profile (A: 8.59", B: 12.75"), Standard (A: 10.59", B: 14.75"), and Angled (A: 42.59", B: 46.75").

Pre-Installation Checklist

- Ensure power is disconnected at the circuit breaker.
- · Verify all components are present as per the packing list.
- Confirm the mounting location can support the fan's weight.

Wiring Instructions

Connect the fan wiring to the household wiring according to local electrical codes. Ensure all connections are secure and insulated.

Blade Installation

Attach the five reversible blades to the motor housing. The blades feature Light Grey Oak on one side and Grayed Walnut on the other, allowing for customization.




Image: Close-up view of the light grey oak finish on one side of a fan blade.



Image: Close-up view of the grayed walnut finish on the reverse side of a fan blade.

OPERATING INSTRUCTIONS

Your Hunter ceiling fan comes with a convenient remote control for easy operation of fan speed and light functions.



Image: The handheld remote control for the Hunter ceiling fan, featuring buttons for light dimming, changing fan speed, battery compartment, and changing fan direction.

Remote Control Functions

- Light Button: Press to turn the light ON/OFF. Hold to dim the light.
- Fan Speed Buttons (Up/Down Arrows): Adjust the fan speed (3-speed WhisperWind motor).
- Fan Direction Button (Star/Asterisk): Reverses the direction of the fan blades for seasonal use.

Reversible Motor Function

The WhisperWind reversible motor allows you to change the direction of the fan blades for optimal air circulation throughout the year.

- Summer Mode (Counter-clockwise): Downward airflow creates a cooling effect.
- Winter Mode (Clockwise): Upward airflow circulates warm air trapped near the ceiling.



Image: An annotated diagram highlighting key features of the Hunter fan: the 3-speed WhisperWind Motor, 13-degree blade pitch, and the Integrated Dimmable LED light.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your ceiling fan.

Cleaning

- Always turn off power to the fan before cleaning.
- Use a soft, damp cloth to clean the fan blades and motor housing.
- Do not use abrasive cleaners or solvents, as they may damage the finish.

Light Bulb Replacement

The integrated light kit includes two 9-Watt energy-efficient, dimmable LED bulbs. When replacing, ensure the power is off and allow bulbs to cool before handling.

- Recommended Light Bulb Shape Code: E26
- · Light Bulb Base Code: A19

TROUBLESHOOTING

Before contacting customer support, please refer to the following common issues and their solutions.

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control battery low.	Check circuit breaker; Verify all wire connections are secure; Replace remote control battery.
Light does not work	Bulb loose or burnt out; Incorrect bulb type; Wiring issue.	Tighten or replace bulb; Ensure correct bulb type (E26/A19 LED); Check light kit wiring.
Fan wobbles	Loose blades or blade holders; Unbalanced blades; Loose mounting bracket.	Tighten all blade screws; Use balancing kit (not included) if necessary; Secure mounting bracket.
Remote control not working	Battery dead or incorrectly installed; Remote not paired with fan.	Replace battery, ensuring correct polarity; Refer to remote pairing instructions (if applicable, not detailed in product info).

SPECIFICATIONS

Detailed technical specifications for the Hunter 52-inch Contemporary Ceiling Fan.

• Brand: Hunter

• Model: 52-inch Contemporary Brushed Nickel Indoor Ceiling Fan

• Color: Brushed Nickel

• Electric Fan Design: Ceiling Fan

Power Source: ACStyle: Modern

• Product Dimensions: 52"D x 52"W x 14.75"H

• Room Type: Bedroom, Dining Room, Kitchen, Office, Living Room/Family Room

• Special Features: AC Motor, Dimmable, Frosted Glass, Reversible Blades, Reversible Motor, Variable Speed

• Recommended Uses: Indoor

• Wattage: 45 watts

• Blade Finish: Light Grey Oak / Grayed Walnut (Reversible)

• Light Kit: Integrated, Dimmable LED (2 x 9 Watt bulbs included)

• Motor: 3-speed WhisperWind reversible motor

• Mounting System: Installer's Choice (Standard, Low, Angled)




Image: EnergyGuide label indicating an estimated yearly energy cost of \$13, with an airflow of 2,618 Cubic Feet Per Minute and an airflow efficiency of 59 Cubic Feet Per Minute Per Watt.

WARRANTY AND SUPPORT

For warranty information or technical support, please contact Hunter Fan Company directly. Refer to the product packaging or the official Hunter website for the most current contact details and warranty terms. This product is ETL listed, ensuring it meets specific safety standards.

© 2023 Hunter Fan Company. All rights reserved.

Related Documents - 52-inch Contemporary Brushed Nickel Indoor Ceiling Fan



Hunter Fonthill Ceiling Fan Installation Manual & Guide

Comprehensive installation, operation, and troubleshooting guide for the Hunter Fonthill ceiling fan (Model 52901, 52903, 52904). Includes safety warnings, parts list, and warranty information.



Hunter Nolita 6-Light Chandelier Installation Guide (Models 19875, 19876)

Comprehensive installation guide for the Hunter Nolita 6-Light Chandelier (Models 19875, 19876). Includes safety warnings, parts identification, tools required, step-by-step assembly, wiring instructions, finishing touches, and cleaning tips.



Hunter Betsy Ceiling Fan Installation Manual

Comprehensive installation manual for the Hunter Betsy ceiling fan (Models 52764, 52765), providing step-by-step instructions, safety warnings, troubleshooting tips, and warranty information.




Hunter Bristlecone Ceiling Fan Installation Manual (Models 51805, 53247)

Comprehensive installation manual for the Hunter Bristlecone ceiling fan, covering models 51805 (Noble Bronze) and 53247 (Brushed Nickel). This guide provides step-by-step instructions for assembly, wiring, and mounting, along with safety warnings, troubleshooting tips, and warranty information.



Hunter Bennett Collection Ceiling Fan Installation Manual

Comprehensive installation guide for the Hunter Bennett Collection ceiling fan (Models 50420, 50421), covering setup, wiring, troubleshooting, and warranty information.



Hunter Kerrison 19542/19543 8-Light Foyer Lantern Pendant Installation Guide

Comprehensive installation guide for the Hunter Kerrison 8-Light Foyer Lantern Pendant (Models 19542, 19543), covering preparation, assembly, wiring, finishing, and cleaning. Includes safety warnings and required tools.