

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [iRobot](#) /

› [iRobot Roomba E5 \(5150\) Robot Vacuum User Manual](#)

iRobot e515020

iRobot Roomba E5 (5150) Robot Vacuum User Manual

MODEL: E515020

INTRODUCTION AND OVERVIEW

The Roomba E5 (5150) Robot Vacuum is designed to provide powerful and efficient cleaning for your home. Equipped with a 3-Stage Cleaning System and Dual Multi-Surface Rubber Brushes, it effectively pulls in dust, dirt, and pet hair from various floor types. Its intelligent sensors allow for seamless navigation, while Wi-Fi connectivity enables control via the iRobot Home App or voice assistants like Amazon Alexa and Google Assistant.



Figure 1: The iRobot Roomba E5 Robot Vacuum and its accompanying smartphone application.

PRODUCT FEATURES

- **Powerful Suction:** Delivers 5X the air power for deep cleaning.
- **Smart Connectivity:** Compatible with Amazon Alexa and Google Assistant for voice control.
- **Ideal for Pet Owners:** Effectively cleans dirt, hair, and allergens, trapping 99% of cat and dog dander allergens.
- **Intelligent Navigation:** Sensors intelligently navigate the robot under and around objects, avoiding obstacles and preventing falls down stairs.
- **Automated Cleaning:** Auto-adjusts to different floor types (carpets, rugs, tile, hardwood) and automatically recharges after cleaning.



Figure 2: The Roomba E5 demonstrating its power-lifting suction on a wooden floor.



Figure 3: An illustration of the Roomba E5's underside, highlighting its 5X power-lifting suction system.



Figure 4: The Roomba E5 can be controlled using voice commands through compatible devices like Amazon Alexa.



Figure 5: The Roomba E5 utilizes Dirt Detect Technology to identify and focus on dirtier areas.

Video 1: An official overview of the iRobot Roomba E5 (5150) Robot Vacuum, highlighting its features and capabilities.

SPECIFICATIONS

Brand	iRobot
Model Name	Roomba
Item Model Number	e515020
Color	Black
Product Dimensions	13.45"L x 13.39"W x 3.65"H
Item Weight	7.23 pounds
Battery Life	90 minutes
Filter Type	Disk

Included Components

Filter, Docking station, Cleaning pad

SETUP


Before first use, ensure your Roomba E5 is fully charged. Place the Home Base charging station on a level surface against a wall, ensuring there are no obstacles for at least 1.5 feet (0.5 meters) on either side and 4 feet (1.2 meters) in front. Plug the Home Base into a power outlet. Place your Roomba E5 onto the Home Base, ensuring the charging contacts align. The battery indicator will show charging status. Download the iRobot Home App to connect your Roomba to your Wi-Fi network and access smart features like scheduling and remote control.

OPERATING INSTRUCTIONS

To start a cleaning cycle, simply press the 'CLEAN' button on the robot or use the iRobot Home App. The Roomba E5 will automatically navigate your home, cleaning until its battery is low, at which point it will return to its Home Base to recharge. For targeted cleaning of a specific area, place the Roomba E5 on the desired spot and press the 'SPOT CLEAN' button. The robot will clean in a spiral pattern. You can also set up cleaning schedules via the iRobot Home App to automate daily or weekly cleaning tasks.

MAINTENANCE

Regular maintenance is crucial for optimal performance of your Roomba E5. After each cleaning cycle, empty the dust bin. The dust bin is washable; remove the filter before rinsing the bin under water. Allow the dust bin to dry completely before reinserting the filter and placing it back into the robot. Regularly check and clean the Dual Multi-Surface Rubber Brushes and the side brush to remove any tangled hair or debris. The filter should be replaced approximately every 2 months, or more frequently if you have pets.



Quick rinse and you're done

Keeping your Roomba® robot vacuum clean has never been easier. With a washable dust bin, any leftover dirt and debris simply washes away.

Figure 6: The washable dust bin of the Roomba E5 can be easily rinsed for cleaning.

TROUBLESHOOTING

If your Roomba E5 encounters an issue, it will typically provide an audible alert and an indicator light. Refer to the iRobot Home App for specific error messages and troubleshooting steps. Common issues include the robot getting stuck (clear obstacles from its path), the dust bin being full (empty and clean the bin), or the brushes needing cleaning (remove hair and debris). Ensure the Home Base is properly plugged in and free of obstructions if the robot is not returning to charge.


WARRANTY AND SUPPORT

The iRobot Roomba E5 (5150) Robot Vacuum comes with a 1-year limited warranty. For detailed warranty information, technical support, or to order replacement parts, please refer to the official documents below or visit the iRobot support website.

User Manual (PDF): [Download Here](#)

Warranty (PDF): [Download Here](#)

Related Documents - e515020

<small>User Manual of Product 1: iRobot Roomba 671 Robot Vacuum with Wi-Fi Connectivity. Works with Alexa. Good for Pet Hair, Carpets, and Hard Floors.</small>	<p>iRobot Roomba 671 Robot Vacuum User Manual</p> <p>This user manual provides detailed instructions for setting up, using, and maintaining the iRobot Roomba 671 Robot Vacuum with Wi-Fi Connectivity. Learn about its features, safety instructions, troubleshooting, and customer care.</p>
<small>User Manual of Product 1: iRobot Roomba 694 Robot Vacuum Wi-Fi Connectivity. Personalized Cleaning Recommendations. Works with Alexa. Good for Pet Hair, Carpets, Hard Floors, and Charging.</small>	<p>iRobot Roomba 694 Robot Vacuum Owner's Guide</p> <p>Comprehensive owner's guide for the iRobot Roomba 694 robot vacuum, covering safety instructions, setup, operation, maintenance, troubleshooting, and regulatory information.</p>
<small>User Manual of Product 1: iRobot Roomba i3 EVO (3150) Wi-Fi Connected Robot Vacuum. - New Clean by Room with Smart Mapping. Works with Alexa. Good for Pet Hair, Carpets & Hard Floors, Self-Charging.</small>	<p>iRobot Roomba i3 EVO (3150) User Manual: Setup, Cleaning, and Maintenance</p> <p>Comprehensive user manual for the iRobot Roomba i3 EVO (3150) Wi-Fi Connected Robot Vacuum. Learn about setup, operation, cleaning, maintenance, safety, and troubleshooting for your Roomba.</p>
<small>User Manual of Product 1: iRobot Roomba 692 Robot Vacuum - Wi-Fi Connected. Personalized Cleaning Recommendations. Works with Alexa. Good for Pet Hair, Carpets, Hard Floors, Self-Charging.</small>	<p>iRobot Roomba 692 Robot Vacuum Owner's Guide Features, Safety, and Care</p> <p>Comprehensive owner's guide for the iRobot Roomba 692 Robot Vacuum. Learn about setup, usage, safety instructions, maintenance, troubleshooting, and customer support for your Wi-Fi connected, Alexa-compatible cleaning robot.</p>
	<p>iRobot Roomba 900 Series Quick Start Guide</p> <p>A concise guide for setting up and starting your iRobot Roomba 900 robot vacuum. Learn how to set up the Home Base, activate the robot, and download the iRobot HOME app for enhanced features.</p>

User Manual of Product 1:
iRobot Roomba s9+ (9550) Self-Emptying Robot Vacuum --
Engine built for 40 Days, Wi-Fi Connected, Smart Mapping,
Powerful Suction, Camera & LiDAR, Ideal for Pet Hair, Carpets,
Jana Blach

[iRobot Roomba s9+ \(9550\) Self-Emptying Robot Vacuum User Manual](#)

Comprehensive user manual for the iRobot Roomba s9+ (9550) Self-Emptying Robot Vacuum, covering safety, operation, maintenance, troubleshooting, and regulatory information. Features Wi-Fi connectivity, smart mapping, and powerful suction.