Rii K66DE

Rii K66 Mechanical Gaming Keyboard User Manual

Model: K66

1. Introduction

The Rii K66 is a high-performance USB wired mechanical gaming keyboard designed for both work and gaming. It features a QWERTZ layout, anti-ghosting capabilities, and programmable functions, ensuring a responsive and customizable user experience. Equipped with brown silent switches and red LED illumination, the K66 offers durability and aesthetic appeal.

This manual provides comprehensive instructions for setting up, operating, maintaining, and troubleshooting your Rii K66 keyboard.

2. Safety Information

- Keep the keyboard away from liquids and excessive moisture to prevent damage.
- Avoid exposing the keyboard to extreme temperatures (hot or cold) or direct sunlight.
- Do not attempt to disassemble or modify the keyboard. This may void your warranty and cause damage.
- Use only the provided USB cable for connection.

3. Package Contents

Please verify that all items are present in your package:

- 1 x Rii K66 104-Key USB Wired Mechanical Gaming Keyboard
- 1 x User Manual



Image: Rii K66 keyboard packaging and included user manual.

4. Setup

4.1 Connecting the Keyboard

1. Carefully unpack the Rii K66 keyboard from its packaging.
2. Locate an available USB port on your computer (PC, Mac, Laptop, Notebook).
3. Plug the USB connector of the keyboard cable firmly into the USB port.
4. The keyboard is plug-and-play and should be automatically recognized by your operating system (Windows 10/8/7, Linux, Vista, Mac). No additional drivers are typically required.

4.2 Adjusting Keyboard Height

The Rii K66 keyboard features two foldable brackets on its underside. Gently flip these brackets out to elevate the

rear of the keyboard, allowing for a more ergonomic typing angle. Fold them back in for a flatter profile.



Image: The Rii K66 keyboard displaying its dimensions, including the height which can be adjusted using the rear brackets.

5. Operating Instructions

5.1 Basic Operation

The Rii K66 is a full 104-key QWERTZ mechanical keyboard. It supports anti-ghosting, allowing multiple keys to be pressed simultaneously without conflict, which is crucial for fast-paced gaming and efficient typing.



Image: The Rii K66 Mechanical Gaming Keyboard, showcasing its full QWERTZ layout and red LED backlighting.

5.2 Backlight Control

The keyboard features vibrant red LED illumination. The backlight automatically enters standby mode (turns off) after a period of inactivity. Pressing any key will reactivate the backlight.

- **Adjust LED Brightness:** Press **Fn** + **F9** (or the key with the '*' symbol) to cycle through brightness levels.
- **Adjust Flash Frequency:** Press **Fn** + **F10** (or the key with the '+' symbol) to change the speed of dynamic lighting effects.
- **Toggle ON/OFF LEDs:** Press **Fn** + **Esc** to turn the backlighting on or off.
- **Change Light Mode:** Press **Fn** + **F12** to cycle through different lighting effects (e.g., static, wave, ripple, breathing).

5.3 Programmable Features (Macros)

The Rii K66 supports programmable settings, allowing you to create and execute macros for enhanced productivity or gaming performance. It features 5 individual macro LEDs.

- **Macro Recording:** Press **Fn** + **PrtSc** to begin macro recording. The macro LED will illuminate. Type your desired key sequence. Press **Fn** + **PrtSc** again to save the macro.
- **Macro Play:** Press **Fn** + **Scroll Lock** to activate macro playback. The keyboard will execute the recorded sequence.

5.4 Multimedia and Function Keys

The keyboard integrates various function shortcuts accessible via the **Fn** key:



Image: Top view of the Rii K66 keyboard, illustrating the layout and the various function short keys and their combinations.

Function	Key Combination
Home	Fn + F1
Previous Track	Fn + F2
Play/Pause	Fn + F3
Next Track	Fn + F4
Mute	Fn + F5
Volume -	Fn + F6
Volume +	Fn + F7
Keyboard Lock	Fn + F8
WIN Lock	Fn + Windows Key

Function	Key Combination
Adjusting LED Brightness	Fn + F9 (or '*')
Adjusting Flash Frequency	Fn + F10 (or '+')
ON/OFF LEDs	Fn + Esc
Light Mode Cycle	Fn + F12
Macro Play	Fn + Scroll Lock
Macro Recording	Fn + PrtSc
Return to Factory Defaults	Press Fn + Del for 3 seconds (all LEDs flash 3 times)

5.5 Mechanical Switches

The Rii K66 utilizes brown silent mechanical switches, known for their tactile bump without a loud click, providing a balance between typing feedback and quiet operation. These switches are designed for a key life of 50 million keystrokes.



Image: A close-up view of the mechanical switches used in the Rii K66 keyboard, highlighting their design.

6. Maintenance

6.1 Cleaning

- To clean the keyboard, disconnect it from your computer.
- Use a soft, dry, lint-free cloth to wipe down the surface.
- For dust and debris between keys, use compressed air.
- Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the keyboard's finish and internal components.

6.2 Storage

When not in use for extended periods, store the keyboard in a cool, dry place, away from direct sunlight and extreme temperatures. It is recommended to keep it in its original packaging to protect it from dust and physical damage.

7. Troubleshooting

7.1 Keyboard Not Responding

- **Check USB Connection:** Ensure the USB cable is securely plugged into both the keyboard and the computer.
- **Try a Different USB Port:** Connect the keyboard to another USB port on your computer to rule out a faulty port.
- **Restart Computer:** A simple system restart can often resolve connectivity issues.
- **Test on Another Computer:** If possible, test the keyboard on a different computer to determine if the issue is with the keyboard or your system.

7.2 Backlight Issues

- **Backlight Off:** The backlight automatically turns off in standby mode. Press any key to reactivate it.
- **Adjust Brightness:** Use **Fn** + **F9** to increase brightness.
- **Toggle Backlight:** Ensure the backlight hasn't been turned off using **Fn** + **Esc**.

7.3 Keys Not Registering

- **Keyboard Lock:** Ensure the keyboard is not locked. Press **Fn** + **F8** to toggle the keyboard lock.
- **Clean Keys:** Dust or debris under the keycaps can sometimes prevent proper registration. Use compressed air to clean around the affected keys.
- **Factory Reset:** If issues persist, try resetting the keyboard to factory defaults by pressing **Fn** + **Del** for 3 seconds.

8. Specifications

Feature	Detail
Model	K66
Keyboard Layout	QWERTZ, 104 Keys
Interface	USB Wired
Key Switch Type	Brown Silent Mechanical Switches
Key Life	50,000,000 strokes
Anti-Ghosting	Full N-Key Rollover
Backlight	Red LED, Illuminated, Programmable
Material	Metal structure with matte texture
Color	Black
Working Voltage	5V
Keyboard Dimensions (L x W x H)	436 x 188 x 36mm (17.16 x 7.40 x 1.42 inches)

Feature	Detail
Compatibility	Windows 10/8/7, Linux, Vista, Mac

9. Warranty and Support

9.1 Warranty Information

The Rii K66 Mechanical Gaming Keyboard comes with a limited warranty. Please refer to the warranty card included with your product or visit the official Rii website for detailed warranty terms and conditions, including coverage period and limitations.

9.2 Customer Support

For technical assistance, troubleshooting not covered in this manual, or general inquiries, please contact Rii customer support through their official channels. You may also visit the Rii store on Amazon for product information and support resources.

Online Support: Visit the Rii Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question