

SENXINGYAN SXY-M2

SENXINGYAN SXY-M2 Bluetooth Speaker User Manual

Model: SXY-M2

1. INTRODUCTION

Thank you for choosing the SENXINGYAN SXY-M2 Bluetooth Speaker. This portable speaker is designed to deliver high-quality audio with robust features for various environments. Please read this manual carefully to ensure proper use and to maximize your listening experience.

2. WHAT'S IN THE BOX

- M2 Portable Bluetooth Speaker
- MicroUSB Charging Cable
- 3.5mm AUX Cable
- Portable Braided Rope

3. PRODUCT OVERVIEW AND FEATURES

The SENXINGYAN SXY-M2 speaker is equipped with advanced technology to provide a superior audio experience. Key features include:

- **Powerful Sound:** Features 2x10W stereo drivers for impressive sound with rich bass, compact mids, and clear highs.
- **Bluetooth 5.0:** Ensures a stable connection up to 15 meters with low latency, compatible with all Bluetooth-enabled devices.
- **Long Playtime:** Built-in 2800mAh lithium-ion battery provides up to 16 hours of playback on a full charge (3-4 hours charging time).
- **IPX6 Waterproof:** Constructed with high-quality waterproof, non-slip, durable silicone material, making it resistant to water splashes, dust, and rain. Ideal for outdoor use.
- **Multi-functional Connectivity:** Supports 3.5mm AUX input, TF card, USB drive, and FM radio mode.
- **Hands-free Calling:** Integrated microphone with noise and echo cancellation for clear hands-free communication.
- **True Wireless Stereo (TWS):** Connect two M2 speakers for a 360° stereo sound experience.



Figure 1: Front view of the SENXINGYAN SXY-M2 Bluetooth Speaker, showing the control buttons.

SUPPORT FOR HADNS-FREE CALLS

Bluetooth V5.0: Effective distance 15M



Figure 2: The speaker positioned next to a smartphone, demonstrating its hands-free call capability via Bluetooth V5.0 with an effective distance of 15 meters.

TURE WIRELSS STEREO

Pair 2 speakers for a 360° stereo effect

Left

Right




Figure 3: Two M2 speakers paired together to create a 360° stereo sound experience, labeled 'Left' and 'Right'.

SOPHISTICATED AND POWERFUL SOUND BASS PROCESSING TECHNOLOGY



Figure 4: An exploded diagram illustrating the internal components of the speaker, highlighting its sophisticated sound and bass processing technology.

IPX6 WATERPROOF

Don't worry about water splashes, dust, rain!



Figure 5: The speaker shown with water splashing on it, emphasizing its IPX6 waterproof rating, suitable for use in wet conditions.



Figure 6: A visual summary of the speaker's features, including its small size, IPX6 waterproof rating, Hi-Fi Bluetooth V5.0, 3.5mm audio cable support, 16-hour long playtime, FM mode, USB/TF card slot, and hands-free call support.

4. SETUP

4.1 Charging the Speaker

Before first use, fully charge the speaker. Connect the MicroUSB charging cable to the speaker's charging port and the other end to a USB power adapter (5V DC) or a computer's USB port. The charging indicator light will illuminate during charging and turn off when fully charged. A full charge typically takes 3-4 hours.

4.2 Powering On/Off

Press and hold the power button () for approximately 3 seconds to turn the speaker on or off. A sound prompt will indicate the power status.

4.3 Bluetooth Pairing

1. Turn on the speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing blue LED light.
2. Enable Bluetooth on your device (smartphone, tablet, computer).
3. Search for available Bluetooth devices and select "SXY-M2" from the list.
4. Once connected, the LED light will turn solid blue, and you will hear a confirmation sound.

5. OPERATING INSTRUCTIONS

5.1 Button Functions

- **Power Button ():** Press and hold for 3 seconds to power on/off. Short press to switch modes (Bluetooth/FM/AUX/USB/TF).
- **Play/Pause Button (▶||):** Short press to play or pause music. In Bluetooth mode, short press to answer/end calls. Press and hold to reject a call.
- **Volume Up / Next Track Button (⊕):** Short press to increase volume. Press and hold to skip to the next track.
- **Volume Down / Previous Track Button (⊖):** Short press to decrease volume. Press and hold to go to the previous track.

5.2 True Wireless Stereo (TWS) Pairing

To pair two SXY-M2 speakers for TWS stereo sound:

1. Ensure both speakers are powered on and not connected to any Bluetooth device.
2. On one speaker (this will be the master speaker), double-press the Play/Pause button. It will enter TWS pairing mode.
3. The two speakers will automatically connect to each other. You will hear a confirmation sound once paired.
4. Once TWS is established, connect your device to the master speaker via Bluetooth as described in section 4.3.

5.3 FM Radio Mode

1. Short press the Power button () to switch to FM radio mode.
2. Press and hold the Play/Pause button (▶||) to automatically scan and save available radio stations.
3. Use the Volume Up (⊕) and Volume Down (⊖) buttons to switch between saved stations.

5.4 AUX/USB/TF Card Playback

- **AUX Mode:** Insert the 3.5mm audio cable into the AUX port on the speaker and connect the other end to your audio device. The speaker will automatically switch to AUX mode.
- **USB/TF Card Mode:** Insert a USB drive or TF card (with audio files) into the respective port. The speaker will automatically detect and play music from the inserted storage.

6. MAINTENANCE

To ensure the longevity and optimal performance of your SENXINGYAN SXY-M2 speaker, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the speaker's surface. For stubborn dirt, a slightly damp cloth can be used, but ensure the speaker is completely dry before use or charging. Do not use abrasive cleaners or solvents.

- **Waterproof Care:** While the speaker is IPX6 waterproof, it is not designed for submersion. Ensure the charging port and other openings are securely covered when exposed to water. After exposure to water, wipe the speaker dry before charging.
- **Battery Care:** To preserve battery life, avoid fully discharging the speaker frequently. If storing for an extended period, charge the battery to about 50% and recharge every few months.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is low or depleted.	Charge the speaker fully.
No sound from speaker.	Volume is too low; device not connected; incorrect mode.	Increase volume on speaker and device. Ensure Bluetooth is connected or correct mode (AUX/USB/TF) is selected.
Bluetooth connection fails.	Speaker is too far from device; interference; speaker already connected to another device.	Move speaker closer to device. Disconnect from other devices. Restart speaker and device.
Poor FM radio reception.	Weak signal; environmental interference.	Relocate the speaker to an area with better signal. Perform an auto-scan again.
TWS pairing fails.	Speakers are already connected to a device; incorrect pairing procedure.	Ensure both speakers are disconnected from any Bluetooth devices. Follow TWS pairing steps precisely.

8. SPECIFICATIONS

Feature	Detail
Model Number	SXY-M2
Brand	SENXINGYAN
Connectivity Technology	Bluetooth 5.0
Maximum Speaker Output Power	20 Watts
Audio Output Mode	Stereo
Battery Type	Lithium-Ion (2800mAh)
Playtime	Up to 16 hours
Charging Time	3-4 hours
Waterproof Rating	IPX6

Feature	Detail
Product Dimensions	7 x 7 x 10 cm
Weight	400 Grams
Input Voltage	5 Volts (DC)
Material	Acrylonitrile Butadiene Styrene (ABS), Metal
Mounting Type	Tabletop

9. WARRANTY AND SUPPORT

The SENXINGYAN SXY-M2 Bluetooth Speaker comes with a 24-month warranty from the date of purchase, covering manufacturing defects. For any questions, technical support, or warranty claims, please contact SENXINGYAN customer service through the platform where you purchased the product. Please have your purchase receipt and product model number ready when contacting support.