

[Manuals.plus](#) /

› [Best Choice Products](#) /

› Best Choice Products Acacia Wood Chaise Lounge Chair User Manual

Best Choice Products SKY6437

User Manual: Best Choice Products Acacia Wood Chaise Lounge Chair

Model: SKY6437

Brand: Best Choice Products

INTRODUCTION

This manual provides essential information for the assembly, operation, and maintenance of your Best Choice Products 79x26in Acacia Wood Chaise Lounge Chair. Designed for outdoor relaxation, this chaise lounge features a durable acacia wood frame, comfortable foam-padded cushions, an adjustable backrest, a convenient slide-out side table, and built-in wheels for easy mobility. Please read this manual thoroughly before use to ensure safe and optimal performance of your product.




Image: The Best Choice Products Acacia Wood Chaise Lounge Chair in Cream, showcasing its full design with the adjustable backrest in an upright position.

KEY FEATURES

- **Contemporary Style:** Features an open backrest and high armrests for a sleek, modern aesthetic that enhances any outdoor space.
- **Quality Design:** Constructed with a naturally hardy acacia wood frame and paired with all-weather cushions for long-lasting outdoor enjoyment.
- **Adjustable Backrest:** A durable groove and peg system allows for four preset backrest angles, providing customizable comfort.
- **Pullout Side Table:** A convenient, hidden table slides out from either side of the lounge chair, offering a surface for refreshments or personal items.
- **Built-in Wheels:** Equipped with wood and rubber wheels for effortless movement across your yard or patio, allowing you to easily reposition the chair for sun or shade.

ADJUSTABLE BACKREST


Find your comfort zone with a four preset angles on a padded backrest



180 - 100
Degrees



Image: Close-up of the chaise lounge's adjustable backrest mechanism, showing the different reclining positions.



PULLOUT SIDE TABLE

A hidden utility table slides out to hold your favorite food, drinks and books

Image: The integrated pullout side table extended from the chaise lounge, providing a convenient surface.



BUILT-IN WHEELS

A set of wheels make it easy to move this chaise and find your place in the shade

Image: Detail of one of the built-in wood and rubber wheels, designed for easy portability.

PRODUCT DIMENSIONS



Image: Diagram illustrating the overall dimensions of the chaise lounge chair, including length, width, and height.

SETUP & ASSEMBLY

Your Best Choice Products Chaise Lounge Chair is designed for straightforward assembly. Most users report a quick and easy setup process, often completed within 15-20 minutes. It is recommended to loosely assemble all components before fully tightening any bolts to ensure proper alignment.

For detailed, step-by-step assembly instructions, please refer to the official Instructions for Use (IFU) PDF document available online. A link to this document can typically be found on the product's retail page or by searching for "Best Choice Products SKY6437 User Manual" online.

Important: Ensure all parts are present and undamaged before beginning assembly. If any parts are missing or damaged, contact customer support immediately.

OPERATING INSTRUCTIONS

Adjusting the Backrest

The chaise lounge features a multi-position adjustable backrest. To adjust, lift the backrest slightly and move it forward or backward to engage the desired groove in the support system. Ensure the backrest is securely seated in one of the four preset angles before use.

Using the Pullout Side Table

A convenient side table is integrated into the design. To use, simply pull the slatted wooden tray outwards from either side of the chair. To retract, push the tray back into its concealed position beneath the armrest. This table is ideal for holding drinks, snacks, or a book.

Moving the Chaise Lounge

The chaise lounge is equipped with two built-in wheels at one end. To move the chair, lift the end opposite the wheels and roll the chair to your desired location. This allows for easy repositioning to follow the sun or find shade.

Your browser does not support the video tag.

Video: An overview demonstrating the features and operation of the 79x26in Acacia Wood Outdoor Chaise Lounge Chair, including its adjustable backrest and mobility.

MAINTENANCE

Proper care will extend the life and appearance of your chaise lounge chair.

- **Cleaning:** Wipe clean the acacia wood frame and cushions with a damp cloth. For stubborn dirt, a mild soap solution can be used, followed by thorough rinsing and drying.
- **Wood Care:** While acacia wood is naturally hardy, applying a suitable outdoor wood oil (such as teak oil) every 6-12 months can help maintain its rich color and protect it from weathering, especially in harsh climates. Avoid using indoor wood treatments.
- **Cushion Care:** The cushions are all-weather, but storing them indoors or in a waterproof container during prolonged periods of rain or extreme weather will help preserve their condition and prevent fading.
- **Storage:** During off-season or extended periods of non-use, store the chaise lounge in a dry, covered area to protect it from the elements.

TROUBLESHOOTING

Assembly Issues (e.g., Stripped Screws)

In rare cases, some users have reported issues with stripped screw holes during assembly. If this occurs, a common solution is to drill out the stripped hole slightly, insert a small piece of wooden dowel with wood glue, allow it to dry completely (24 hours), and then drill a new pilot hole for the screw. This provides a secure anchor for the screw.

Weight Capacity

The maximum recommended weight capacity for this chaise lounge chair is 350 lbs. Exceeding this limit may compromise the structural integrity of the chair and void any warranty.

Wood Durability Over Time

While the acacia wood frame is designed for outdoor use, prolonged exposure to extreme weather conditions (intense sun, heavy rain, significant temperature fluctuations) without proper maintenance can lead to wear. Regular cleaning and application of outdoor wood oil are crucial for longevity. The manufacturer's warranty typically covers initial defects, not wear and tear from environmental exposure or lack of maintenance beyond a specified period (e.g., 60 days).

SPECIFICATIONS

Attribute	Detail
Brand	Best Choice Products

Model Name	Charles (Model Number: SKY6437)
Color	Cream
Product Dimensions	79"D x 29.75"W x 38"H
Material	Acacia Wood (Frame), Foam (Fill Material)
Maximum Weight Recommendation	350 Pounds
Adjustable Backrest Positions	4
Special Features	Built-in Wheels, Pullout Side Table, Adjustable Backrest
Indoor/Outdoor Usage	Outdoor
Item Weight	52 pounds
Country of Origin	Vietnam

WARRANTY & SUPPORT

Best Choice Products offers a return policy, typically allowing returns within 30 days of purchase. For specific warranty details, including coverage for manufacturing defects, please refer to the documentation included with your product or contact Best Choice Products customer service directly.

For additional support, including a downloadable PDF version of the user manual, please visit the official Best Choice Products website or the product page on Amazon.com.

Official User Guide (PDF): [Download PDF](#)

© 2024 Best Choice Products. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question