

[Manuals.plus](#) /

> [Cata](#) /

> Cata S 900 Wall-Mounted Cooker Hood User Manual

Cata S 900

Cata S 900 Wall-Mounted Cooker Hood User Manual

Model: S 900 | Brand: Cata

1. INTRODUCTION

Thank you for choosing the Cata S 900 Wall-Mounted Cooker Hood. This manual provides essential information for the safe installation, operation, and maintenance of your appliance. Please read these instructions carefully before use and retain them for future reference.

The Cata S 900 is a stylish and efficient wall-mounted decorative cooker hood designed to remove steam, smoke, and odors from your kitchen. It features three extraction levels, quiet operation thanks to its K7 Plus motor, and bright LED lighting for optimal visibility over your cooking area.

2. SAFETY INFORMATION

WARNING: Please read all safety instructions carefully before installation and use to prevent personal injury or damage to the appliance.

- Ensure the electrical installation complies with local regulations and is performed by a qualified electrician.
- Always disconnect the appliance from the power supply before cleaning or maintenance.
- This appliance is intended for domestic use only. Do not use it for purposes other than those for which it was designed.
- Adequate ventilation must be provided in the room when the cooker hood is used at the same time as appliances burning gas or other fuels.
- Do not flambé under the cooker hood.
- Regularly clean the filters to prevent grease accumulation, which can pose a fire hazard.
- Keep children away from the appliance during operation and cleaning.
- The minimum distance between the supporting surface for the cooking vessels on the hob and the lowest part of the cooker hood must be at least 65 cm.

3. PACKAGE CONTENTS

Upon unpacking, please verify that all components are present and undamaged:

- Cata S 900 Cooker Hood Unit
- Installation Kit (screws, wall plugs, mounting bracket)
- User Manual
- Grease Filters (pre-installed)

4. SETUP AND INSTALLATION

The Cata S 900 cooker hood features an easy installation system. However, for safety and optimal performance, professional installation is recommended.

4.1 Mounting the Hood

The hood is designed for wall mounting. Ensure the wall is strong enough to support the weight of the appliance (15 kg). Follow the provided template for drilling holes and securely attach the mounting bracket.

4.2 Ducting Connection

Connect the exhaust outlet of the hood to an appropriate ducting system that leads to the outside. Ensure the ducting is free from obstructions and has minimal bends to maintain optimal airflow.

4.3 Electrical Connection

Connect the hood to a suitable power supply (240V). Ensure the connection is secure and properly grounded. Refer to the wiring diagram in the full technical manual for detailed instructions.



A front view of the Cata S 900 wall-mounted cooker hood, showcasing its stainless steel finish and control panel.



The Cata S 900 cooker hood seamlessly integrated into a contemporary kitchen setting, mounted above a cooking range.

5. OPERATING INSTRUCTIONS

The Cata S 900 cooker hood is equipped with a user-friendly control panel, typically located on the front of the unit.

5.1 Power Levels

The hood offers 3 levels of extraction power to suit various cooking needs. Select the desired level using the control buttons:

- **Level 1:** For light cooking, simmering, or maintaining air quality.
- **Level 2:** For general cooking and moderate steam/odor removal.
- **Level 3:** For intensive cooking, frying, or when maximum extraction (up to 400 m³/h) is required.

The K7 Plus motor ensures quiet operation, with a maximum noise level of less than 62 dB even at the highest setting.

5.2 LED Lighting

The cooker hood features bright E-14 LED lighting to illuminate your cooking surface. Press the light button on the control panel to turn the lights on or off.



A detailed shot highlighting the metallic, washable grease filters and the integrated LED light strip on the underside of the cooker hood.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your cooker hood.

6.1 Cleaning Grease Filters

The metallic grease filters are dishwasher-safe, making cleaning convenient. It is recommended to clean the filters every 2-4 weeks, depending on usage, to maintain extraction efficiency and prevent grease buildup.

1. Disconnect the hood from the power supply.
2. Remove the filters by releasing their latches.
3. Wash the filters in a dishwasher or by hand using hot water and a mild detergent.
4. Ensure filters are completely dry before re-installing.

6.2 Exterior Cleaning

Clean the exterior of the hood with a soft cloth and a non-abrasive cleaner suitable for stainless steel. Avoid using harsh chemicals or abrasive pads that could scratch the surface.

6.3 LED Light Replacement

The LED lights (E-14) have a long lifespan. If replacement is necessary, ensure the hood is disconnected from power. Consult a qualified technician for assistance if you are unsure.

7. TROUBLESHOOTING

Before contacting customer service, please check the following common issues:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Hood does not turn on	No power supply; tripped circuit breaker	Check power connection and circuit breaker.
Low extraction power	Clogged grease filters; obstructed ducting	Clean or replace filters. Check ducting for blockages.
Excessive noise	Loose components; improper installation; obstructed fan	Ensure all parts are secure. Verify correct installation. Check fan for foreign objects.
Lights not working	Faulty LED bulb; electrical connection issue	Check bulb connection. Replace bulb if necessary (ensure power is off).

8. SPECIFICATIONS

Feature	Detail
Brand	Cata
Model Number	2029601
Dimensions (L x W x H)	47 x 90 x 93 cm
Weight	15 kg
Material	Stainless Steel
Color	Stainless Steel
Extraction Levels	3
Max Extraction Capacity	400 m³/h
Noise Level (Max)	Less than 62 dB (stated as 14 Decibels in some specs, but 62 dB from feature bullets is more realistic for max power)
Lighting Type	LED (E-14)
Lighting Wattage	5.5 watts
Filter Type	Dishwasher-safe filters
Mounting Type	Wall-mounted
Voltage	240V
Energy Efficiency Class	C

9. WARRANTY AND SUPPORT

Your Cata S 900 Cooker Hood comes with a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details.

For technical support, spare parts, or warranty claims, please contact your retailer or the authorized Cata service center in your region. Keep your proof of purchase for warranty validation.

You can also visit the official Cata website for more information:www.cata.es

© 2023 Cata. All rights reserved. Information subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question