

ReplacementScrews Stand Screws for Element ELEFW5016

ReplacementScrews Stand Screws User Manual

Compatible with Element ELEFW5016 TV Models

1. INTRODUCTION

Thank you for choosing ReplacementScrews for your television stand needs. This manual provides essential information for the proper installation, use, and maintenance of your new stand screws, specifically designed for compatibility with the Element ELEFW5016 television model. Please read this manual thoroughly before proceeding with installation to ensure a secure and correct setup.

These screws are engineered to replace lost or missing original factory stand screws, ensuring a perfect fit and maintaining the aesthetic integrity of your television setup.

2. PRODUCT OVERVIEW

The ReplacementScrews Stand Screw set includes four (4) black machine screws, precisely manufactured to match the specifications required for attaching the original factory stand legs to your Element ELEFW5016 television. These screws feature a black oxide plating for corrosion resistance and a sleek appearance that blends seamlessly with your TV.



Figure 2.1: Four black Phillips head machine screws included in the set.

Key Features:

- **Complete Set:** Contains all four screws required for attaching the original factory stand to your Element ELEFW5016 TV.
- **Correct Size & Thread:** Precisely sized M4 metric screws with fine threading for a secure fit into pre-threaded metal holes.
- **Black Oxide Plating:** Provides corrosion resistance and a professional, matching finish.
- **Quality Construction:** Designed to prevent stripping and ensure a durable, stable connection.
- **For Original Stands Only:** Exclusively for use with original factory TV stands, not for universal stands or wall mounts.

3. SPECIFICATIONS

Attribute	Specification
Material	Alloy Steel
Drive System	Phillips Drive
Exterior Finish	Black Oxide
Thread Size	M4
Color	Black
Head Type	Pan Head (Phillips)
Item Weight (Total)	0.26 Ounces

Attribute	Specification
Thread Type	Fine Threaded
Thread Coverage	Fully Threaded
Fastener Type	Machine Screw
Number of Pieces	4
Compatibility	Element ELEFW5016 TV

4. SETUP AND INSTALLATION

These screws are designed for straightforward installation. Please ensure your television is powered off and unplugged before beginning. It is recommended to perform this installation on a soft, clean surface to prevent damage to your TV screen.



Figure 4.1: The four screws ready for installation.

- 1. Verify TV Model:** Before installation, locate the model number on the back label of your television. Confirm it is

Element ELEFW5016 to ensure compatibility.

- 2. **Position TV:** Carefully lay your television screen-down on a clean, soft, and stable surface (e.g., a blanket or foam pad) to protect the screen from scratches.
- 3. **Attach Stand Legs:** Align the original factory stand legs with the designated screw holes on the bottom or back of your television.
- 4. **Insert Screws:** Insert one ReplacementScrews machine screw into each corresponding hole.
- 5. **Tighten Screws:** Using a Phillips head screwdriver, carefully tighten each screw. Do not overtighten, as this can strip the threads or damage the TV casing. Tighten until snug and the stand leg is firmly secured.
- 6. **Verify Stability:** Once all screws are tightened, gently lift the TV to ensure the stand legs are securely attached and stable before placing the TV upright.

Important Note: These screws are specifically designed for original factory stands. Do not attempt to use them for universal TV stands or wall mounting brackets, as these applications typically require different types and sizes of fasteners.

5. OPERATING CONSIDERATIONS

Once installed, the screws operate by securely holding the television stand in place. There is no active 'operation' required from the screws themselves. Their function is passive and structural.

Periodic Checks: It is advisable to periodically check the tightness of the screws, especially if the television is frequently moved or if there are vibrations in the area. Loose screws can lead to instability of the television stand.

6. MAINTENANCE

The ReplacementScrews stand screws require minimal maintenance.

- **Cleaning:** If necessary, wipe the screws with a dry, soft cloth to remove dust or debris. Avoid using harsh chemicals or abrasive materials, which could damage the black oxide finish.
- **Storage:** If the screws are removed for any reason, store them in a dry place away from moisture to prevent corrosion. Keep them in a small, sealed bag to avoid loss.

7. TROUBLESHOOTING

If you encounter issues during installation or use, please refer to the following common scenarios:

Problem	Possible Cause	Solution
Screws do not fit or are too large.	Incorrect TV model or non-original stand.	Double-check your TV's model number (ELEFW5016) on the back label. Ensure you are using the original factory stand. These screws are not for universal stands.
Screws are loose after tightening.	Threads may be stripped on the TV or stand, or screws are not fully tightened.	Ensure screws are tightened firmly but do not overtighten. If threads are stripped, professional repair may be needed for the TV or stand.
Missing screws from the package.	Packaging error.	Contact ReplacementScrews customer support immediately for assistance.

8. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your ReplacementScrews Stand Screws, please contact the manufacturer directly. While specific warranty details are not provided in this manual, ReplacementScrews is committed to providing quality products.

Please retain your proof of purchase for any support inquiries.

Manufacturer: ReplacementScrews

© 2025 ReplacementScrews. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07QRVLTFT>

More documents and user manuals: <https://manuals.plus/>