

[Manuals.plus](#) /

› [LEZYNE](#) /

› LEZYNE Mini Drive 400XL Bicycle Front Light User Manual

LEZYNE 1-led-24F-v204

LEZYNE Mini Drive 400XL Bicycle Front Light User Manual

Model: 1-led-24F-v204

INTRODUCTION

Thank you for choosing the LEZYNE Mini Drive 400XL Bicycle Front Light. This manual provides essential information for the proper setup, operation, and maintenance of your new bicycle light. Please read this manual thoroughly before use to ensure optimal performance and safety.

The LEZYNE Mini Drive 400XL is a compact and durable bicycle front light designed for enhanced visibility during both day and night riding. It features a high-output LED emitter, multiple lighting modes, and a convenient cable-free USB charging stick.

PRODUCT OVERVIEW



Image: Front view of the LEZYNE Mini Drive 400XL bicycle front light, showing the LED emitter and power button.



Image: Side view of the LEZYNE Mini Drive 400XL bicycle front light, highlighting the brand logo and model number.

The Mini Drive 400XL features a CNC-machined aluminum body for durability and heat dissipation, a high-output LED emitter, and a highly durable silicone strap for versatile mounting.



Image: The LEZYNE Mini Drive 400XL bicycle front light mounted on a bicycle handlebar, demonstrating its compact size and placement.

SETUP

Charging the Battery

The Mini Drive 400XL features an integrated, cable-free USB stick for convenient recharging. To charge:

1. Locate the USB charging stick at the rear of the light.

2. Carefully pull the light body away from the silicone strap to expose the USB stick.
3. Insert the USB stick directly into a powered USB port (e.g., computer, USB wall adapter).
4. The indicator light will show charging status. A full charge typically takes approximately 2-3 hours.
5. Ensure the USB stick is inserted correctly; if not, it will not charge.

Mounting the Light

The integrated silicone strap allows for easy and secure mounting on various handlebar sizes.

1. Wrap the silicone strap around your bicycle's handlebar.
2. Hook the strap onto the designated tab on the light body.
3. Adjust the light angle to ensure optimal forward illumination without blinding oncoming traffic.

OPERATING INSTRUCTIONS

Power On/Off

- To turn on: Press and hold the power button for 2 seconds.
- To turn off: Press and hold the power button for 2 seconds.

Changing Modes

The Mini Drive 400XL offers eight different output modes. To cycle through modes, press the power button briefly while the light is on.

LEZYNE Mini Drive 400XL Lighting Modes and Runtimes

Mode	Lumens	Runtime (H:MIN)
Blast	400	1:00
Enduro	150	2:30
Economy	75	5:00
Femto	15	20:00
Flash 1	50	13:30
Flash 2	50	13:30
Day Flash	400	7:00
Pulse	50	15:00



Image: A chart illustrating the different lighting modes, corresponding lumen outputs, and approximate runtimes for the Mini Drive 400XL.

Daytime Visibility

The Mini Drive 400XL includes a dedicated Daytime Flash mode (400 lumens, 7:00 runtime) designed to enhance rider visibility during daylight hours, which is crucial for accident prevention.

Your browser does not support the video tag.

Video: An official LEZYNE video demonstrating the importance of daytime visibility for cyclists and showcasing various LEZYNE lights, including the Mini Drive 400XL, in action during the day.

MAINTENANCE

Cleaning

- Clean the light body and lens with a soft, damp cloth.
- Avoid using abrasive cleaners or solvents, as these can damage the finish or lens.

Storage

- Store the light in a cool, dry place when not in use.
- For long-term storage, charge the battery to approximately 50% every few months to maintain battery health.

Water Resistance

The Mini Drive 400XL is IPX7 water-resistant, meaning it can withstand immersion in water up to 1 meter for 30 minutes. However, it is not designed for underwater use. Ensure the USB port is dry before charging.

TROUBLESHOOTING

- **Light not turning on:** Ensure the battery is charged. Press and hold the power button for 2 seconds to power on.
- **Light not charging:** Verify the USB stick is fully and correctly inserted into a powered USB port. Try a different USB port or charger.
- **Short runtime:** The battery may not be fully charged, or a high-lumen mode is being used. Refer to the mode table for expected runtimes. Battery performance can degrade over time with extensive use.
- **Intermittent operation:** Check for loose connections or debris in the USB port. Ensure the light is securely mounted.

If issues persist, please contact LEZYNE customer support.

SPECIFICATIONS

Feature	Detail
Brand	LEZYNE
Model Number	1-led-24F-v204
Light Output (Max)	400 Lumens
Number of Settings	8 (including Daytime Flash)
Material	CNC-machined Aluminum
Power Source	Battery Powered (Rechargeable via integrated USB)

Feature	Detail
Water Resistance Level	IPX7 (Waterproof)
Mounting Type	Handlebar Mount (Integrated Silicone Strap)
Item Weight	0.23 Pounds
Product Dimensions (L x W x H)	9"L x 5.5"W x 1"H
Included Components	Headlight

WARRANTY AND SUPPORT

Warranty Information

This LEZYNE product is covered by a Limited Warranty. For specific details regarding warranty coverage, terms, and conditions, please refer to the official LEZYNE website or contact customer support. Keep your proof of purchase for warranty claims.

Customer Support

For further assistance, technical support, or inquiries, please visit the official LEZYNE website or contact their customer service department. You can find contact information on the LEZYNE website: [LEZYNE Official Store](#)