

[Manuals.plus](#) /

› [Baby born](#) /

› Baby born Baby Annabell Doll Model 916236 Instruction Manual

Baby born 916236

Baby born Baby Annabell Doll Model 916236 Instruction Manual

Brand: Baby born

INTRODUCTION

The Baby Annabell Doll Model 916236 is an interactive baby doll designed to simulate realistic baby behaviors. This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your doll to ensure proper function and enjoyment. The doll features lifelike sounds, movements, and interactive functions such as feeding, crying real tears, and wetting her diaper.



Image: The Baby Annabell Doll, dressed in a pink outfit with a matching hat and bib, featuring blue eyes.

SAFETY INFORMATION

- **Recommended Age:** This doll is suitable for children aged 36 months (3 years) to 72 months (6 years).
- **Water Usage:** Use only clean tap water for the doll's feeding and crying functions. Do not use other liquids.
- **Battery Safety:** Ensure batteries are inserted correctly with the proper polarity. Do not mix old and new batteries, or different types of batteries. Remove batteries if the doll will not be used for an extended period.
- **Cleaning:** Do not immerse the doll in water. Clean the surface with a damp cloth only.
- **Small Parts:** Some accessories may pose a choking hazard for very young children. Adult supervision is recommended.

PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 1 Baby Annabell Doll
- 1 Bottle
- 1 Pacifier

- 1 Bib/Diaper
- 1 Locket



Image: The Baby Annabell Doll displayed with its bottle, pacifier, bib, diaper, and locket.

SETUP

1. **Unpacking:** Carefully remove the doll and all accessories from the packaging. Retain packaging for future reference.
2. **Battery Installation:** Locate the battery compartment, usually on the doll's back. Open it with a screwdriver (not included). Insert the required batteries (typically AA or AAA, check doll for specific type and quantity) ensuring correct polarity (+/-). Close the compartment securely.
3. **Preparing the Bottle:** Fill the included baby bottle with clean tap water. Ensure the cap is securely fastened. This water is used for the doll's drinking, crying, and wetting functions.

Your browser does not support the video tag.

Video: An instructional video demonstrating how to prepare the Baby Annabell doll's bottle for feeding.

OPERATING INSTRUCTIONS

1. Feeding and Drinking

Place the bottle nipple into the doll's mouth. The doll will make realistic sucking sounds and movements. Ensure the bottle contains water for the doll to drink. After feeding, gently pat the doll's back to hear burping sounds.



Image: A child holding the Baby Annabell Doll and feeding it with a pink bottle.

2. Crying Real Tears

If the doll becomes upset, she will cry and produce real tears. To activate this feature, ensure the doll has been fed water. The tears will flow from her eyes. Console the doll by giving her the pacifier or gently rocking her.



Image: A close-up of the Baby Annabell Doll's face, showing tears streaming from its blue eyes.

3. Wetting Diaper

After drinking water, the Baby Annabell Doll can wet her diaper. Gently squeeze her tummy to activate the wetting function. You will need to change her diaper afterwards, just like a real baby.



Image: A child's hands adjusting a diaper on the Baby Annabell Doll.

4. Sleeping and Snoring

When it's time for a nap, gently rock the Baby Annabell Doll. Her eyes will slowly close, and she will begin to make soft snoring sounds, indicating she is asleep.



Image: A child lying in bed, sleeping peacefully next to the Baby Annabell Doll.

5. Interactive Sounds and Movements

The doll produces various realistic baby sounds, including babbles, gurgles, and laughter, in response to interaction. Her mouth also moves when she uses the bottle or pacifier.

Your browser does not support the video tag.

Video: A short video showcasing various interactive features of the Baby Annabell Doll, including sounds and movements.

MAINTENANCE

- **Cleaning the Doll:** Wipe the doll's surface with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners. Avoid getting water into electronic components.
- **Draining Water:** After playing with water functions, ensure all water is drained from the doll to prevent mold or damage. Refer to the doll's specific instructions for water drainage if provided on the doll itself.
- **Accessory Care:** Wash the bib and diaper as needed according to their care labels. Clean the bottle and pacifier with warm, soapy water and rinse thoroughly.
- **Battery Replacement:** When the doll's sounds or movements become weak or inconsistent, it is time to replace the batteries. Follow the battery installation steps in the Setup section.
- **Storage:** Store the doll in a clean, dry place away from direct sunlight and extreme temperatures. Remove batteries if storing for an extended period.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Doll not responding or making sounds.	Low or dead batteries; incorrect battery installation.	Replace batteries with new ones, ensuring correct polarity.
Doll not crying real tears.	Insufficient water in the doll's reservoir; doll not activated to cry.	Ensure the bottle is filled with water and the doll has "drunk" it. Interact with the doll to trigger crying.
Doll not wetting diaper.	No water consumed; tummy not squeezed correctly.	Feed the doll water. Gently squeeze the doll's tummy after feeding.
Doll's eyes not closing or snoring.	Doll not in sleeping mode; mechanism obstruction.	Gently rock the doll to initiate sleep. Check for any obstructions around the eyes.

SPECIFICATIONS

Feature	Detail
Brand	Baby born
Model Name	Baby Annabell Baby Doll
Model Number	916236
Manufacturer	MGA Entertainment
Recommended Age	36 - 72 Months
Material Type	Plastic
Item Dimensions (L x W x H)	8.5" x 3" x 16"
Interactive Features	Interactive Audio, Goes Potty, Cries Real Tears, Eyes Open & Close

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact the manufacturer, MGA Entertainment, directly. Keep your proof of purchase for any warranty claims.

Manufacturer: MGA Entertainment

For further assistance, visit the [Baby born Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question