

[Manuals.plus](#) /

> [Easytry123](#) /

> Easytry123 Remote Control User Manual for Hyundai Air Conditioners (Models: 810900025CW, HSH-S091NBE, HSH-P091NDC, HSH-S121NBE, HSH-S181NBE, HSH-S071NBE, GYKQ-03)

Easytry123 Easytry6961

Easytry123 Replacement Remote Control User Manual

For Hyundai Air Conditioner Models: 810900025CW, HSH-S091NBE, HSH-P091NDC, HSH-S121NBE, HSH-S181NBE, HSH-S071NBE & Asia GYKQ-03

1. PRODUCT OVERVIEW

This document provides instructions for the Easytry123 infrared replacement remote control, designed for specific Hyundai and Asia GYKQ-03 air conditioner models. This remote serves as a functional replacement; however, it is important to note that it may not offer all functions identical to your original remote control. Please refer to the images provided to confirm the appearance and button layout.



Figure 1: Front view of the Easytry123 Replacement Remote Control.

2. COMPATIBILITY

This replacement remote control is compatible with the following air conditioner models:

- Hyundai 810900025CW
- Hyundai HSH-S091NBE
- Hyundai HSH-P091NDC
- Hyundai HSH-S121NBE
- Hyundai HSH-S181NBE
- Hyundai HSH-S071NBE
- Asia GYKQ-03

Important: Ensure your air conditioner model is listed above. This remote is specifically designed for these models, and functionality with unlisted models cannot be guaranteed.

3. SETUP

3.1 Installing Batteries

The remote control requires two (2) AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Note: Always replace both batteries at the same time with new ones. Do not mix old and new batteries, or different types of batteries.



Figure 2: Back view of the remote control with the battery compartment.

4. OPERATING INSTRUCTIONS

This remote control operates via infrared (IR) technology. Ensure there is a clear line of sight between the remote's IR emitter and the air conditioner's receiver. Point the remote directly at the air conditioner when operating.

As a replacement unit, the specific functions and button labels are designed to mimic the original remote. However, some advanced or unique functions of your original air conditioner might not be fully supported or may operate differently. Refer to your air conditioner's original manual for detailed function descriptions.

4.1 Common Button Functions (Based on visual inspection)

- **Power Button (Blue):** Turns the air conditioner ON or OFF.
- **Mode Button (Green):** Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **Temperature Adjustment Buttons (Up/Down Arrows):** Increases or decreases the set temperature.
- **Fan Speed Button (Fan Icon):** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **Timer Button (Clock Icon):** Sets the timer for automatic ON/OFF operations.
- **Sleep/Star Button (Star Icon):** Activates or deactivates sleep mode or a special function.
- **Swing Button (Arrows):** Controls the louver swing function.

Note: The exact icons and functions may vary slightly depending on your specific air conditioner model and its capabilities. Experiment with the buttons to understand their corresponding actions on your unit.

5. MAINTENANCE

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's range decreases or it stops responding. Always use new AAA batteries and dispose of old batteries responsibly.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage.

6. TROUBLESHOOTING

- **Remote not responding:**
 - Check if the batteries are inserted correctly with the correct polarity.
 - Replace old batteries with new AAA batteries.
 - Ensure there is a clear line of sight between the remote and the air conditioner's IR receiver. Remove any obstructions.
 - Confirm that the remote is pointed directly at the air conditioner.
- **Limited range:**
 - Replace batteries.
 - Ensure no strong light sources (like direct sunlight) are interfering with the IR signal.
- **Certain functions not working:**
 - As a replacement remote, some advanced or specific functions of your original air conditioner may not be fully supported. This is normal for universal or replacement remotes.
 - Verify that your air conditioner model is explicitly listed in the compatibility section.

7. SPECIFICATIONS

Feature	Description
Brand	Easytry123
Model Number	Easytry6961
Connectivity Technology	Infrared
Controller Type	Button Control
Maximum Range	10 Meters
Batteries Required	2 AAA batteries (not included)
Special Feature	Replacement remote; may not promise all full same functions equal to original.

8. WARRANTY AND SUPPORT

Specific warranty information for this Easytry123 replacement remote control is not provided in the product details. For any support inquiries, troubleshooting assistance beyond this manual, or questions regarding returns or warranty claims, please contact the seller directly through your purchase platform.