

[Manuals.plus](#) /

› [Bewinner](#) /

› Bewinner Universal RAR-3V2 Air Conditioner Remote Control User Manual

Bewinner RAR-3V2

Bewinner Universal RAR-3V2 Air Conditioner Remote Control User Manual

Brand: Bewinner | Model: RAR-3V2 (Bewinnerie041y8dbo)

INTRODUCTION

This Bewinner RAR-3V2 remote control is specifically designed for Hitachi air conditioners, serving as an ideal replacement for lost or damaged original remotes. It features an intuitive LCD screen for simple and convenient operation. Its compact and portable design ensures it is easy to hold and resistant to slipping.

Key features include easy setup, comfortable handling, a built-in clock, and multiple operating modes such as Fan and Auto. The remote offers simple programming with easy-to-read buttons and provides a powerful signal for long-distance control.

SETUP

Battery Installation

The remote control requires **2 AAA batteries** for operation (not included). Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Slide the battery cover back into place until it clicks securely.

Controller for Hitachi air-conditioning



Powered by 2 * AAA batteries.



Image: Rear view of the remote control with the battery cover removed, illustrating the battery insertion process.

Initial Use

This remote control is designed for **direct use** with compatible Hitachi air conditioners. No complex setup or programming is typically required after battery installation. Simply point the remote at your air conditioner and begin operation.

Directly use, no need to set up

Remote control distance is more than 10m / 30ft (Depend on the air-conditioning model).



Image: The remote control being used to operate a Hitachi air conditioning unit, demonstrating its direct usability.

OPERATING INSTRUCTIONS

The Bewinner RAR-3V2 remote control features an intuitive layout with clearly labeled buttons for various functions. The LCD screen displays current settings and modes.



Image: Front view of the remote control, highlighting its LCD display and button layout.

Key Functions:

- **Power Button:** Turns the air conditioner on or off.
- **Mode Selection:** Cycle through various operating modes such as:
 - *Auto:* Automatically adjusts settings based on room temperature.
 - *Cool:* Provides cooling.
 - *Dry:* Dehumidifies the air.
 - *Fan:* Operates the fan without heating or cooling.
 - *Heat:* Provides heating (if supported by your AC unit).
- **Temperature Adjustment:** Use the **Up/Down arrows** to increase or decrease the desired temperature.
- **Fan Speed:** Adjust the fan speed (e.g., Low, Medium, High, Auto).
- **Swing/Louvre Control:** Adjust the direction of the airflow.

- **Timer:** Set a timer for the air conditioner to turn on or off automatically.
- **Clock:** Set the current time on the remote's built-in clock.
- **Reset Button:** A small recessed button, typically used to reset the remote to factory settings. May require a pointed object (like a pen tip) to press.



Image: A user's hand interacting with the remote control, illustrating the ease of button operation.

MAINTENANCE

To ensure the longevity and optimal performance of your remote control, follow these maintenance guidelines:

- **Battery Replacement:** Replace batteries when the remote's performance degrades or the LCD display becomes dim. Always replace both batteries at the same time with new ones.
- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as

- these can damage the remote's surface or internal components.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
 - **Avoid Drops:** Handle the remote with care to prevent damage from accidental drops.

TROUBLESHOOTING

If you encounter issues with your Bewinner RAR-3V2 remote control, refer to the table below for common problems and their solutions:

Problem	Possible Cause	Solution
Remote is not responding or AC unit does not react.	Dead or incorrectly installed batteries; Obstruction between remote and AC unit; Remote is out of range.	Check and replace batteries, ensuring correct polarity. Remove any obstructions. Ensure you are within the effective operating range (up to 30 feet).
Limited control distance or intermittent response.	Low battery power; Strong light interference; Obstruction.	Replace batteries. Avoid using the remote in direct sunlight or near strong light sources that might interfere with the infrared signal. Ensure clear line of sight.
Remote functions are incorrect or erratic.	Internal error; Remote needs reset.	Remove batteries for a few minutes, then reinsert them. If issues persist, press the 'RESET' button (usually a small recessed button) with a pointed object.
Remote does not work with my Hitachi AC model.	Incompatibility with specific AC model.	While designed for Hitachi, some specific models may have unique protocols. Verify compatibility with your AC unit's model number if issues persist.

SPECIFICATIONS

Detailed technical specifications for the Bewinner RAR-3V2 remote control:

Feature	Detail
Model	RAR-3V2 (Bewinnerie041y8dbo)
Brand	Bewinner
Compatible Devices	Hitachi Air Conditioners
Connectivity Technology	Infrared
Power Supply	2 x AAA Batteries (not included)
Power Supply Type	DC 3V
Maximum Range	More than 10 meters / 30 feet (may vary by AC model)

Feature	Detail
Material	ABS
Color	White
Product Dimensions (L x W x H)	14 x 5.5 x 1.7 cm / 5.51 x 2.17 x 0.67 inches
Weight	68g
UPC	765192091075



Image: Dimensions of the remote control for reference.

WARRANTY AND SUPPORT

This product typically comes with a **1-year manufacturer warranty**. For specific warranty details or to inquire about support, please refer to the documentation provided with your purchase or contact the seller directly.

For technical assistance or troubleshooting beyond the scope of this manual, it is recommended to contact Bewinner customer support or the retailer from whom the product was purchased.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question