

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [iRobot](#) /

› [iRobot Roomba s9+ Self Emptying Robot Vacuum Instruction Manual](#)

iRobot s955020

iRobot Roomba s9+ Robot Vacuum Instruction Manual

Brand: iRobot

Model: s955020

PRODUCT OVERVIEW

The iRobot Roomba s9+ is a powerful and intelligent robot vacuum designed for thorough cleaning. It features advanced technologies for efficient navigation, powerful suction, and convenient self-emptying capabilities.



The iRobot Roomba s9+ robot vacuum with its accompanying Clean Base Automatic Dirt Disposal unit.

Key Features:

- **Powerful Suction:** Delivers 40x more Power-Lifting Suction compared to Roomba i Series robots, utilizing a 3-Stage Cleaning System to lift, loosen, and eliminate debris and pet hair. Automatically increases suction on carpets with power boost technology.

- **Self-Emptying Clean Base:** The s9+ automatically empties its vacuum bin into an enclosed bag within the Clean Base, holding up to 60 days of debris.
- **Imprint Smart Mapping:** Learns the layout of your home, builds personal Smart Maps, and allows control and scheduling of specific rooms for cleaning. Supports multiple maps for different levels of your home.
- **PerfectEdge Technology:** Advanced sensors and a specially designed Corner Brush optimize cleaning deep into corners and along edges. Ideal for homes with pets due to 40% larger Multi-Surface Dual Rubber Brushes that resist tangling.
- **Intelligent Navigation:** Guided by vSLAM technology, it expertly cleans and navigates in neat, efficient rows. Careful Drive Mode detects objects (taller than 2.5 cm) and cleans around them.
- **Personalized Cleaning Suggestions:** Powered by iRobot OS, the robot provides tailored cleaning recommendations based on your habits, pollen seasons, and pet-shedding times.
- **Automatic Cleaning Schedules:** Can be set to automatically start cleaning when you leave and stop when you return.
- **Imprint Link Technology:** Works with Braava jet m6 robot mop to vacuum then mop automatically in perfect sequence for a comprehensive clean.



**Attacks messes using a
3-Stage Cleaning System**

*Compared to Roomba® 600 series

The underside of the Roomba s9+ highlighting its 3-Stage Cleaning System with dual rubber brushes for effective debris pickup.



***Gets into corners
and edges thoroughly***

The Roomba s9+ utilizing its PerfectEdge Technology to clean deep into corners and along edges.

**iRobot® vSLAM® Technology gathers
over 230,400 data points per second**



The robot vacuum employs vSLAM technology to gather data points and navigate efficiently, creating a detailed map of its environment.



The Roomba s9+ can be directed to spot clean specific messes as they happen, integrating with the iRobot Home App or voice assistants.




Powered by iRobot OS

iRobot OS provides personalized cleaning suggestions, such as recommending extra cleaning during shedding season, to keep your home tidy.



*Ideal for
homes with pets*



Through Imprint Link Technology, the Roomba s9+ robot vacuum and Braava jet m6 robot mop can coordinate to vacuum and then mop automatically.



The Roomba s9+ automatically detects carpeted areas and increases its cleaning power for a deeper clean.

SETUP GUIDE

Follow these steps to set up your iRobot Roomba s9+ for the first time.

1. Unboxing and Placement:

- Remove all packaging materials from the robot and the Clean Base.
- Place the Clean Base in an area with good Wi-Fi coverage, on a hard, level surface, and against a wall. Ensure there are no obstacles within 1.5 feet (0.5 meters) on either side of the Clean Base and 4 feet (1.2 meters) in front of it.

2. Initial Charging:

- Plug in the Clean Base.

- Place the Roomba s9+ onto the Clean Base, ensuring the charging contacts align. The light ring on the robot will pulse white to indicate charging.
- Allow the robot to fully charge before its first cleaning mission (approximately 3 hours).

3. Connect to iRobot Home App:

- Download the iRobot Home App from your device's app store.
- Follow the in-app instructions to connect your Roomba s9+ to your home Wi-Fi network. This will enable smart mapping, scheduling, and other advanced features.

Your browser does not support the video tag.

Official iRobot video demonstrating the seamless integration of the Roomba s9+ into a clean home routine, highlighting its self-sufficiency.

OPERATING YOUR ROOMBA S9+

Your Roomba s9+ is designed for intelligent and efficient cleaning. Here's how to operate it effectively:

1. Starting a Cleaning Job:

- Press the **CLEAN** button on the robot or use the iRobot Home App to start a cleaning cycle.
- The robot will automatically navigate and clean your home.

2. Smart Mapping and Customization:

- After a few cleaning runs, the robot will create a Smart Map of your home in the iRobot Home App.
- Use the app to label rooms, set **Keep Out Zones** (areas the robot should avoid), and define **Clean Zones** (specific areas for targeted cleaning).
- You can schedule cleaning jobs for specific rooms or your entire home at preferred times.

3. Voice Control:

- Connect your Roomba s9+ to compatible voice assistants like Amazon Alexa or Google Home.
- Use voice commands to start, stop, or send your robot to clean specific areas (e.g., "Alexa, tell Roomba to vacuum the kitchen").

4. Object Detection (Careful Drive Mode):

- The robot is designed to detect and navigate around objects taller than 2.5 cm, reducing the likelihood of collisions.

MAINTENANCE AND CARE

Regular maintenance ensures your Roomba s9+ operates at peak performance. The iRobot Home App will notify you when maintenance is required.

1. Emptying the Clean Base Bag:

- The Clean Base bag holds up to 60 days of debris. When the bag is full, the app will notify you.
- Lift the lid of the Clean Base. Pull up on the bag's tab to remove it. The bag automatically seals itself.
- Dispose of the full bag and insert a new one, ensuring it clicks into place.



Removing the full dirt disposal bag from the Clean Base. The bag seals automatically upon removal for mess-free disposal.

2. Cleaning the Dustbin and Filter:

- The robot's internal dustbin should be emptied regularly, especially if you don't have the Clean Base.
- Open the robot's lid, press the dustbin release button, and pull out the dustbin.
- Open the dustbin door and empty debris.
- Remove the filter from the dustbin. Tap the filter against a trash can to remove debris. The filter is not washable.
- Rinse the dustbin with water (do not wash the filter). Allow it to air dry completely before reinserting the

filter and placing the dustbin back into the robot.



The dustbin of the Roomba s9+ with its filter, which should be regularly cleaned or replaced for optimal performance.

3. Cleaning the Brushes:

- Periodically remove and clean the Multi-Surface Dual Rubber Brushes and the Corner Brush.
- Turn the robot over. Pinch the green tabs to release the brush frame and remove the brushes.
- Remove any hair or debris wrapped around the brushes or trapped in the brush bearings.
- For the Corner Brush, use a small screwdriver to remove the screw, then remove and clean the brush.
- Reinstall all components securely.

TROUBLESHOOTING COMMON ISSUES

If your Roomba s9+ encounters an issue, the light ring will indicate an error, and the robot may speak a

message. Refer to the iRobot Home App for detailed troubleshooting steps.

General Tips:

- Robot Stuck or Error Message:** Check the iRobot Home App for specific error codes and instructions. Often, clearing debris from wheels or brushes can resolve the issue.
- Poor Cleaning Performance:** Ensure the dustbin is empty, the filter is clean, and the brushes are free of tangled hair or debris.
- Navigation Issues:** Ensure your home is well-lit during cleaning for optimal vSLAM navigation. Clear any new obstacles or rearrange furniture that might confuse the robot.
- Wi-Fi Connectivity:** If the robot loses connection, check your Wi-Fi router and ensure the robot is within range. Follow app instructions to reconnect.

For more comprehensive troubleshooting, please refer to the official [User Manual \(PDF\)](#).

TECHNICAL SPECIFICATIONS

Feature	Detail
Brand	iRobot
Model Name	Roomba s9+
Item Model Number	s955020
Product Dimensions	12.25" L x 12.25" W x 3.5" H
Item Weight	8.15 pounds
Color	Black
Special Feature	Ideal for Pet Hair, Powerful Suction, Edge Cleaning, Wi-Fi Connected, Self-Emptying
Included Components	Dusting Brush, Filter, Dirt Disposal Bag, Charging Station
Filter Type	Cartridge
Battery Life	120 minutes
Capacity (Clean Base)	60 days of debris
Power Source	Battery Powered
Control Method	Voice, App
Compatible Devices	Smartphones, Amazon Echo, Tablets, Google Home

Specific Instructions for Use

Dual action, hard floor, carpet

WARRANTY AND SUPPORT

Your iRobot Roomba s9+ comes with a manufacturer's warranty and access to comprehensive support resources.

Warranty Information:

- The iRobot Roomba s9+ includes a **1-year limited warranty**. Please refer to the official warranty document for full terms and conditions.

Customer Support:

- For additional support, troubleshooting, or to purchase accessories, visit the official [iRobot Store](#).
- You can also download the complete [User Manual \(PDF\)](#) for detailed instructions and information.

Related Documents - s955020

 Kullanıcı Kılavuzu 900 Serisi Roomba 960, 955, 965, 961, 962, 963	<u>iRobot Roomba 900 Serisi Kullanıcı Kılavuzu</u> Kullanım kılavuzu ve bakım bilgileri iRobot Roomba 900 Serisi robot süpürge için. Güvenlik talimatları, kurulum, kullanım, sorun giderme ve garanti bilgileri içerir.
 iRobot 900 Series Quick Start Guide Guide de démarrage rapide Guía de inicio rápido	<u>iRobot Roomba 900 Series Quick Start Guide</u> A concise guide for setting up and starting your iRobot Roomba 900 robot vacuum. Learn how to set up the Home Base, activate the robot, and download the iRobot HOME app for enhanced features.
 800 Series Owner's Guide	<u>iRobot Roomba 800 Series Owner's Guide: Setup, Usage, and Maintenance</u> Comprehensive owner's guide for the iRobot Roomba 800 Series vacuuming robot. Learn about setup, scheduling, cleaning modes, regular maintenance, troubleshooting, and customer support for your Roomba.

	<p>iRobot Roomba Discovery Series Service Manual - Troubleshooting and Repair Guide</p> <p>Comprehensive service manual for the iRobot Roomba Discovery Series, covering troubleshooting, diagnostics, repair procedures, and maintenance for models like Roomba Scheduler, Discovery SE, Sage, and Red. Includes detailed guides on built-in tests, disassembly, and component testing.</p>
	<p>iRobot Roomba Discovery Series Service Manual</p> <p>Comprehensive service manual for the iRobot Roomba Discovery Series robotic vacuum cleaners, detailing troubleshooting, diagnostics, maintenance, and repair procedures for models like Roomba Scheduler, Discovery SE, Sage, and Red.</p>
	<p>iRobot Roomba 770 Battery Replacement Guide</p> <p>A step-by-step guide to replacing the battery in an iRobot Roomba 770, including necessary tools and parts.</p>