

Sharp EL-1501

Sharp EL-1501 Compact Cordless Paperless Printing Calculator

Model: EL-1501 (8541735555)

User Instruction Manual

1. INTRODUCTION

This manual provides detailed instructions for the operation and maintenance of your Sharp EL-1501 Compact Cordless Paperless Printing Calculator. This device is designed to combine the functionality of a desktop calculator with the unique features of a paperless printing calculator, allowing for efficient and accurate calculations without the need for paper printouts.

The EL-1501 features a 12-digit main display and a five-line secondary LCD for reviewing up to 300 previous entries. Its cordless, battery-operated design ensures portability and convenience.




Figure 1: Front view of the Sharp EL-1501 Paperless Printing Calculator.

2. SETUP

The Sharp EL-1501 calculator is designed for cordless operation, powered by batteries. Follow these steps to prepare your calculator for first use:

1. **Battery Installation:** The calculator requires 4 AA batteries. These batteries are included with your purchase. Locate the battery compartment on the underside of the calculator. Open the compartment cover, insert the batteries, ensuring correct polarity (+/-), and then close the cover securely.
2. **Power On:** Press the **ON/C.CE** button located on the bottom left of the keypad to turn on the calculator. The display should illuminate.
3. **Initial Display Check:** Verify that the 12-digit main display and the 5-line scrolling LCD are functioning correctly.



Figure 2: The Sharp EL-1501 calculator ready for use on a desk.

3. OPERATING INSTRUCTIONS

The Sharp EL-1501 operates with printing calculator logic, offering a range of functions for various calculations. Below are instructions for common operations:

3.1 Basic Operations

- **Number Entry:** Use the numeric keypad (0-9) to enter numbers.
- **Arithmetic Operations:** Use the **+**, **-**, **×**, and **÷** keys for addition, subtraction, multiplication, and division, respectively.
- **Equals:** Press the **=** key to display the result of a calculation.
- **Clear Entry/Clear All:** The **C.CE** key clears the last entered number or the entire calculation depending on the context.
- **Backspace:** Use the **←** key to delete the last digit entered.

3.2 Advanced Functions

- **Cost/Sell/Margin (CSM):** These dedicated keys (**COST**, **SELL**, **MGN**) simplify profit margin calculations. Enter any two variables, and the third will be automatically calculated.
 - To calculate **SELL** price: Enter **COST**, press **COST**, enter **MARGIN** %, press **MGN**, then press **SELL**.
 - To calculate **COST**: Enter **SELL** price, press **SELL**, enter **MARGIN** %, press **MGN**, then press **COST**.
 - To calculate **MARGIN** %: Enter **COST**, press **COST**, enter **SELL** price, press **SELL**, then press **MGN**.
- **Tax Keys:** Use **TAX+** and **TAX-** for quick tax calculations. Set the tax rate using the **RATE SET** function.
- **Memory Functions:** The calculator includes a four-key memory (**M+**, **M-**, **RM**, **CM**) for storing and recalling values.

- **Grand Total (GT):** The GT key accumulates the results of calculations and displays the grand total.
- **Rounding and Decimal Settings:** Adjust rounding and decimal places using the dedicated switches/buttons.
- **Scrolling Function:** The 5-line secondary LCD allows you to scroll back and forth through up to 300 previous entries using the arrow keys (▲, ▼).





Figure 3: Key functions including Cost/Sell/Margin and Scrolling Function.



EL-1501



Automatic
Tax Keys



Rounding
Switch



Decimal
Switch



Grand Total
Function



Key Memory



Backspace Key



Percent Key

Figure 4: Overview of key features such as Automatic Tax Keys, Rounding Switch, Decimal Switch, Grand Total Function, 4 Key Memory, Backspace Key, and Percent Key.

4. MAINTENANCE

Proper care and maintenance will extend the life of your Sharp EL-1501 calculator:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the calculator. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the casing or display.
- **Battery Replacement:** When the display becomes dim or the calculator functions erratically, it is time to replace the batteries. Always replace all 4 AA batteries at the same time with new ones to ensure optimal performance. Dispose of old batteries according to local regulations.
- **Storage:** Store the calculator in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity. If storing for an extended period, it is recommended to remove the batteries to prevent leakage.
- **Handling:** Avoid dropping the calculator or subjecting it to strong impacts, as this can damage internal components or the display.

5. TROUBLESHOOTING

If you encounter issues with your Sharp EL-1501, refer to the following common troubleshooting tips:

Troubleshooting Guide

Problem	Possible Cause	Solution
Calculator does not turn on.	Dead or incorrectly installed batteries.	Check battery polarity. Replace all 4 AA batteries with new ones.
Display is dim or flickering.	Low battery power.	Replace all 4 AA batteries.
Incorrect calculation results.	Incorrect input, incorrect mode setting, or memory error.	Clear the calculation using C.CE . Re-enter the calculation carefully. Check decimal and rounding settings. Clear memory if necessary.
Scrolling display not working.	No history to scroll through, or feature not activated.	Perform some calculations to generate history. Ensure you are using the correct arrow keys.

If the problem persists after trying these solutions, please refer to the official user manual PDF linked in the support section or contact Sharp customer support.

6. SPECIFICATIONS

Key specifications for the Sharp EL-1501 Paperless Printing Calculator:

- **Model Number:** 8541735555 (EL-1501)
- **Display:** 12-digit main LCD, 5-line scrolling secondary LCD
- **Power Source:** 4 AA batteries (included)
- **Dimensions (L x W x H):** 9 x 5.9 x 2.4 inches (approximately)
- **Item Weight:** 1.1 pounds
- **Functions:** Cost/Sell/Margin, Tax Keys, 4-Key Memory, Grand Total, Rounding, Decimal Selector, Percent, Sign Change, Backspace.
- **Color:** White
- **First Available:** April 18, 2019







Figure 5: Approximate dimensions of the Sharp EL-1501 calculator.

7. WARRANTY AND SUPPORT

For detailed warranty information and further support, please refer to the official documentation provided by Sharp.

- **Official User Manual:** A comprehensive user manual in PDF format is available for download. [Download User Manual \(PDF\)](#)
- **Manufacturer Support:** For technical assistance, service, or warranty claims, please visit the official Sharp website or contact their customer service department.

	SHARP EL-1901 Paperless Printing Calculator Operation Manual This operation manual provides detailed instructions for the SHARP EL-1901 Paperless Printing Calculator, covering its features, controls, operation modes, calculation examples, and maintenance.
	Sharp EL-1611V Electronic Printing Calculator Operation Manual Comprehensive operation manual for the Sharp EL-1611V electronic printing calculator, covering setup, controls, operations, maintenance, and specifications. Learn how to use its printing, tax, and memory functions.
	Sharp EL-1197PIII Electronic Printing Calculator Operation Manual Comprehensive operation manual for the Sharp EL-1197PIII Electronic Printing Calculator, covering features, controls, calculations, maintenance, specifications, and warranty information.
	Sharp EL-T3301 Thermal Printing Calculator Operation Manual Comprehensive operation manual for the Sharp EL-T3301 thermal printing calculator, covering its features, controls, calculation examples, error handling, and specifications.
	Sharp EL-1801P Electronic Printing Calculator Operation Manual Comprehensive operation manual for the Sharp EL-1801P Electronic Printing Calculator, detailing its features, controls, functions, calculation examples, specifications, and troubleshooting.
	Sharp ELSI MATE EL-244W, EL-310W, EL-377W Electronic Calculator Operation Manual Official operation manual for the Sharp ELSI MATE EL-244W, EL-310W, and EL-377W electronic calculators, covering features, specifications, basic calculations, tax calculations, and battery replacement. Provides detailed instructions and operational guidance.




[pdf] User Manual

EL 1501 UVU TINSZA277EHVT 420x296 105x148 SHARP Sharp Calculators 1 Subtotal Used to get subtotal s of additions and or subtractions When pressed following the key is displayed with symbol O calculation Manual sharpcalculators images Manuals Printing |||

PAPERLESS PRINTING CALCULATOR CALCULADORA IMPRESORA SIN PAPEL OPERATION MANUAL **EL-1501** MANUAL DE MANEJO PRINTED IN CHINA / IMPRESO EN CHINA 18ASC TINSZA277EHVT ENGLISH INTRODUCTION This calculator shows calculations on a sub-display rather than printing on roll paper. You can view the calcu...

lang:es score:29 filesize: 402.62 K page_count: 2 document date: 2019-02-05



[pdf] User Manual

EL 1501 MORAVIA Europe paperless printing calculator calculadora impresora sin papel operation manual de manejo el printed in china impreso en 18asc tinsza277ehvt 455 es it sharp calculators files manuals file |||

PAPERLESS PRINTING CALCULATOR CALCULADORA IMPRESORA SIN PAPEL OPERATION MANUAL **EL-1501** MANUAL DE MANEJO OPERATING CONTROLS POWER ON / CLEAR / CLEAR ENTRY KEY: Clear This key also serves as a clear key for the calculation register and resets an error condition. Clear entry When pressed after a n...

lang:es score:28 filesize: 997.03 K page_count: 4 document date: 2019-10-30



[pdf] User Manual Guide

ILLUSTRATED RADIO REPAIR World Radio History tester instruction manual high fidelity guide quizzes television book radio trouble shooting book membership in tv club consultation service f c amateur license training printed circuitry servicing lessons you will learn and Electronics Illustrated Repair Hertzberg 633 1967 worldradiohistory Archive

ELECTRONICS ILLUSTRATED RADIO REPAIR By Robert Hertzberg How To Fix... *AC-DC Sets *Transistor Portables *Solid State Table Models *Multi-Band Receivers *Auto Radios *FM Sets BUILD YOUR OWN BOAT AND SAVE Cruisers and Auxiliary Sailers Ketches, Catboats and Catamarans Inboard and Outboard Spe...

lang:en score:25 filesize: 6.46 M page_count: 116 document date: 2020-05-19



[pdf]

EL 1501 el sharp calculators it file attachments 803 |||

EL-1501 I SHARP calcolatrici sono rappresentati in Europa esclusivamente dal Gruppo MORAVIA www.sharp-calculators.com info sharp-calculators.com FUNZIONE DISPLAY FLUORESCENTE A 12 CIFRE DISPLAY LCD A 5 RIGHE ALIMENTAZIONE A BATTERIA SEPARATORE OGNI 3 CIFRE IMPOSTAZIONE DECIMALE F-3-2-0-A ...

lang:tl score:22 filesize: 159.7 K page_count: 1 document date: 2020-05-29



[pdf]

EL 1501 el sharp calculators de file attachments 924 |||

EL-1501 Sharp Taschenrechner werden in Europa von der MORAVIA Gruppe vertreten www.sharp-calculators.com info sharp-calculators.com FUNKTIONEN 12-STELLIGE FLUORESZIEREND ANZEIGE 5-ZEILIGES LCD-ANZEIGE BATTERIEBETRIEB AUTOMATISCHE PUNKTIERUNG NACHKOMMASTELLEN F-3-2-0-A RUNDEN-FUNKTION 4-T...

lang:de score:22 filesize: 160.78 K page_count: 1 document date: 2020-01-14



[pdf]

EL 1501 el sharp calculators cz file attachments 1047 |||

EL-1501 Kalkulatory Sharp zastupuje v Evrop obchodn skupina MORAVIA Group www.sharp-calculators.com info sharp-calculators.com FUNKCE 12CIFERN FLUORESCENCN DISPLEJ 5DKOV LCD DISPLEJ NAPJEN BATERI 3CIFERN INTERPUNKCE NASTAVEN POCTU DESETINNCH MST F-3-2-0-A FUNKCE ZAKROUHLOVN PAM SE 4 TLAC...

lang:tl score:22 filesize: 162.38 K page_count: 1 document date: 2020-01-14




[pdf]

Pobierz Arkusz danych EL 1501 Sharp calculators el sharp pl file attachments 1112 |||

EL-1501 Kalkulatory SHARP reprezentowane s w Europie przez MORAVIA Group www.sharp-calculators.com info sharp-calculators.com OPIS PRODUKTU 12-CYFROWY WYWIETLACZ FLUORESCENCYJNY 5-LINIOWY WYWIETLACZ LCD ZASILANIE BATERYJNE 3-CYFROWA INTERPUNKCJA USTAWIENIE MIEJSC DZIESITNYCH F-3-2-0-A ZAO...

lang:tl score:22 filesize: 162.03 K page_count: 1 document date: 2020-01-14



[pdf] User Manual Guide

Administrator Product User Guide AGA Ludlow Electric Stove Wide Living Ellesmere and Standard 2022
agaliving sites default files user guides uploaded |||

ELLESMERE WIDE ELLESMERE STANDARD LUDLOW WIDE LUDLOW STANDARD Electric Stove Models Manual or Wi-Fi App Controlled Installation Operating Manual INSTALLER: LEAVE THIS MANUAL WITH THE APPLIANCE. CUSTOMER: PLEASE RETAIN THIS MANUAL FOR FUTURE REFERENCE. For use in GB IE United Kingdom and Ireland...

lang:en score:22 filesize: 4.11 M page_count: 42 document date: 2022-06-22



[pdf]

Descargar Ficha de datos EL 1501 Sharp calculators el sharp es file attachments 1046 |||

EL-1501 Las calculadoras Sharp representa en Europa el grupo MORAVIA Group www.sharp-calculators.com info sharp-calculators.com FUNCIONES PANTALLA FLUORESCENTE DE 12 DGITOS PANTALLA LCD DE CINCO RENGLONES ALIMENTACIN: BATERA PUNTUACIN DE 3 CIFRAS CONFIGURACIN DECIMAL F-3-2-0-A REDONDEO 4...

lang:pt score:22 filesize: 160.81 K page_count: 1 document date: 2020-01-14



[pdf]

ContalDmicrosoft EL 1501 Pour assurer un fonctionnement sans problème de votre calculatrice SHARP nous vous recommandons ce qui suit 1 La doit être conservée dans 91MRINo7FXS m media amazon images l |||


CALCULATEUR D IMPRESSION SANS PAPIER MANUEL D UTILISATION **EL-1501**

SHARP CORPORATION INTRODUCTION Cette calculatrice montre les calculs sur

un sous-cran plutt que d imprimer sur du papier roul. Vous pouvez afficher l

historique des calculs en appuyant sur ou . Appuyer sur pour revenir aux calculs....

lang:fr **score:16** filesize: 518.21 K page_count: 13 document date: 2020-12-04



[pdf]

User Manual Guide 1501 XCD Luana Wichmann genie 1501xcd manual dwn alza cz 47536 |||

1501 XCD DE BEDIENUNGSANLEITUNG 2 GB INSTRUCTION MANUAL 8 FR


GUIDE DUTILISATION 14 IT ISTRUZIONI PER L USO 20 ES MANUAL DEL

USUARIO 26 NL GEBRUIKSAANWIJZING 32 CZ NVOD K OBSLUZE 37 Verze/

Versin/ Versione: 09/ 2012 DE BEDIENUNGSANLEITUNG Sehr geehrter Kunde,

sehr geehrte Kundin, wir...

lang:de **score:15** filesize: 501.79 K page_count: 42 document date: 2016-11-29



[pdf]

User Manual Specifications Warranty Accessories

TFT 7700 Series Studio Transmitter Link Manual Time and Frequency Technology Stud Index of tft

manuals steampoweredradio |||

PRINTING DATE DECEMBER, 1979 7700 SERIES STUDIO TRANSMITTER LINK

TIME FREQUENCY TECHNOLOGY, INC. 3090 Oakmead Village Drive Santa Clara,

CA 95051 408 246-63-6365 www.SteamPoweredRadio.Com SECTION 1 SECTION 2

TABLE OF CONTENTS GENERAL INFORMATION PAGE 1.1 1.2


Introduction.

lang:en **score:15** filesize: 90.4 M page_count: 162 document date: 2020-01-07



[pdf] User Manual Guide

Microsoft Word 11883 Manual 1501 XCD Vers 02 2017 tobias krebs 18 ago 2023 — Halten Sie Ihre Finger und Hände stets fern von der Eingabeöffnung um ernsthafte Verletzungen zu vermeiden 5 Der kontinuierliche Schneidevorgang sollte manual 96385 17667996 avxperten dk files ||| 1501 XCD DE BEDIENTUNGSANLEITUNG 2 GB INSTRUCTION MANUAL 8 FR GUIDE D UTILISATION 14 IT ISTRUZIONI PER L USO 20 ES MANUAL DEL USUARIO 26 Version/ Versin/ Versione: 02/ 2017 DE BEDIENTUNGSANLEITUNG Sehr geehrter Kunde, sehr geehrte Kundin, wir danken Ihnen fr den Kauf dieses Qualittspr... lang:de score:15 filesize: 784.26 K page_count: 31 document date: 2017-12-06



[pdf] Safety Datasheet

MSDS 0 05MB Sharp EL 1501 Paperless Printing Calculator master images files shrel1501 sds officesupplysource product 4792546 ||| ... lang:de score:11 filesize: 52.44 K page_count: 0 document date: 0000-00-00



Katalog kalkulaček Sharp

Kompletní produktový katalog kalkulaček Sharp, včetně kapesních, stolních, vědeckých a tiskových modelů. Obsahuje detailní specifikace a chytré funkce pro kancelář, školu i domácnost. lang:tl score:11 filesize: 23.68 M page_count: 48 document date: 2023-02-20

This product is a consumer product which is used in a hermetically sealed state. So, it is not an object of the SDS system. This document is provided to customers as reference information for the safe handling of the product. The information and recommendations are both in good faith and are believed to be accurate at the date of preparation. Panasonic Corporation makes no warranty expressed or implied.

PRODUCT SAFETY DATA SHEET**1 Chemical product and company identification**

Name of Product : Zinc Carbon Battery (R20, R14, R6, R03, GP22)
Name of Company : Panasonic Corporation
Address : 1-1 Matsubara-cho, Matsubara-city, Osaka, 570-8501, Japan
Emergency Contact : +81-6-6895-3441 (9:00-17:00 JST)

2 Hazard identification

GHS Classification : Not applicable
Hazard : When the leaked liquid adheres to the skin, it may cause the damage of the skin.
Hazard : There is the risk of explosion if batteries are disposed in fire, heated above 100 degree C. Stacking or jumbling batteries may cause external short circuits, heat generation and explosion.

3 Composition information of ingredients

Component	Material	CAS No.	Content
Positive electrode	Manganese dioxide	1313-13-9	20-30wt%
	Acetylene black	1333-86-4	4-5wt%
Negative electrode	Zinc	7440-66-6	5-20wt%
Electrolyte	Zinc Chloride	7664-68-7	3-10wt%
	Ammonium chloride	12125-02-9	0.05-0.5wt%
	Water	-	9-20wt%

[\[pdf\]](#) Datasheet Safety Datasheet Warranty

PRODUCT SAFETY DATA SHEET Panasonic MSDS Sharp EL 1501 12 digit Printing Calculator

OfficeSupply SHREL1501 SDS content oppictures Master Images Files |||

Zinc Carbon Battery Ref. No.: MN-PSDS-5E-2 Effective Date: Jan. 1, 2019 Page 1 / 4

This product is a consumer product which is used in a hermetically sealed state. So, it is not an object of the SDS system. This document is provided to customers as reference information for the safe handling of the ...

lang:en score:10 filesize: 101.83 K page_count: 4 document date: 2019-03-21