Sensea 74555033 - Duscharmatur NATU (AD)

Sensea NATU Single-Lever Shower Mixer Faucet Instruction Manual

Model: 74555033 - Duscharmatur NATU (AD)

1. Product Overview

Product Description

The Sensea NATU Single-Lever Shower Mixer Faucet is designed for easy and quick wall-mounted installation. It features a sleek chrome finish and durable brass construction, ensuring reliable performance and a modern aesthetic for your bathroom. This mixer provides precise control over water flow and temperature with its single lever operation and 40mm ceramic cartridge.

Key Features

- Visually attractive single-lever shower mixer faucet.
- Easy and quick to mount.
- Color: Chrome, brilliant finish.
- Material: Durable Brass construction.
- Flow rate: 25.3 L/min.
- Ceramic cartridge: 40 mm for smooth operation.
- Two-hole type for wall installation.
- Mounting distance: 150 mm.
- Connection: 1/2 inch.




Figure 1: Sensea NATU Single-Lever Shower Mixer Faucet, showcasing its chrome finish and compact design.

2. Safety Information

Please read all instructions carefully before installation and use. Keep this manual for future reference.

- Ensure the main water supply is turned off before beginning any installation or maintenance work.
- If you are unsure about any part of the installation process, consult a qualified plumber.
- Do not use abrasive cleaners or harsh chemicals on the faucet's surface, as this may damage the finish.
- Always test water temperature before use to prevent scalding, especially for children and the elderly.
- Ensure all connections are secure and leak-free after installation.

3. Setup and Installation

Before You Begin

Ensure you have all necessary components and tools before starting the installation.

Required Tools (Not Included):

- Adjustable wrench
- Screwdriver
- Plumber's tape (PTFE tape)
- Level
- Measuring tape

Installation Steps (Wall-Mounted)

1. **Turn off Water Supply:** Locate the main water shut-off valve for your home or bathroom and turn it off. Open existing faucets to drain any remaining water from the pipes.
2. **Prepare Mounting Area:** Ensure the wall surface is clean and ready for installation. This faucet requires a two-hole setup with a standard mounting distance of 150 mm (15 cm) between the hot and cold water inlets.
3. **Install Eccentric Connectors:** Apply plumber's tape to the threaded ends of the eccentric connectors. Screw them into the hot and cold water outlets in the wall. Adjust them until they are level and the distance between their centers is exactly 150 mm. The 1/2 inch connections should face outwards.
4. **Attach Decorative Covers:** Slide the decorative chrome covers over the eccentric connectors, flush against the wall.
5. **Mount the Faucet:** Carefully align the faucet's inlets with the eccentric connectors. Hand-tighten the large nuts onto the connectors.
6. **Secure the Faucet:** Using an adjustable wrench, carefully tighten the nuts. Do not overtighten, as this can damage the faucet or connections. Ensure the faucet is level and securely fixed to the wall.
7. **Check for Leaks:** Slowly turn the main water supply back on. Inspect all connections for any signs of leaks. If leaks are present, turn off the water supply and re-tighten the connections as needed.
8. **Test Operation:** Once installed and leak-free, test the faucet's operation by moving the lever to control water flow and temperature.

4. Operating Instructions

The Sensea NATU shower mixer features a single lever for intuitive control of water flow and temperature.

- **Water Flow Control:** Lift the lever upwards to increase water flow. Push it downwards to decrease flow and turn off the water.
- **Temperature Control:** Move the lever to the left for hot water and to the right for cold water. Adjust the position between hot and cold to achieve your desired water temperature.

5. Maintenance

Regular cleaning and maintenance will ensure the longevity and optimal performance of your Sensea NATU faucet.

- **Cleaning the Surface:** Clean the chrome surface regularly with a soft cloth and mild soap or a non-abrasive bathroom cleaner. Rinse thoroughly with clean water and dry with a soft cloth to prevent water spots.
- **Avoid Harsh Cleaners:** Do not use abrasive sponges, scouring pads, or cleaners containing ammonia, bleach, acids, or alcohol, as these can damage the chrome finish.
- **Cartridge Maintenance:** The 40mm ceramic cartridge is designed for durability. If you experience persistent drips or difficulty controlling water flow/temperature, the cartridge may need cleaning or replacement. This typically requires professional assistance.
- **Aerator Cleaning (if applicable):** Although this is a shower mixer, if it were to have an aerator (e.g., for a bath spout attachment), it should be periodically unscrewed and cleaned of mineral deposits.

6. Troubleshooting

Refer to the following table for common issues and their potential solutions.

Problem	Possible Cause	Solution
Low Water Flow	Partially closed shut-off valve; mineral buildup in pipes or faucet.	Ensure water supply valves are fully open. Consult a plumber for pipe cleaning or cartridge inspection.
Leaking from Faucet Spout	Worn or damaged ceramic cartridge.	Contact a qualified plumber to inspect and replace the 40mm ceramic cartridge.
Leaking at Connections	Loose connections; insufficient plumber's tape.	Turn off water supply. Tighten connections. If necessary, reapply plumber's tape and re-tighten.
Difficulty Adjusting Temperature	Issue with ceramic cartridge.	Consult a plumber for cartridge inspection or replacement.

7. Specifications

Attribute	Value
Brand	Sensea
Model	NATU
Manufacturer Reference	74555033 - Duscharmatur NATU (AD)
Total Height	9.5 cm
Length	17.5 cm

Attribute	Value
Width	11.5 cm
Flow Rate	25.3 L/min
Minimum Required Flow	20 L/min
Ceramic Cartridge	40 mm
Material	Brass
Mounting Type	Wall-mounted
Hole Type	2 holes
Mounting Distance	150 mm
Connection	1/2 inch
Weight	0.83 kg

8. Warranty and Support

For warranty information, technical support, or to inquire about replacement parts, please contact Sensea customer service or the retailer where you purchased the product. Keep your proof of purchase for warranty claims.
For further assistance, please refer to the official Sensea website or contact their authorized service centers.

© 2024 Sensea. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question