Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sensea 81879124

Sensea Remix 2" Complete Rain Shower Set

Model: 81879124

INTRODUCTION

Thank you for choosing the Sensea Remix 2" Complete Rain Shower Set. This manual provides essential information for the safe installation, operation, and maintenance of your new shower system. Please read it thoroughly before installation and keep it for future reference.

This shower set is designed to provide a pleasant showering experience with a timeless design, compatible with all standard faucets (faucet not included).





Image: The Sensea Remix 2" Complete Rain Shower Set, showcasing the main shower column with rain shower head and hand shower in a chrome finish.

Safety Information

Please observe the following safety precautions to prevent injury or damage to the product:

- Ensure all connections are secure and watertight to prevent leaks.
- Do not use abrasive cleaners or harsh chemicals, as they may damage the chrome finish.
- Ensure the wall mounting is strong enough to support the weight of the shower system.
- Always turn off the main water supply before beginning installation or performing maintenance.
- If you are unsure about any part of the installation process, consult a qualified plumber.

Package Contents

Verify that all components are present before beginning installation:

- 1 x Complete Shower System (Shower column, Rain shower head, Hand shower, Hose)

- 1 x Mounting Material (Screws, wall plugs, gaskets)

Note: Faucet is not included.

Setup and Installation

Follow these steps for proper installation of your Sensea shower system:

1. **Preparation:** Turn off the main water supply. Clear the installation area.
2. **Mounting Height:** Determine the desired height for the shower column. The column height is adjustable from 75 cm to 115 cm. The minimum required ceiling height is 210 cm.
3. **Marking Drill Holes:** Position the shower column against the wall and mark the drill holes for the wall support. The fixing distance is 370 mm. The wall support is adjustable to adapt to existing holes.
4. **Drilling and Anchoring:** Drill holes at the marked positions and insert appropriate wall plugs.
5. **Attaching the Column:** Secure the shower column to the wall using the provided mounting material.
6. **Connecting Water Supply:** Connect the flexible hose (1.5m length, 1/2" inlet diameter) from your faucet (not included) to the shower column. The connection hose for faucets is 80 cm long. Ensure all connections are tight and sealed.
7. **Installing Shower Heads:** Attach the rain shower head and hand shower to their respective connections on the column. The hand shower holder is height-adjustable and integrated into the shower bar.
8. **Final Check:** Turn on the main water supply slowly and check for any leaks.




Image: Technical diagram illustrating the dimensions and installation points of the shower system, including adjustable column height (75-115 cm) and fixing distance (370 mm).



Image: Visual representation of key features, including universal compatibility with various water outlets, Easy Clean nozzles for the shower heads, and an integrated shelf for convenience.

Operating Instructions

Your Sensea shower system offers a versatile showering experience:

- **Rain Shower Head:**
  - The rectangular rain shower head measures 28 x 20 cm and is chrome-plated.
  - It is swivel-adjustable for optimal water coverage.
  - Water consumption at 3 bar: > 16 l/min with fully open jet (38°C).
- **Hand Shower:**

- The hand shower measures 25 x 8.5 cm and is chrome-plated.
- It features 3 adjustable spray functions for personalized showering.
- Water consumption at 3 bar: 9 to 12 l/min with fully open jet (38°C).
- The flexible hose is 1.5m long, smooth, made of PVC, and features an anti-twist design.

- **Integrated Shelf:** The shower system includes a convenient shelf for storing shower essentials.




Image: The hand shower demonstrating its three distinct spray modes, offering versatility for different showering preferences.



Image: Icons representing key features: adjustable height for both shower heads, Easy Clean nozzles, the 28x20 cm dimension of the rain shower head, and its swivel capability.

Maintenance

To ensure the longevity and appearance of your Sensea shower system, follow these maintenance tips:

- **Cleaning:** Clean the chrome surfaces regularly with a soft cloth and mild soap or a non-abrasive bathroom cleaner. Rinse thoroughly with water and dry to prevent water spots.
- **Easy Clean Nozzles:** The shower heads feature "Easy Clean" silicone nozzles. To remove limescale, simply rub the nozzles with your finger or a soft brush.
- **Avoid Harsh Chemicals:** Do not use abrasive sponges, scouring pads, or cleaners containing alcohol, ammonia, bleach, or phosphoric acid, as these can damage the finish.
- **Hose Care:** Periodically check the shower hose for kinks or damage. The anti-twist design helps prevent tangling.

Troubleshooting

If you encounter issues with your shower system, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Low water pressure from shower heads.	Clogged nozzles or mineral buildup.	Clean the "Easy Clean" nozzles by rubbing them. If persistent, check water supply lines for obstructions.
Leaks at connections.	Loose connections or worn gaskets.	Tighten connections. Replace gaskets if necessary. Ensure plumber's tape was used during installation.
Hand shower not switching modes.	Mineral buildup in the selector mechanism.	Soak the hand shower head in a descaling solution (e.g., vinegar and water) to dissolve mineral deposits.

If the problem persists after attempting these solutions, please contact Sensea customer support.

Specifications

Model Number	81879124
Product Dimensions	37 x 26 x 210 cm (assembled)
Weight	3.94 kg
Main Material	Stainless Steel (column), ABS Plastic (shower heads, handle), PVC (hose)
Finish Type	Polished Chrome
Rain Shower Head Dimensions	28 x 20 cm (rectangular)
Hand Shower Dimensions	25 x 8.5 cm
Hand Shower Functions	3 adjustable spray functions
Column Height Adjustment	75 cm to 115 cm
Fixing Distance	370 mm (adjustable wall support)
Hose Length	1.5 m (flexible, anti-twist PVC)
Connection Hose Length (to faucet)	80 cm
Water Consumption (Rain Shower)	> 16 l/min at 3 bar (38°C)
Water Consumption (Hand Shower)	9-12 l/min at 3 bar (38°C)

Warranty and Support

This Sensea product is manufactured to high-quality standards. For any questions regarding installation, operation, or maintenance, please contact Sensea customer support. Please retain your proof of purchase for warranty claims.
For further assistance, visit the official Sensea website or contact their customer service department.

© 2024 Sensea. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07QZ3KWNM

More documents and user manuals: **https://manuals.plus/**