

[Manuals.plus](#) /

› [JOLY JOY](#) /

› JOLY JOY Smart Floor Lamp User Manual

JOLY JOY Smart Floor Lamp (Model B07QZVQD15)

JOLY JOY Smart Floor Lamp User Manual

Model: B07QZVQD15

1. IMPORTANT SAFETY INSTRUCTIONS

Please read these instructions carefully before assembly and use. Keep this manual for future reference.

- **Electrical Safety:** Ensure the power supply matches the lamp's requirements. Do not use if the cord or plug is damaged. Unplug before cleaning or moving.
- **Placement:** Place the lamp on a stable, level surface to prevent tipping. Keep away from water and heat sources.
- **Children and Pets:** The weighted base helps prevent tipping, but always supervise children and pets around the lamp.
- **Bulb:** This lamp uses an integrated LED bulb designed for long life. Do not attempt to replace the LED module yourself.

2. PACKAGE CONTENTS

Verify that all components are present in the package:

- Lamp Base
- Lamp Pole Sections (typically 3-4 sections)
- Lampshade Frame and Fabric
- Smart LED Bulb (pre-installed or separate)
- Power Adapter with Foot Switch

3. ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your JOLY JOY Smart Floor Lamp:

1. Carefully unpack all components and lay them out on a clean, flat surface.
2. Screw the lowest lamp pole section into the lamp base, turning clockwise until secure.
3. Continue screwing the remaining lamp pole sections together, ensuring each connection is tight.
4. Attach the lampshade fabric to the lampshade frame. The fabric typically wraps around the frame and secures with Velcro or clips.
5. Carefully attach the assembled lampshade to the top lamp arm. Ensure it is centered and stable.

6. If the smart LED bulb is not pre-installed, screw it into the lamp's socket.



Image: The fully assembled JOLY JOY Smart Floor Lamp, showcasing its sleek design and beige lampshade.



Image: Diagram illustrating the dimensions of the JOLY JOY Smart Floor Lamp, including its height of 168cm and base diameter of 26cm.

4. INSTALLATION AND CONNECTION

4.1 Power Connection

Plug the power adapter into a standard wall outlet. The lamp features a convenient foot switch for basic on/off control.

4.2 Smart Control Setup (Smartphone App)

To unlock the full smart features, download the compatible smart home application (e.g., TuyaSmart or Smart Life) from your device's app store. Ensure your smartphone is connected to a 2.4GHz Wi-Fi network, as the lamp does not support 5GHz Wi-Fi.

1. Open the smart home app and register or log in.
2. Add a new device (usually by tapping a '+' icon). Select 'Lighting' or 'Lamp' from the device list.
3. Follow the in-app instructions to put the lamp into pairing mode (often by cycling the power switch a few times until

the light blinks rapidly).

4. Confirm your 2.4GHz Wi-Fi network and enter the password.
5. Wait for the app to connect to the lamp. Once connected, you can rename the device.



Image: A hand holding a smartphone displaying the smart bulb control interface, demonstrating how to control the lamp via the mobile application.

4.3 Voice Control Setup (Amazon Alexa)

After connecting the lamp to the smart home app, you can integrate it with Amazon Alexa for voice control:

1. Open the Amazon Alexa app.
2. Go to 'Skills & Games' and search for the smart home app you used (e.g., TuyaSmart or Smart Life).
3. Enable the skill and link your smart home app account.
4. Discover devices. Alexa should find your JOLY JOY Smart Floor Lamp.
5. You can now control the lamp with voice commands like: "Alexa, turn on the floor lamp" or "Alexa, set floor lamp brightness to 50%".

Voice Control

Easily control your lights directly through Alexa

Hi, alexa. Turn on the floor lamp

Okay~

Hi, alexa. Set floor lamp brightness to 100%

Okay~



Image: An illustration showing voice commands for Alexa to control the JOLY JOY Smart Floor Lamp, such as turning it on or adjusting brightness.

5. OPERATING INSTRUCTIONS

5.1 Basic Operation (Foot Switch)

The integrated foot switch allows for simple on/off control of the lamp.

5.2 Stepless Dimmable and Color Adjustment

Using the smartphone app, you can precisely control the lamp's brightness and color temperature:

- **Brightness:** Adjust from 1% to 100% to suit your needs.
- **Color Temperature:** Change from warm white to cool white.
- **RGB Colors:** Access over 16 million different colors for ambient lighting.
- **Memory Mode:** The lamp remembers your last brightness and color settings when turned off and on again.



Image: A visual representation of the stepless dimming and RGB color options available for the JOLY JOY Smart Floor Lamp, showing various light settings.

5.3 Advanced Features (App Control)

The app provides additional functionalities:

- **Timer Function:** Schedule the lamp to turn on or off at specific times.
- **Smart Scenes:** Create custom lighting scenes for different activities or moods.
- **Group Control:** If you have multiple JOLY JOY smart lights, group them for simultaneous control.

Features



Control via Smart phone(Android & IOS), you can control your light anywhere;



Voice control: Compatible with Alexa family and Google home



Timer function: Automatic on/off with timer function



16+ millions different color changeable



Brightness 1~100% dimmable



Smart scene and Group control



Image: An infographic listing key features of the JOLY JOY Smart Floor Lamp, including smartphone control, voice control, timer function, 16+ million colors, dimmable brightness, and smart scene control.

6. MAINTENANCE

To ensure the longevity and optimal performance of your lamp:

- **Cleaning:** Unplug the lamp before cleaning. Use a soft, dry cloth to wipe down the metal parts. For the lampshade, a soft, slightly damp cloth can be used, but avoid excessive moisture. Do not use abrasive cleaners or solvents.
- **Bulb:** The LED bulb is designed for long-term use (up to 50,000 hours) and is not user-replaceable.
- **Storage:** If storing the lamp, disassemble it carefully and store in its original packaging in a dry place.

7. TROUBLESHOOTING

If you encounter issues with your JOLY JOY Smart Floor Lamp, refer to the following:

Problem	Possible Cause	Solution
Lamp does not turn on.	No power; loose connection; faulty outlet.	Check power plug and outlet. Ensure all pole sections are tightly screwed.
Cannot connect to Wi-Fi.	Incorrect Wi-Fi band (5GHz); wrong password; lamp not in pairing mode.	Ensure your router is set to 2.4GHz or your phone is connected to the 2.4GHz band. Re-enter Wi-Fi password. Cycle lamp power to re-enter pairing mode.
App control is unresponsive.	Poor Wi-Fi signal; app glitch; lamp offline.	Check Wi-Fi signal strength. Restart the app. Unplug and replug the lamp to reset.
Voice control (Alexa) not working.	Alexa skill not enabled; account not linked; device not discovered.	Verify the smart home skill is enabled and linked in the Alexa app. Run device discovery in Alexa app.

If problems persist, please contact JOLY JOY customer support.

8. SPECIFICATIONS

- **Brand:** JOLY JOY
- **Model:** B07QZVQD15
- **Type of Bulb:** LED
- **Special Features:** Dimmable, Energy Efficient, Smart Control (Wi-Fi, Alexa compatible)
- **Material:** Metal (base), Plastic (shade)
- **Color:** Beige (shade)
- **Product Dimensions:** 26D x 26W x 168H Centimetres (approx. 65 inches height)
- **Item Weight:** 4.72 kg (approx. 11.9 pounds)
- **Power Source:** AC
- **Switch Style:** Push Button (foot switch)
- **Installation Method:** Freestanding

9. WARRANTY AND SUPPORT

The JOLY JOY Smart Floor Lamp comes with a**2-year warranty** from the date of purchase, covering manufacturing defects.

For technical support, warranty claims, or any questions regarding your product, please contact JOLY JOY customer service through the retailer's platform or the contact information provided on the official JOLY JOY website.

We are committed to your satisfaction and are happy to assist you with any issues.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question