

[Manuals.plus](#) /

› [Pomya](#) /

› Pomya Retro Classic Joystick Controller for Atari 2600 and 7800 Systems Instruction Manual

Pomya Pomyaon2wys6i94

Pomya Retro Classic Joystick Controller Instruction Manual

Model: Pomyaon2wys6i94

1. INTRODUCTION

This manual provides comprehensive instructions for the Pomya Retro Classic Joystick Controller. Designed for compatibility with classic gaming systems, this controller offers a traditional gaming experience. Please read this manual thoroughly to ensure proper setup and operation.

2. PACKAGE CONTENTS

- 1x Pomya Retro Classic Joystick Controller

3. PRODUCT FEATURES

- Advanced joystick controller with an operating button and a four-way joystick.
- Ergonomic design for comfortable grip.
- Constructed from wear-resistant materials for durability.
- No driver installation required for direct gameplay.

4. COMPATIBILITY

The Pomya Retro Classic Joystick Controller is suitable for all Atari 2600 systems. It is also compatible with the Atari 7800 console; however, please note that not all games designed for the Atari 7800 system are supported.

5. SETUP

To set up your Pomya Retro Classic Joystick Controller, follow these steps:

1. Locate the joystick port on your compatible gaming console (e.g., Atari 2600, Atari 7800).
2. Insert the controller's connector cable firmly into the joystick port.
3. Ensure the connection is secure before powering on your console.

An advanced joystick controller with an operating button
and a four-way joystick



The Pomya Retro Classic Joystick Controller, featuring a standard connector cable for console attachment.

6. OPERATING INSTRUCTIONS

The controller features a central joystick for directional input and a single action button for gameplay interaction.

- **Joystick:** Move the central stick in the desired direction (up, down, left, right, and diagonals) to control in-game movement.
- **Action Button:** Press the red button located on the controller's base to perform actions such as firing, jumping, or selecting, depending on the game.

Adopt ergonomic design, comfortable grip.

Suitable for all Atari 2600 systems, also compatible with Atari 7800 console (all games of Atari 7800 are not supported).



A user's hand comfortably gripping the joystick, highlighting its ergonomic design for extended gameplay.



An overhead perspective of the joystick controller, showing the central stick and the red action button.

7. MAINTENANCE AND CARE

To ensure the longevity and optimal performance of your controller:

- Keep the controller clean by wiping it with a soft, dry cloth. Avoid using harsh chemicals or abrasive cleaners.
- Store the controller in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid excessive force or dropping the controller, as this may damage internal components.

8. TROUBLESHOOTING

If you encounter issues with your Pomya Retro Classic Joystick Controller, consider the following:

- **Controller Not Responding:** Ensure the connector cable is fully and securely plugged into the console's joystick port. Try unplugging and re-plugging the controller.

- **Incorrect Input:** Verify that the game you are playing is compatible with a standard joystick controller. Some games may require specific controller types.
- **Intermittent Functionality:** Check the cable for any visible damage or kinks. If possible, test the controller on another compatible console or with a different game to isolate the issue.

9. SPECIFICATIONS

Model Number	Pomyaon2wys6i94
Product Dimensions	3.78 x 3.35 x 4.53 inches
Item Weight	6.7 ounces
Manufacturer	Pomya



The underside of the joystick controller, displaying its base and rubber feet for stability.

10. WARRANTY AND SUPPORT

For any questions or support regarding this product, please contact Pomya customer service. We are committed to providing quality service and will assist you with any issues you may encounter.
Please refer to your purchase documentation for specific warranty details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07R21XWDS>

More documents and user manuals: <https://manuals.plus/>