

AGV ISV7-1 SR

AGV ISV7-1 SR Internal Sunvisor Instruction Manual

INTRODUCTION

This manual provides essential instructions for the proper installation, operation, and maintenance of your AGV ISV7-1 SR Internal Sunvisor. Designed for specific AGV motorcycle helmets, this sunvisor enhances riding comfort by reducing glare during daytime use. Please read these instructions carefully before use to ensure optimal performance and safety.

The AGV ISV7-1 SR Internal Sunvisor is a replacement accessory compatible with AGV Sport Modular helmets. It is a smoke-tinted visor intended for daytime use only.

SETUP AND INSTALLATION

Proper installation of the internal sunvisor is crucial for its functionality and your safety. Follow these steps carefully:

1. **Prepare Your Helmet:** Ensure your AGV Sport Modular helmet is clean and free of debris.
2. **Locate Sunvisor Mechanism:** Identify the internal sunvisor mechanism within your helmet. This typically involves small attachment points or clips near the forehead area.
3. **Align the Sunvisor:** Carefully align the AGV ISV7-1 SR sunvisor with the helmet's internal mechanism. The sunvisor has specific attachment tabs or pins designed to fit into corresponding slots in the helmet.
4. **Secure the Sunvisor:** Gently but firmly press the sunvisor into place until you hear or feel it click securely into the attachment points. Do not force the sunvisor, as this may cause damage.
5. **Test Functionality:** Once installed, operate the sunvisor's deployment and retraction mechanism several times to ensure it moves smoothly and locks securely in both the up and down positions.

If you encounter any resistance or difficulty during installation, refer to your helmet's specific user manual or consult an authorized AGV dealer.



Image: The AGV ISV7-1 SR Internal Sunvisor, shown in its smoke-tinted form. This image displays the curved shape and attachment points of the sunvisor, which is designed to fit inside compatible AGV motorcycle helmets.

OPERATING INSTRUCTIONS

The AGV ISV7-1 SR Internal Sunvisor is designed for ease of use during your ride.

- **Deployment:** To deploy the sunvisor, locate the control lever or slider on the side or bottom edge of your helmet. Move the lever or slider to the 'down' position to lower the sunvisor into your field of vision.
- **Retraction:** To retract the sunvisor, move the control lever or slider to the 'up' position. The sunvisor will retract fully into the helmet shell.

Important Safety Notice: The AGV ISV7-1 SR Internal Sunvisor is a smoke-tinted visor and is intended for **DAY TIME USE ONLY**. Do not use this sunvisor in low-light conditions, at night, or in adverse weather conditions where visibility is reduced, as this can impair your vision and compromise safety.

MAINTENANCE AND CARE

Proper care will extend the life and maintain the clarity of your AGV ISV7-1 SR Internal Sunvisor.

- **Cleaning:** The sunvisor should be cleaned with a soft, damp cloth and mild soap or a specialized helmet visor cleaner. **Hand Wash Only.** Avoid abrasive materials or harsh chemicals, as these can scratch or damage the tint and surface coating.
- **Drying:** Allow the sunvisor to air dry completely or gently pat it dry with a clean, soft microfiber cloth.
- **Inspection:** Regularly inspect the sunvisor for scratches, cracks, or any signs of damage. A damaged sunvisor can impair vision and should be replaced immediately.
- **Storage:** When not in use, ensure the sunvisor is retracted into the helmet to protect it from accidental damage or scratches. Store the helmet in a protective bag or case.

TROUBLESHOOTING

If you experience issues with your AGV ISV7-1 SR Internal Sunvisor, consider the following common solutions:

- **Sunvisor Not Deploying/Retracting Smoothly:**
 - Check for obstructions: Ensure no debris or helmet lining is blocking the sunvisor's path.
 - Verify installation: Re-check that the sunvisor is correctly seated in its attachment points.
 - Clean mechanism: Dust or dirt in the mechanism can cause stiffness. Gently clean around the pivot points.
- **Scratches or Reduced Clarity:**
 - If scratches are significant and impair vision, the sunvisor should be replaced. Minor scratches can sometimes be polished with specialized visor scratch removers, but this is not guaranteed.
- **Sunvisor Detaches:**
 - Re-install the sunvisor, ensuring all attachment points are securely engaged. If it repeatedly detaches, the attachment mechanism in the helmet or on the sunvisor may be damaged, requiring professional inspection.

For persistent issues, contact AGV customer support or an authorized AGV service center.

SPECIFICATIONS

Product Name	AGV ISV7-1 SR Internal Sunvisor
Brand	AGV
Item Model Number	20KV28IEN1002
Product Dimensions	9 x 5 x 5 inches
Item Weight	7.04 ounces
Care Instructions	Hand Wash Only
Fit Type	Vehicle Specific Fit (AGV Sport Modular Helmets)
Pattern	Solid

WARRANTY AND SUPPORT

For information regarding warranty coverage for your AGV ISV7-1 SR Internal Sunvisor, please refer to the warranty documentation provided with your original helmet purchase or visit the official AGV website. Warranty terms and conditions may vary.

If you require technical assistance, have questions about installation, or need to report a defect, please contact AGV customer support through their official website or an authorized AGV dealer. Ensure you have your product model number (ISV7-1 SR or 20KV28IEN1002) and purchase details available when contacting support.

