

[Manuals.plus](#) /

> [ReadyWired](#) /

> ReadyWired Power Cord Cable User Manual

ReadyWired KDL-46EX710, KDL-46EX711, KDL-46HX800, KDL-52EX700

ReadyWired Power Cord Cable User Manual

For Sony KDL-46EX710, KDL-46EX711, KDL-46HX800, KDL-52EX700

PRODUCT OVERVIEW

The ReadyWired Power Cord Cable is designed to provide reliable power connectivity for compatible Sony television models. This 6-foot cable ensures guaranteed compatibility and is an essential accessory for your entertainment setup.



This image displays the ReadyWired Power Cord Cable. It features a standard two-prong (Type A) plug on one end for connecting to a wall outlet and a two-slot (C7) connector on the other end for connecting to compatible electronic devices, such as Sony TVs. The cable is black and coiled for display.

IMPORTANT SAFETY INFORMATION

- Always ensure the power cord is fully inserted into both the wall outlet and the device.
- Do not use the cord if it is damaged, frayed, or has exposed wires.

- Avoid placing heavy objects on the cord or kinking it sharply.
- Keep the cord away from water and heat sources.
- Disconnect the power cord from the outlet before cleaning the device or if it will be unused for an extended period.

SETUP

1. Ensure your Sony TV and the power outlet are turned off.
2. Locate the power input port on your Sony TV. This is typically a two-slot (figure-8) receptacle.
3. Insert the two-slot end of the ReadyWired Power Cord Cable firmly into the power input port of your Sony TV.
4. Insert the two-prong plug end of the ReadyWired Power Cord Cable into a standard wall electrical outlet.
5. Once connected, you may turn on your Sony TV.

OPERATING

The ReadyWired Power Cord Cable functions as a direct power supply for your compatible Sony television. Once properly connected, it provides the necessary electrical current for the device to operate. No further user interaction is required for its operation beyond initial connection.

MAINTENANCE

To ensure the longevity and safe operation of your power cord, follow these maintenance guidelines:

- **Cleaning:** Wipe the cord with a dry, soft cloth. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, coil the cord loosely. Avoid tight coiling or kinking, which can damage the internal wires.
- **Inspection:** Periodically inspect the cord for any signs of damage, such as cuts, fraying, or discoloration. If damage is observed, discontinue use immediately and replace the cord.
- **Environment:** Keep the cord in a dry environment, away from extreme temperatures and direct sunlight.

TROUBLESHOOTING

If you experience issues with your device's power, refer to the following common troubleshooting steps:

Issue	Solution
No Power to Device	<p><i>Check Connections:</i> Ensure both ends of the power cord are securely plugged into the device and the wall outlet.</p> <p><i>Test Outlet:</i> Plug another device into the same wall outlet to confirm the outlet is functioning.</p> <p><i>Inspect Cord:</i> Examine the power cord for any visible damage. If damaged, replace it.</p> <p><i>Device Power Button:</i> Ensure the device's power button is pressed or switched on.</p>
Intermittent Power	<p><i>Secure Connections:</i> Re-seat both ends of the power cord to ensure a snug fit.</p> <p><i>Avoid Overloading:</i> Ensure the outlet is not overloaded with other high-power devices.</p>

SPECIFICATIONS

Brand	ReadyWired
Length	6 Ft.
Connector Gender	Male-to-Female
Voltage	120 Volts (AC)
Plug Format (Wall)	Type B (Standard US 2-prong)
Appliance Connector	C7 (Figure-8)
Item Weight	2.39 ounces
Package Dimensions	6 x 1 x 0.9 inches
Compatible Models	Sony KDL-46EX710, KDL-46EX711, KDL-46HX800, KDL-52EX700

WARRANTY INFORMATION

This ReadyWired Power Cord Cable is typically covered by a manufacturer's warranty. For specific details regarding warranty duration and terms, please refer to the product packaging or contact ReadyWired customer support. Amazon's return policy for this product allows for a refund or replacement within 30 days of purchase.

CUSTOMER SUPPORT

For further assistance, technical support, or warranty inquiries, please contact ReadyWired directly.

You may also refer to the product listing on [Amazon.com](https://www.amazon.com) for additional information or to contact the seller, River City Electronics.

© 2025 ReadyWired. All rights reserved.