

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [ReadyWired](#) /

› **ReadyWired Power Cord Instruction Manual for Panasonic Technics SA-GX530, SA-GX550, SA-GX650, SA-GX670 Stereo Receivers**

ReadyWired SA-GX530, SA-GX550, SA-GX650, SA-GX670

ReadyWired Power Cord Instruction Manual

FOR PANASONIC TECHNICS SA-GX530, SA-GX550, SA-GX650, SA-GX670 STEREO RECEIVERS

Model: Universal AC Power Cord (6 ft)

Introduction

This manual provides instructions for the safe and proper use of your ReadyWired Power Cord. This power cord is designed to provide reliable power to compatible Panasonic Technics Stereo Receivers, specifically models SA-GX530, SA-GX550, SA-GX650, and SA-GX670.

Important Safety Information

- Read all instructions before use.
- Do not expose the power cord to water or excessive moisture.
- Do not use the power cord if it is damaged. Inspect for cuts, fraying, or bent prongs.
- Ensure the power outlet matches the voltage requirements of your stereo receiver.
- Always grasp the plug, not the cord, when disconnecting from an outlet.
- Keep out of reach of children and pets.

Setup: Connecting Your Power Cord

1. **Inspect the Power Cord:** Before connecting, visually inspect the ReadyWired Power Cord for any signs of damage, such as cuts, fraying, or bent prongs. Do not use if damaged.
2. **Locate the Power Inlet:** Identify the power inlet port on the back of your Panasonic Technics SA-GX530, SA-GX550, SA-GX650, or SA-GX670 Stereo Receiver. This is typically a two-prong (IEC C7) or three-prong (IEC C13) receptacle. The ReadyWired cord is a standard two-prong polarized or non-polarized cord, compatible with many receivers.
3. **Connect to Receiver:** Align the connector end of the ReadyWired Power Cord with the power inlet on your stereo receiver. Gently push the connector firmly into the inlet until it is fully seated.
4. **Connect to Power Outlet:** Plug the other end of the ReadyWired Power Cord into a standard electrical wall outlet. Ensure the outlet is easily accessible.
5. **Verify Connection:** Confirm that both ends of the power cord are securely connected.



Image: The ReadyWired power cord, showing its two-prong connector designed for compatible stereo receivers.

Operating: General Use

Once the ReadyWired Power Cord is securely connected to both your Panasonic Technics Stereo Receiver and a power outlet, your receiver is ready to be powered on according to its own operating instructions.

- **Power On/Off:** Use the power button on your stereo receiver to turn it on or off. The power cord simply supplies the necessary electrical current.
- **Unplugging:** To disconnect power, always grasp the plug firmly and pull it straight out from the wall outlet. Do not pull on the cord itself.

Maintenance: Care and Storage

- **Cleaning:** Wipe the power cord with a dry, soft cloth if it becomes dusty. Do not use liquid cleaners.
- **Storage:** When not in use, coil the power cord loosely. Avoid tight coiling or kinking, which can damage the internal wires. Store in a cool, dry place away from direct sunlight.
- **Inspection:** Periodically inspect the cord for any signs of wear or damage. Replace immediately if damage is found.

Troubleshooting: Common Issues

Problem	Possible Cause	Solution
No power to receiver	Cord not fully plugged in	Ensure both ends of the cord are securely connected.
No power to receiver	Wall outlet is not active	Test the wall outlet with another device or check your circuit breaker.
No power to receiver	Damaged power cord	Inspect the cord for damage. Replace if necessary.
Receiver not turning on	Receiver's internal issue	Consult your Panasonic Technics receiver's manual for troubleshooting its power functions.

Specifications

- **Brand:** ReadyWired
- **Length:** 6 Feet (1.8 meters)
- **Color:** Black
- **Connector Type:** Male-to-Male (Standard AC power connector)
- **Compatibility:** Panasonic Technics SA-GX530, SA-GX550, SA-GX650, SA-GX670 Stereo Receivers
- **Usage:** Indoor/Outdoor (Note: Ensure receiver is also rated for outdoor use if applicable)

Warranty and Support

ReadyWired products are designed for reliability. For specific warranty details or support inquiries, please refer to the ReadyWired official website or contact your retailer. Keep your purchase receipt for warranty claims.

For technical support regarding your Panasonic Technics Stereo Receiver, please consult the receiver's original manufacturer documentation or support channels.