

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [ONIKUMA](#) /

› [ONIKUMA K1B Gaming Headset User Manual](#)

ONIKUMA K1B

ONIKUMA K1B Gaming Headset User Manual

Model: K1B

INTRODUCTION

Thank you for choosing the ONIKUMA K1B Gaming Headset. This manual provides detailed instructions for setting up, operating, and maintaining your headset to ensure optimal performance and longevity. Please read this manual carefully before use.

PACKAGE CONTENTS

- 1 x ONIKUMA K1B Gaming Headset
- 1 x Conversion Line (Y-splitter cable)
- 1 x User Manual

PRODUCT OVERVIEW

The ONIKUMA K1B Gaming Headset is designed for an immersive gaming experience, featuring comfortable over-ear cups, an omnidirectional microphone, and LED lighting. It is compatible with various gaming consoles, including PS4 and Xbox One.



Figure 1: Front-side view of the ONIKUMA K1B Gaming Headset with its omnidirectional microphone extended. The headset features a camouflage design and comfortable ear cushions.



Figure 2: Angled view of the ONIKUMA K1B Gaming Headset, showing the camouflage pattern and the microphone in a retracted position. The headset is designed for over-ear comfort.

SETUP INSTRUCTIONS

1. Connect to Device:

- For devices with a single 3.5mm audio jack (e.g., most laptops, newer controllers): Plug the 3.5mm jack directly into your device's audio port.
- For devices with separate audio and microphone jacks (e.g., older PCs): Use the included conversion line (Y-splitter cable) to connect the headset's 3.5mm jack to the separate audio and microphone ports on your device.

- For LED lighting: Plug the USB connector into an available USB port on your device (PC, console, or USB power adapter) to power the headset's LED lights. The USB connection is for lighting only, not for audio.

- Adjust Headset Fit:** Extend or retract the headband to comfortably fit your head. Ensure the ear cups fully cover your ears for optimal sound isolation and comfort.
- Position Microphone:** Adjust the flexible omnidirectional microphone to a suitable distance from your mouth for clear voice capture.
- Configure Audio Settings:** After connecting, navigate to your device's audio settings to ensure the ONIKUMA K1B headset is selected as the default output and input device. Adjust volume levels as needed.

OPERATING INSTRUCTIONS

- Volume Control:** The headset features an in-line volume control wheel on the cable. Rotate the wheel to increase or decrease the audio volume.
- Microphone Mute:** An in-line switch allows you to quickly mute or unmute the microphone. Ensure the microphone is unmuted when you wish to communicate.
- LED Lighting:** The LED lights activate automatically when the USB cable is connected to a powered USB port. There is no separate switch for the LED lights.
- Noise Control:** The headset incorporates noise control features. For optimal performance, ensure the ear cups are properly seated over your ears.

MAINTENANCE

- Cleaning:** Use a soft, dry cloth to clean the headset. For ear cushions, gently wipe with a slightly damp cloth if necessary, then dry thoroughly. Do not use harsh chemicals or abrasive cleaners.
- Storage:** Store the headset in a cool, dry place away from direct sunlight and extreme temperatures. Avoid placing heavy objects on the headset.
- Cable Care:** Avoid sharp bends or excessive pulling on the cables. Always grasp the plug, not the cable, when disconnecting.
- Water Resistance:** While the product description mentions "Waterproof", it is generally recommended to avoid exposing electronic devices to liquids. Protect the headset from spills and moisture to prevent damage.

TROUBLESHOOTING

Problem	Possible Solution
No sound from headset	<ul style="list-style-type: none">Ensure the 3.5mm jack is fully inserted into the device.Check the in-line volume control and increase the volume.Verify device audio settings to ensure the headset is selected as the output device.Test the headset on another device to rule out device-specific issues.

Problem	Possible Solution
Microphone not working	<ul style="list-style-type: none"> Ensure the microphone mute switch on the cable is in the "unmute" position. Verify device audio settings to ensure the headset microphone is selected as the input device. If using the Y-splitter, ensure it is correctly connected to both mic and audio ports. Check for any software-based microphone privacy settings on your device.
LED lights not working	<ul style="list-style-type: none"> Ensure the USB cable is securely plugged into a powered USB port. Try a different USB port or power source.

SPECIFICATIONS

Feature	Detail
Model	K1B
Speaker Diameter	50mm
Impedance	20Ω ± 15%
Sensitivity	117dB ± 3dB
Frequency Range	20-20000Hz
Mic Dimension	6.0mm x 2.7mm
Mic Sensitivity	-36dB ± 1dB
Mic Impedance	2.2kΩ
Directivity	Omni-directional
LED Working Voltage	DC5V ± 5%
Working Current	Below 100mA
Headset Interface	USB (for LED) + 3.5mm Stereo Audio and Mic Plug
Cable Length	2.2m
Material	Plastic
Compatible Devices	Gaming Consoles (PS4, Xbox One), PC, etc.
Noise Control	Active Noise Cancellation

WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the documentation provided at the time of purchase or contact your retailer. For technical

support or further assistance, please reach out to the product seller or manufacturer's customer service. Extended warranty options may be available from third-party providers. Please check with your retailer for details on such offerings.

© 2024 ONIKUMA. All rights reserved.