SQ-200

Generic LF SQ200 Portable Quran Speaker User Manual

Model: SQ-200

1. Introduction

The Generic LF SQ200 is a versatile portable speaker designed to provide a comprehensive Quran listening experience. It features full Quran audio recitation, translation audio, Ayah by Ayah and word by word recitation, an MP3 player, FM radio, and voice recording capabilities. Its compact design, remote control operation, and rechargeable battery make it ideal for personal use, travel, or educational purposes.

Please read this manual carefully before using the device to ensure proper operation and to maximize its features.

2. Product Overview

2.1 Key Features

- Complete Quran Audio Recitation (various Qaris)
- Quran Translation Audio (multiple languages)
- Ayah by Ayah and Word by Word Recitation
- MP3 Player Functionality
- FM Radio
- Voice Recording
- Infrared Remote Control
- Micro SD Card Support (4GB/8GB included)
- USB Rechargeable Battery
- Compact and Portable Design

2.2 Package Contents

Upon unpacking, please ensure all items listed below are present and in good condition:



Figure 1: The LF SQ200 package contents, showing the portable speaker, remote control, USB charging cable, user manual, and two power adapters.

- LF SQ200 Portable Quran Speaker
- Remote Control
- USB Charging Cable
- Micro SD Card (pre-installed or separate)
- Power Adapter(s)
- User Manual (this document)

2.3 Component Identification

Familiarize yourself with the various buttons and ports on your LF SQ200 speaker and its remote control.




Figure 2: Front and back view of the LF SQ200 speaker, highlighting the volume controls, ON/OFF switch, LED indicator, IR receiver, TF card slot, microphone port, and DC5V charging port.

1. **+ VOLUME -:** Volume Up/Down buttons.
2. **ON/OFF:** Power switch for the speaker.
3. **LED:** Indicator light for power and charging status.
4. **IR:** Infrared receiver for the remote control.
5. **TF:** Micro SD card slot.
6. **MIC:** Microphone port (for voice recording).
7. **DC5V:** USB charging port.



Figure 3: The LF SQ200 speaker and its remote control, showing their relative sizes and button layout on the remote.

The remote control features dedicated buttons for power, volume, play/pause, mode selection (Quran, MP3, FM), Surah selection, Qari selection, translation toggling, and other functions. Refer to the remote's labels for specific button actions.

3. Setup

3.1 Charging the Speaker

1. Connect the small end of the USB charging cable to the **DC5V** port on the speaker.
2. Connect the larger end of the USB cable to the provided power adapter.
3. Plug the power adapter into a standard wall outlet.
4. The **LED** indicator will illuminate to show charging status. It will change color or turn off when fully charged.
5. A full charge typically takes 2-3 hours.

3.2 Inserting the Micro SD Card

The Micro SD card containing the Quran audio and other files is usually pre-installed. If not, or if you wish to replace it:

1. Locate the **TF** card slot on the side of the speaker.
2. Gently insert the Micro SD card into the slot with the gold contacts facing down (or as indicated by a small icon next to the slot) until it clicks into place.
3. To remove, push the card in slightly until it springs out.

3.3 Powering On/Off

- To power on the speaker, slide the **ON/OFF** switch to the 'ON' position. The LED indicator will light up.
- To power off, slide the **ON/OFF** switch to the 'OFF' position. The LED indicator will turn off.

4. Operating Instructions

4.1 Basic Playback and Volume Control

- Once powered on, the speaker will typically resume playback from where it last stopped or start in Quran mode.
- Use the **+ VOLUME -** buttons on the speaker or the volume buttons on the remote control to adjust the sound level.
- Press the **Play/Pause** button on the remote to pause or resume playback.

4.2 Mode Selection

Press the **MODE** button on the remote control to switch between different functions:

- **Quran Mode:** For listening to Quran recitations and translations.
- **MP3 Mode:** For playing general audio files stored on the Micro SD card.
- **FM Radio Mode:** For listening to local FM radio stations.

4.3 Quran Mode Functions

- **Surah Selection:** Use the numbered buttons (1-6) or dedicated Surah buttons on the remote to select a specific Surah. You may also use the navigation buttons to move to the next/previous Surah.
- **Qari Selection:** Press the **QARI** button to cycle through available reciters.
- **Translation:** Press the **TRANSLATIONS** button to toggle the translation audio on or off. You may also be able to select different translation languages.
- **Ayah by Ayah / Word by Word:** Some models support specific buttons or combinations to enable Ayah by Ayah or word by word recitation. Refer to the remote's specific labels.

4.4 MP3 Mode Functions

- In MP3 mode, the speaker will play audio files from the Micro SD card.
- Use the navigation buttons on the remote to skip to the next or previous track.
- The **Play/Pause** button functions as usual.

4.5 FM Radio Mode Functions

- In FM Radio mode, press the **FM** button (often labeled with a radio icon) to activate the radio.
- Press and hold the Play/Pause button to automatically scan and save available FM stations.
- Use the navigation buttons to switch between saved stations.

4.6 Voice Recording

If your model supports voice recording (indicated by a MIC port):

1. Ensure a Micro SD card is inserted.
2. Switch to the recording mode (if available via a dedicated button or mode selection).
3. Press the record button (often a red dot or REC) to start recording.
4. Speak clearly into the **MIC** port.

5. Press the record button again to stop and save the recording.
6. Recordings are typically saved as MP3 files on the Micro SD card.

5. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Do not use liquid cleaners or abrasive materials.
- **Battery Care:** To prolong battery life, avoid fully discharging the speaker frequently. Charge it regularly, even if not in use for extended periods.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Exposure:** Although listed as "Waterproof" in some specifications, it is generally recommended to avoid exposing electronic devices to water to prevent damage.

6. Troubleshooting

6.1 No Power

- Ensure the **ON/OFF** switch is in the 'ON' position.
- Check if the battery is charged. Connect the speaker to a power source using the USB cable and adapter.

6.2 No Sound

- Increase the volume using the **+ VOLUME -** buttons or the remote.
- Ensure the speaker is not muted.
- If playing from the Micro SD card, ensure the card is properly inserted and contains valid audio files.

6.3 Remote Control Not Working

- Ensure there are no obstructions between the remote and the speaker's **IR** receiver.
- Check the remote control's battery and replace if necessary.
- Point the remote directly at the speaker's IR receiver.

6.4 FM Radio Reception is Poor

- Move the speaker to a different location, preferably near a window, to improve signal reception.
- Perform an auto-scan again to find stronger signals.

7. Specifications

Brand	Generic
Model Name	SQ-200
Connectivity Technology	USB
Speaker Type	Portable

Power Source	Battery Powered
Built-In Media	Remote Control, Micro SD Card (4GB/8GB)
Control Method	Remote Control, Voice Control
Color	Gold
Is Waterproof	TRUE
Dimensions (Speaker)	Approx. 2.35" (Diameter) x 2.5" (Height)
Dimensions (Remote)	Approx. 1.55" (Width) x 3.4" (Height) x 0.3" (Thickness)
UPC	192132714297

8. Warranty and Support

This product comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package or contact your retailer for specific details regarding warranty coverage and duration.

For technical assistance, troubleshooting, or further inquiries, please contact the seller or the manufacturer directly. Contact information can usually be found on the product packaging or the seller's website.

9. Important Safety Information

- Do not expose the device to extreme temperatures or humidity.
- Do not attempt to disassemble or repair the device yourself. This will void the warranty.
- Keep out of reach of children.
- Use only the provided charging cable and adapter.
- Dispose of the battery and device according to local regulations.

© 2023 Generic. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why do my SQ-200 Portable Quran Speakers stop producing sound after several hours of continuous playback, and how can I fix this issue?

Based on the manual for the Generic SQ-200 Portable Quran Speaker, there is no specific mention of a known firmware bug for long-duration playback. However, since the issue occurs on two separate units after...

Read full answer