

[Manuals.plus](#) /

› [Sweety Fox](#) /

› Sweety Fox Q1 Evolutive High Chair Instruction Manual - Dark Grey

Sweety Fox Q1

Sweety Fox Q1 Evolutive High Chair Instruction Manual

Model: Q1 | Brand: Sweety Fox

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your Sweety Fox Q1 Evolutive High Chair. Please read all instructions carefully before assembly and use, and retain this manual for future reference. The high chair is designed for children from 6 months up to 3 years, with a maximum weight capacity of 15 kg.

2. SAFETY INFORMATION

Your Sweety Fox Q1 High Chair is certified according to EN 14988 standards, ensuring high safety. Adhere to the following safety guidelines:

- Always secure your child with the 5-point safety harness.
- Never leave your child unattended in the high chair.
- Ensure the high chair is placed on a stable, flat surface.
- Do not use the high chair if any parts are damaged or missing.
- The maximum weight capacity for this high chair is 15 kg.
- The tray is made from BPA-free plastic.

3. PACKAGE CONTENTS

The Sweety Fox Q1 Evolutive High Chair package includes:

- 1 x Sweety Fox Q1 High Chair (main unit with seat cushion)
- 1 x Removable Tray with plastic insert
- 1 x Play Bar with hanging toys

4. SETUP AND ASSEMBLY

The Sweety Fox Q1 High Chair is designed for easy setup. Follow these steps to prepare your high chair for use:

4.1 Unfolding the High Chair

To unfold the high chair from its compact storage position:

1. Hold the high chair by the handles at the top of the frame.
2. Press the release buttons on the side of the frame (as shown in the video) and gently pull the legs apart until they lock into place.
3. Ensure all four legs are fully extended and locked before use.



Figure 4.1: High chair in folded position and being carried.

4.2 Attaching the Tray

The tray can be easily attached and removed:

1. Align the tray with the armrests of the high chair.
2. Slide the tray onto the armrests until it clicks into place.
3. To remove, press the release buttons on the underside of the tray and pull it forward.
4. The tray features a removable plastic insert for easy cleaning.

Plateau amovible et pratique




Figure 4.2: Removable and adjustable tray.

4.3 Attaching the Play Bar

To attach the play bar:

1. Locate the attachment points on the high chair's armrests.
2. Insert the play bar into these slots until it is securely fastened.

Arche bébé inclus



Figure 4.3: Play bar with toys attached.

4.4 Assembly Video Guide

For a visual guide on assembly and adjustments, please watch the following video:

Your browser does not support the video tag.

Video 4.4: Demonstrates unfolding, height adjustment, tray attachment, and harness use.

5. OPERATING THE HIGH CHAIR

The Sweetie Fox Q1 High Chair offers multiple adjustments for your child's comfort and safety.

5.1 Adjusting Seat Height

The high chair features 7 different height positions:

1. Locate the height adjustment buttons on the side of the main frame.
2. Press the buttons and slide the seat unit up or down to your desired height.
3. Release the buttons and ensure the seat locks securely into position.

Chaise haute évolutive

6-36
mois




Figure 5.1: High chair adjustability features.

5.2 Adjusting Backrest Recline

The backrest can be adjusted to 5 reclining positions, allowing use as a bouncer for younger infants:

1. Locate the recline lever at the back of the seat.
2. Pull the lever and adjust the backrest to one of the 5 available positions.
3. Release the lever and ensure the backrest is securely locked.

5.3 Adjusting Footrest

The footrest has 3 adjustable positions for your child's comfort:

1. Locate the footrest adjustment mechanism beneath the footrest.
2. Adjust to the desired position and ensure it clicks into place.

5.4 Using the 5-Point Harness

Always secure your child with the 5-point harness for safety:

1. Place your child in the seat.
2. Bring the shoulder straps over your child's shoulders and the waist straps around their waist.

3. Connect the two waist buckles to the central buckle.
4. Adjust the straps to ensure a snug, secure fit without being too tight.



Figure 5.4: 5-point safety harness and rear wheels.

5.5 Folding for Storage

To fold the high chair for compact storage:

1. Ensure the tray is removed.
2. Press the folding release buttons (refer to video for exact location) and push the legs together.
3. The high chair will fold into a compact, freestanding unit.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures hygiene and extends the life of your high chair.

6.1 Cleaning the Tray

The removable plastic tray insert is dishwasher safe for convenient cleaning.

Nettoyage simplifié



Résiste au
lave-vaisselle



Figure 6.1: Dishwasher-safe tray insert.

6.2 Cleaning the Seat Cushion

The polyurethane seat cushion can be easily wiped clean with a damp cloth and mild soap. Do not machine wash or tumble dry the cushion.

6.3 Frame Cleaning

Wipe the high chair frame with a damp cloth. Avoid abrasive cleaners.

7. TROUBLESHOOTING

If you encounter any issues with your Sweety Fox Q1 High Chair, please refer to the following common solutions:

- **Chair not unfolding/folding smoothly:** Ensure all release buttons are fully pressed and there are no obstructions. Check that the legs are aligned correctly.
- **Tray not attaching/detaching:** Verify that the tray is aligned with the armrests and the release buttons are fully engaged/disengaged.
- **Harness not securing:** Check that all buckle components are correctly inserted and the straps are adjusted to the appropriate length for your child.

For further assistance, please contact Sweety Fox customer support.

8. SPECIFICATIONS

Feature	Detail
Model Number	Q1
Maximum Supported Weight	15 kg
Main Material	Polyurethane
Age Range	6 months - 3 years
Seat Height Positions	7
Backrest Recline Positions	5
Footrest Positions	3
Safety Harness	5-point
Tray Features	Removable, BPA-free, dishwasher safe insert
Portability	Foldable design
Product Dimensions (L x W x H)	103 x 71 x 52 cm
Product Weight	9.34 kg

9. WARRANTY AND SUPPORT

Sweety Fox offers a 30-day satisfaction guarantee for this product. If you have any questions or require assistance, please contact our customer support team. We aim to respond to all inquiries within 24 hours.