

[Manuals.plus](#) /

› [JARDLITE](#) /

› JARDLITE L1000 LED Emergency Handheld Flashlight User Manual

JARDLITE L1000

JARDLITE L1000 LED Emergency Handheld Flashlight User Manual

Model: L1000

INTRODUCTION

Thank you for choosing the JARDLITE L1000 LED Emergency Handheld Flashlight. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your flashlight. Please read these instructions thoroughly before use and retain them for future reference.



Image: Four JARDLITE L1000 LED flashlights.

PRODUCT OVERVIEW

Components Included (4-pack variant)

- 4x JARDLITE L1000 LED Tactical Flashlights
- 2x AAA Battery Holders (for using AAA batteries)
- 4x Rechargeable Battery Tubes (for using 18650 batteries)
- 4x Hand Straps
- 2x Operation Guides

Key Features

- **Adjustable Focus:** Transition between spotlight for long-distance illumination and floodlight for wide-area illumination.
- **Five Light Modes:** Includes 3 brightness levels (High, Medium, Low), Strobe, and SOS emergency modes.

- **High-Efficiency LED:** Provides bright illumination.
- **Durable Construction:** Military-grade aluminum alloy and steel with hard-anodized finish.
- **Water Resistant:** Designed to withstand water exposure.
- **Power Source Options:** Compatible with one 18650 Lithium-ion battery or three AAA batteries (batteries not included).



Image: Labeled diagram of the JARDLITE L1000 flashlight components.



Image: JARDLITE L1000 flashlight held in hand.

SETUP

Battery Installation

The JARDLITE L1000 flashlight can be powered by either one 18650 Lithium-ion battery or three AAA batteries. Batteries are not included.

1. **Unscrew the Tail Cap:** Rotate the tail cap counter-clockwise to remove it from the flashlight body.
2. **Insert Batteries:**
 - **For 18650 Battery:** Insert one 18650 Lithium-ion battery into the provided rechargeable battery tube with the positive (+) end facing towards the flashlight head.
 - **For AAA Batteries:** Place three AAA batteries into the provided AAA battery holder, ensuring correct polarity (+/-) as indicated on the holder. Then insert the holder into the flashlight body with the positive (+) end facing towards the flashlight head.
3. **Secure the Tail Cap:** Screw the tail cap back onto the flashlight body clockwise until it is firmly tightened. This ensures proper electrical contact and water resistance.

OPERATING INSTRUCTIONS

Power On/Off

- To turn the flashlight **ON**, press the power button located on the tail cap until it clicks.

- To turn the flashlight **OFF**, press the power button again until it clicks.

Mode Selection

The JARDLITE L1000 features five lighting modes: High, Medium, Low, Strobe, and SOS.

- With the flashlight ON, gently press the power button (half-press, without clicking) to cycle through the modes.
- The sequence is typically: High → Medium → Low → Strobe → SOS.
- To select a mode, release the button when the desired mode is active.



Image: Illustration of lighting modes, zoom function, and LED light source.

Focus Adjustment (Zoom Function)

The flashlight features an adjustable focus mechanism to change the beam type.

- To achieve a **spotlight** beam for long-distance illumination, pull the head of the flashlight outwards.

- To achieve a **floodlight** beam for wide-area illumination, push the head of the flashlight inwards.



Image: Comparison of floodlight and spotlight beams.

MAINTENANCE

Cleaning

- Wipe the flashlight body with a clean, soft cloth.
- For stubborn dirt, use a slightly damp cloth. Avoid harsh chemicals or abrasive cleaners.
- Keep the lens clean for optimal light output. Use a lens cleaning cloth if necessary.

Battery Care

- Remove batteries if the flashlight will not be used for an extended period to prevent leakage.
- Replace all AAA batteries simultaneously. Do not mix old and new batteries or different battery types.
- Ensure correct battery polarity during installation.

Storage

- Store the flashlight in a cool, dry place away from direct sunlight and extreme temperatures.
- Keep out of reach of children.

Water Resistant



Image: JARLITE L1000 flashlight demonstrating water resistance.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Flashlight does not turn on.	◦ Dead or low batteries. ◦ Incorrect battery installation (polarity). ◦ Loose tail cap.	◦ Replace batteries with fresh ones. ◦ Check and correct battery polarity. ◦ Tighten the tail cap securely.
Light is dim or flickers.	◦ Low battery power. ◦ Loose connections. ◦ Dirty battery contacts.	◦ Replace batteries. ◦ Ensure tail cap and battery tube are tightly screwed. ◦ Clean battery contacts with a cotton swab and rubbing alcohol.


Problem	Possible Cause	Solution
Cannot change light modes.	◦ Button not being half-pressed correctly.	◦ Ensure the flashlight is ON, then gently press the tail switch without fully clicking it.

SPECIFICATIONS


Brand	JARDLITE
Model	L1000
Light Source Type	LED
Brightness	250 Lumens
Power Source	Battery Powered (1x 18650 or 3x AAA, not included)
Voltage	3 Volts
Material	Alloy Steel / Anti-Slip Aluminum
Water Resistance Level	Waterproof
Special Features	Adjustable Light Modes, Drop Resistant, Durable, Weatherproof, Zoomable, Compact, Water Resistant
Product Dimensions (approx.)	3.94"D x 3.15"W x 5.51"H (This dimension might refer to the packaging or a single unit's extended state, please refer to product listing for precise individual unit dimensions if critical.)
Item Weight (approx.)	3.53 ounces (per flashlight)



Reading



Hiking



Camping



Exploring

Image: Various usage scenarios for the JARDLITE L1000 flashlight.

WARRANTY AND SUPPORT

Specific warranty information for the JARDLITE L1000 LED Emergency Handheld Flashlight is not provided in this manual. For details regarding warranty coverage, returns, or technical support, please refer to the product packaging, the retailer's website where the product was purchased, or contact JARDLITE customer service directly.

You may also visit the [JARDLITE Store on Amazon](#) for additional product information and support resources.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question