

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Globe Electric](#) /

› [Globe Electric 67136 72" Torchiere Floor Lamp with Adjustable Reading Light Instruction Manual](#)

Globe Electric 67136

Globe Electric 67136 72" Torchiere Floor Lamp with Adjustable Reading Light Instruction Manual

Model: 67136

Brand: Globe Electric

PRODUCT OVERVIEW

The Globe Electric 67136 72-inch Torchiere Floor Lamp offers a versatile lighting solution for your home. This two-in-one lamp provides both ambient uplighting and focused task lighting through its adjustable reading arm. Featuring a matte white finish and frosted shades, it blends seamlessly with various interior styles. Independent switches allow for separate control of each light, and the torchiere includes a three-step dimmer for customizable illumination.

Key Features

- Ambient & Task Lighting: Torchiere uplight for general illumination, adjustable reading arm for targeted light.
- Modern Minimalist Style: Matte white frame and clean lines complement contemporary, transitional, or industrial interiors.
- Adjustable Reading Arm: Pivoting light provides customizable direction for reading, working, or relaxing.
- Independent Switch Controls: Separate rotary switches for individual operation of torchiere and reading light.
- Bulb Compatibility: Designed for E26 base bulbs (sold separately), supporting LED, incandescent, or smart options.

PACKAGE CONTENTS

Please ensure all the following components are present before beginning assembly:

- Lamp Base
- Lamp Pole Sections (multiple, pre-wired)
- Torchiere Shade (frosted)
- Reading Light Shade (frosted)

- Adjustable Reading Light Arm
- Power Cord (integrated)
- Instruction Sheet

ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your Globe Electric floor lamp:

Step 1: Unpack Components

Carefully remove all components from the packaging. Place them on a flat, clean surface to ensure no parts are lost or damaged.

Step 2: Assemble the Lamp Pole

Connect the lamp pole sections by screwing them clockwise. As you connect each section, gently pull the power cord through the pole to prevent tangling and ensure a snug fit. Ensure all connections are secure.



Image: A fully assembled Globe Electric 72-inch Torchiere Floor Lamp with adjustable reading light, featuring a matte white finish and frosted shades, positioned in a modern bedroom setting.

Step 3: Attach the Base

Securely attach the assembled pole to the lamp base by screwing it clockwise until it is firm and stable. The base is weighted for stability.

Step 4: Attach Shades and Reading Light

Attach the frosted torchiere shade to the top lamp socket. Then, attach the frosted reading light shade to the adjustable arm. Ensure they are seated correctly.




Image: A close-up view of the lamp's upper section, highlighting the torchiere shade and the adjustable reading light with its individual on/off rotary switch.

Step 5: Install Light Bulbs

Insert the appropriate E26 base bulbs (sold separately) into both the torchiere and reading light sockets. Screw them in clockwise until snug.

Note on Bulb Compatibility:

- The torchiere requires 1x E26 Medium Base Bulb (150W maximum).
- The reading lamp requires 1x E26 Medium Base Bulb (40W maximum).
- Both bulbs are sold separately. The lamp supports LED, incandescent, or smart bulbs.

OPERATING YOUR LAMP

Your Globe Electric floor lamp is designed for ease of use with versatile lighting options.

Power Connection

Plug the lamp's power cord into a standard 120V electrical outlet. Ensure the outlet is functional.

Independent Switch Controls

The lamp features dual independent rotary switches, allowing you to control the torchiere and reading light separately.





Image: A close-up of the lamp's central pole, showing the torchiere's 3-step rotary dimmer switch and the reading lamp's on/off rotary switch for independent control.

Torchiere Light

The torchiere light is controlled by a 3-step rotary dimmer switch located on the main pole. Turn the switch clockwise to cycle through low, medium, and high light settings, then off.

Reading Light

The reading light has a simple on/off rotary switch located on its fixture. Turn the switch to turn the light on or off.

Adjustable Reading Arm

The reading light is attached to an adjustable gooseneck arm. Gently bend the arm to direct the light to your desired position for reading, crafting, or any other task requiring focused illumination.

CARE AND MAINTENANCE

Proper care will ensure the longevity and optimal performance of your lamp.

Cleaning

- Always unplug the lamp from the power outlet before cleaning.
- Wipe the metal frame with a soft, dry cloth to remove dust and fingerprints.
- Clean the frosted plastic shades with a soft, damp cloth and a mild, non-abrasive soap if necessary. Avoid harsh chemicals or abrasive materials that could scratch the surface.

Bulb Replacement

- Ensure the lamp is unplugged and the bulbs are completely cool before attempting to replace them.
- Unscrew the old bulb counter-clockwise from its socket.
- Screw in the new E26 base bulb clockwise until it is snug. Do not overtighten, as this can damage the socket or the bulb.

TROUBLESHOOTING

If you encounter any issues with your lamp, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Lamp does not light up.	Power cord not securely plugged in.	Ensure the power cord is firmly plugged into a functional 120V electrical outlet.
Lamp does not light up.	Bulb is loose or burnt out.	Check if the bulb is screwed in tightly. Replace the bulb if it is burnt out.
Lamp does not light up.	Rotary switch is in the 'off' position.	Turn the rotary switch to the desired 'on' setting (low, medium, or high for torchiere; on for reading light).
Light flickers.	Loose bulb or incompatible dimmer.	Tighten the bulb. If using a dimmable bulb, ensure it is compatible with the lamp's dimmer function.
Lamp is wobbly.	Pole sections or base not tightened.	Ensure all pole sections and the base are securely screwed together.

PRODUCT SPECIFICATIONS

Detailed specifications for the Globe Electric 67136 Torchiere Floor Lamp:




Image: Diagram showing the dimensions of the 72-inch floor lamp, including its height, base diameter (10 inches), and 6-foot cord length.

- Model Number: 67136

- Dimensions: 10"D x 10"W x 72.88"H
- Item Weight: 7.04 pounds
- Finish Type: Matte
- Base Material: Plastic
- Shade Material: Plastic
- Bulb Base: E26
- Torchiere Wattage: 150W Max (bulb sold separately)
- Reading Lamp Wattage: 40W Max (bulb sold separately)
- Switch Type: Rotary
- Power Source: Corded Electric
- Voltage: 120 Volts
- Indoor/Outdoor Usage: Indoor
- Special Feature: Dimmable (for torchiere)

WARRANTY AND SUPPORT

Warranty Information

This product comes with no warranty.

Customer Support

For further assistance, product inquiries, or to explore other Globe Electric products, please visit the official Globe Electric store:

[Globe Electric Store](#)