

AODELAN SRR-PEBBLE

AODELAN SRR-PEBBLE Wireless Camera Remote Control for Sony Cameras

Instruction Manual

INTRODUCTION

The AODELAN SRR-PEBBLE Wireless Camera Remote Control is designed to provide photographers with flexible control over their Sony cameras. This device supports both wireless and wired operation, enabling various shooting modes without direct camera interaction, thereby minimizing camera shake and enhancing creative possibilities.

PACKAGE CONTENTS

- AODELAN Wireless Shutter Remote Receiver x1
- AODELAN Wireless Shutter Remote Transmitter x1
- Connecting Cable x2
- CR2032 Battery x1 (for transmitter)
- Lanyard x1
- Instruction Manual x1

Note: 2 AAA batteries for the receiver are not included.



Image: AODELAN SRR-PEBBLE Wireless Remote Control showing the transmitter, receiver, connecting cables, and lanyard.

COMPATIBILITY

This remote control is compatible with a wide range of Sony Alpha and Cyber-shot cameras. Please ensure your camera model supports remote control functionality via a multi-terminal or specific remote port.

Compatible Sony Alpha Models:

- a9, a7, a7 II, a7 III, a7R, A7R V, a7R II, a7R III, a7S, a7S II, a6500, a6300, a6000, a5100, a5000, a3000, a77 II, a58

- a100, a200, a300, a350, a500, a550, a560, a580, a700, a850, a900
- a33, a35, a37, a55, a57, a65, a77, a77 II, a99, a99 II
- A7 IV, A7R IVA, A7R IIIA, A9 III, A1 II

Compatible Sony Cyber-shot Models:

- DSC-RX0, RX1R II, RX1R M2, RX10M2, RX10M3, RX10M4, RX10 IV, RX10 III, RX10 II, RX10, RX100 VI, RX100 VA, RX100 V, RX100 IV, RX100 III, RX100 II, RX100M2, RX100M3, RX100M4, RX100M5
- HX300, HX350, HX400V, HX400, HX50, HX60, HX90, HX90V, QX30, WX500
- ILCE-QX1, NEX-3N

Compatible Minolta Models:

- MAXXU 5D, 7D, DIMAGE 7, 7i, A1, A2

Replaces Sony RM-L1AM and RM-SPR1.

SETUP

1. Battery Installation

- **Transmitter:** The transmitter requires one CR2032 battery (included). Open the battery compartment on the back of the transmitter and insert the CR2032 battery, ensuring correct polarity.
- **Receiver:** The receiver requires two AAA batteries (not included). Open the battery compartment on the back of the receiver and insert the AAA batteries, ensuring correct polarity.



Continuous shooting

Capture more exciting moments

Image: AODELAN SRR-PEBBLE Wireless Remote Control with open battery compartments for the transmitter and receiver.

2. Connecting the Receiver to the Camera

1. Attach the receiver to your camera's hot shoe for secure mounting.
2. Connect one of the provided connecting cables from the receiver to your camera's remote terminal (Multi/Micro USB Terminal for Sony cameras).
3. Turn on both your camera and the receiver.

Wired



Wireless

Control range: 262 ft



Image: AODELAN SRR-PEBBLE Wireless Remote Control receiver attached to a camera, illustrating both wired and wireless setup options.

3. Pairing Transmitter and Receiver

The AODELAN SRR-PEBBLE uses 2.4GHz digital radio technology for wireless communication. Ensure both the transmitter and receiver are powered on. The devices should automatically pair. If not, refer to the detailed pairing instructions in the included manual for specific steps, which typically involve setting a frequency channel on both devices.

Your browser does not support the video tag.

Video: Demonstrates the pairing process and basic functionality of the AODELAN Camera Remote Control. This video shows how to connect the remote to a camera and trigger the shutter.

OPERATING INSTRUCTIONS

The AODELAN SRR-PEBBLE offers multiple shooting modes and functions for enhanced control.

1. Basic Shutter Release

- **Autofocus:** Half-press the shutter button on the transmitter to activate autofocus.

- **Single Shot:** Fully press the shutter button to take a single photograph.

2. Advanced Shooting Modes

- **Delayed Shooting:** Use the delay function to set a timer before the shutter is released, allowing you to be in the shot or minimize camera shake.



Delayed Shooting

Take photos more freely

Image: The AODELAN SRR-PEBBLE transmitter highlighting its delayed shooting capability.

- **Continuous Shooting:** Activate continuous shooting mode on your camera and use the remote to capture a series of photos rapidly.

360 ° controllable

Remote control range: 262 ft

Record beautiful moments at any time



Image: The AODELAN SRR-PEBBLE transmitter demonstrating continuous shooting, useful for capturing sequences.

- **Bulb Function:** For long exposure photography, set your camera to Bulb mode. Press and hold the shutter button on the transmitter to keep the shutter open for the desired duration. Release the button to close the shutter.



Bulb Setting

Take more exciting photos

Image: The AODELAN SRR-PEBBLE transmitter in Bulb mode, ideal for long exposure photography like star trails.

- **Video Recording:** Use the dedicated video record button on the transmitter to start and stop video recording.

Your browser does not support the video tag.

Video: Demonstrates how to use the AODELAN Camera Remote Control for both photo and video functions, including starting and stopping recording.

MAINTENANCE

- **Battery Replacement:** Replace the CR2032 battery in the transmitter and AAA batteries in the receiver as needed. Refer to the "Battery Installation" section for instructions.
- **Cleaning:** Use a soft, dry cloth to clean the remote control. Avoid using liquid cleaners or solvents.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

- **Remote not responding:**
 - Ensure both the transmitter and receiver have fresh batteries and are powered on.

- Verify that the receiver is correctly connected to the camera's remote terminal and securely mounted on the hot shoe.
 - Check if the transmitter and receiver are properly paired. Refer to the pairing instructions if necessary.
 - Ensure the camera's remote control settings are enabled in its menu.
- **Limited range:**
 - Ensure there are no significant obstructions between the transmitter and receiver.
 - Check for potential sources of interference (e.g., other wireless devices).
 - Replace batteries if they are low.
- **Camera not focusing/shooting:**
 - Confirm the camera is in a compatible shooting mode (e.g., single shot, continuous, bulb).
 - Ensure the camera's autofocus system is active and able to acquire focus.

SPECIFICATIONS

Product Dimensions	3.15 x 3.15 x 1.18 inches
Item Weight	1.75 ounces
Item Model Number	SRR-PEBBLE
Batteries (Transmitter)	1 CR2032 battery (included)
Batteries (Receiver)	2 AAA batteries (not included)
Transmission Technology	2.4GHz Digital Radio
Working Distance	Up to 80m (262 ft)
Color	Black
Manufacturer	AODELAN

WARRANTY AND SUPPORT


AODELAN products are designed for quality and reliability. If you encounter any issues or have questions regarding your SRR-PEBBLE Wireless Camera Remote Control, please contact AODELAN customer support. We value your feedback and are committed to providing the best service.

For support, please refer to the contact information provided in your product packaging or visit the official AODELAN website.



[Aodelan PEBBLE Wireless Shutter Remote User Manual](#)

This user manual provides instructions for the Aodelan PEBBLE Wireless Shutter Remote, covering its features, operation, troubleshooting, and warranty information. It details how to use the transmitter and receiver for various shooting modes including autofocus, single shot, continuous release, and Bulb shooting, as well as its functionality as a wired remote.



[AODELAN WTR-2 TRS-1 Wireless Timer Remote Shutter Release User Manual](#)

Comprehensive user manual for the AODELAN WTR-2 and TRS-1 wireless and wired timer remote shutter release systems. Learn about features, setup, operation, safety, and technical specifications for photographers.



[AODELAN WTR-2 & TRS-1 Wireless Timer Remote Shutter Release User Manual](#)

Comprehensive user manual for the AODELAN WTR-2(T), WTR-2(R), and TRS-1 wireless and wired timer remote shutter release systems. Learn about features, setup, operation, and technical specifications.



[AODELAN ZC-4 Remote Controller User Manual](#)

User manual for the AODELAN ZC-4 Remote Controller and Receiver, detailing wireless and wired operation for Sony camcorders, multi-cam control, and key features for professional video production.



[AODELAN BR-E1A Wireless Remote Control User Manual](#)

User manual for the AODELAN BR-E1A Wireless Remote Control, detailing its features, setup, operation for still photos and movies, compatibility with Canon cameras, and specifications. Includes safety precautions and regulatory information.



[AODELAN BR-E1A Wireless Remote Control User Manual | Features & Specifications](#)

Comprehensive user manual for the AODELAN BR-E1A Wireless Remote Control. Learn about its features, setup, shooting modes, safety precautions, and specifications. Compatible with Canon cameras.