

[Manuals.plus](#) /

› [STANLEY](#) /

› Stanley Hand Truck SXWTD-FT585 User Manual

STANLEY SXWTD-FT585

Stanley Hand Truck User Manual

Model: SXWTD-FT585

Brand: STANLEY

INTRODUCTION

The Stanley SXWTD-FT585 Hand Truck is a versatile 2-in-1 utility cart designed for easy material handling. It can be used as both a traditional hand truck and a flat platform cart, offering flexibility for various tasks. Its robust construction ensures durability and reliable performance.





Image: The Stanley SXWTD-FT585 Hand Truck in its upright, two-wheel hand truck configuration, ready for use.





Image: The Stanley SXWTD-FT585 Hand Truck transformed into a four-wheel platform cart, suitable for larger or multiple items.

KEY FEATURES

- **Versatile Utility Cart:** Folds and opens in seconds for quick deployment and storage. Comes 100% fully assembled, ready for immediate use.
- **Compact Lightweight Design:** Constructed from strong and durable steel. Major plastic stress points are made of durable nylon, while other plastic components are polypropylene, ensuring longevity and light weight.
- **TPR Grip Handle and Bungee:** Features a comfortable TPR grip handle for secure handling. Includes a bungee cord to safely secure loads during transport.

- **2 Convenient Operation Modes:** Easily converts between a hand truck (two-wheel mode) and a platform cart (four-wheel mode) thanks to its innovative 2-in-1 folding design.

SETUP AND ASSEMBLY

The Stanley SXWTD-FT585 Hand Truck comes 100% fully assembled from the factory. No additional assembly is required. Simply unfold the unit to your desired configuration (hand truck or platform cart) before use.

Unfolding for Use:

1. To convert to a hand truck, ensure the base plate is folded down and the handle is extended upwards. Secure the handle in place using the locking clips.
2. To convert to a platform cart, release the handle locking mechanism and fold the handle down. Extend the base plate to form a flat platform. Ensure all wheels are properly deployed.





Image: A user demonstrating the compact folding capability of the hand truck, making it easy to store or transport in a vehicle.

OPERATING INSTRUCTIONS

Hand Truck Mode (2-Wheel Operation):

- Ensure the unit is in the upright hand truck configuration.
- Place the item(s) to be moved onto the base plate.
- Use the included bungee cord to secure the load to the frame, preventing shifting during transport.
- Tilt the hand truck back using the TPR grip handle and carefully move the load.
- Maximum load capacity in hand truck mode: 154.3 lbs (70 kg).





Image: A person efficiently moving heavy items using the hand truck in its two-wheel configuration.

Platform Cart Mode (4-Wheel Operation):

- Ensure the unit is converted to the flat platform cart configuration.
- Place item(s) onto the platform. For stability, distribute weight evenly.
- Push or pull the cart using the extended handle.
- Maximum load capacity in platform cart mode: 302 lbs (137 kg).



Image: The platform cart mode in action, transporting a large toolbox across a worksite.



Image: A construction worker pushing the Stanley platform cart loaded with a crate, demonstrating its utility on a construction site.

MAINTENANCE

To ensure the longevity and optimal performance of your Stanley Hand Truck, follow these simple maintenance guidelines:

- **Cleaning:** Wipe down the steel and plastic components with a damp cloth to remove dirt and debris. Avoid using harsh chemicals that may damage the materials.
- **Lubrication:** Periodically check moving parts, such as wheel axles and folding hinges. Apply a small amount of silicone-based lubricant if any stiffness or squeaking is observed.
- **Inspection:** Regularly inspect the frame, wheels, and locking mechanisms for any signs of wear, damage, or loose fasteners. Tighten any loose screws or bolts as needed.
- **Storage:** Store the hand truck in a clean, dry place when not in use. Its compact folding design allows for easy storage in small spaces.



Image: A detailed view of the durable wheels and sturdy base of the Stanley hand truck, highlighting its robust construction.

TROUBLESHOOTING

Most issues with the Stanley Hand Truck can be resolved with basic checks. If you encounter problems, please refer to the following:

- **Difficulty Folding/Unfolding:** Ensure all locking mechanisms are fully disengaged. Check for any obstructions or debris in the hinge areas. Do not force the mechanism.
- **Wheels Not Rolling Smoothly:** Inspect wheels for debris (e.g., string, hair) wrapped around the axles. Clean as necessary. If wheels are damaged, contact customer support for replacement parts.
- **Instability During Use:** Ensure the load is centered and secured with the bungee cord. Verify that the hand truck or platform cart is fully locked into its operating configuration. Do not exceed the stated load capacities.

For issues not covered here, please contact Stanley customer support.

SPECIFICATIONS

Attribute	Detail
Brand	STANLEY
Model Number	SXWTD-FT585
Material	Alloy Steel, Nylon, Polypropylene
Color	Yellow & Black
Item Weight	4.4 pounds (2 Kilograms)
Product Dimensions (L x W x H)	25.2"L x 13.78"W x 4.72"H (folded)
Load Capacity (Hand Truck Mode)	154.3 Pounds (70 kg)
Load Capacity (Platform Cart Mode)	302 Pounds (137 kg)
Number of Wheels	4
Wheel Type	Plastic, Polypropylene, Steel, TPR



STRENGTH & DURABILITY

LOAD CAPACITY : HANDTRUCK - 70KG
: PLATFORM TRUCK - 137KG

WEIGHT : 7.4KG

MATERIAL : STEEL, NYLON, POLYPROPLYLENE

WHEEL MATERIAL : PP + TPR

SIZE & MOVEMENT

FOLDED DIMN : 38.9X11.7X64.3CM

PLATFORM DIMN : 78X45X92CM

HANDTRUCK DIMN : 45X41.6X110CM

BASE PLATE DIMN : 38.8X23.1CM

BASE PLATE PLATFORM DIMN : 57.1X38.2CM

PLASTIC WHEELS : 12.7CM

CASTERS : 8.6CM

Image: A graphic detailing the strength, durability, size, and movement specifications of the hand truck in both hand truck and platform modes.



Image: Visual representation of the dimensions of the Stanley hand truck when fully extended in platform cart mode.

WARRANTY INFORMATION

Stanley products are manufactured to high-quality standards and are guaranteed against manufacturing defects. For specific warranty terms and conditions applicable to your SXWTD-FT585 Hand Truck, please refer to the warranty card included with your purchase or visit the official Stanley website. Keep your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

For any inquiries, technical assistance, or spare parts, please contact Stanley customer support:

Phone: 1800-203-0644 (Monday - Saturday, 09:00 AM - 06:00 PM IST, except government holidays)

Email: SBD-CUSTOMERCOMMUNICATIONS@SBDINC.COM

WhatsApp: Scan the QR code or click the link to connect:[+91 96060 55835](https://wa.me/919606055835)

Service Network: Over 500+ authorized service centers available.



SALES AND AFTER
SALES SUPPORT



GREAT SERVICE
NETWORK



WARRANTY



ORIGINAL PARTS



INFORMATION



OMNICHANNEL
SUPPORT

CUSTOMER CARE CONTACT

PHONE:

1800-203-0644

EMAIL:

SBD-CUSTOMER
COMMUNICATIONS
@SBDINC.COM

WHATSAPP:



+91 96060 55835

SCAN THE CODE TO CONTACT US

MON-SAT

09:00 AM - 06:00 PM IST

EXCEPT GOVERNMENT HOLIDAYS

NUMBER OF AUTHORIZED
SERVICE CENTER : 500+

Image: Stanley Total Care information, including contact details for sales, service, warranty, and omnichannel support.

© 2024 STANLEY. All rights reserved. Information is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question