

Calvas CLS-D41D8CD98F00B204E9800998ECF8427E

User Manual for Calvas Fetcus Remote Control

Model: CLS-D41D8CD98F00B204E9800998ECF8427E

Compatible with Panasonic CS-E9CKP, CS-E15CKP, CWA75C258, CWA75C377, CWA75C376 Air Conditioners

1. PRODUCT OVERVIEW

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Calvas Fetcus replacement remote control for Panasonic air conditioners. This remote is designed to provide seamless control over your compatible air conditioning unit, offering functions such as power, mode selection, temperature adjustment, fan speed control, and timer settings.



Figure 1: Front view of the Calvas Fetcus remote control.

2. SETUP

2.1. Battery Installation

The remote control requires batteries for operation. Please follow these steps to install or replace the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two new batteries of the appropriate type (e.g., AAA or AA, please check markings inside the compartment) into the compartment, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside.
4. Close the battery compartment cover by sliding it back into place until it clicks securely.



Figure 2: Battery compartment on the back of the remote control.

2.2. Initial Use

Once batteries are installed, the remote control is ready for use. No programming is typically required for this replacement remote, as it is pre-programmed for compatible Panasonic air conditioner models. Simply point the remote control towards the air conditioner's receiver and press the desired function button.

3. OPERATING INSTRUCTIONS

Familiarize yourself with the buttons and their functions for optimal control of your air conditioner.



Figure 3: Detailed view of remote control buttons.

3.1. Button Functions

- **ON/OFF Button:** Powers the air conditioner on or off.
- **MODE Button:** Cycles through operating modes such as Cool, Heat, Fan, Dry, Auto.
- **TEMP ▲/▼ Buttons:** Adjusts the desired temperature setting up or down.
- **FAN SPEED Button:** Changes the fan speed (e.g., Low, Medium, High, Auto).
- **AIR SWING Button:** Controls the vertical louver movement for air direction.
- **TIMER Button:** Initiates or adjusts the timer settings for scheduled operation.
- **AUTO Button:** Activates the automatic operating mode, where the unit selects the best mode and fan speed based on room temperature.
- **RESET Button:** Resets the remote control settings (usually a small recessed button requiring a pointed object).

3.2. Basic Operation

- 1. **Turning On/Off:** Press the **ON/OFF** button once to turn the unit on, and again to turn it off.
- 2. **Selecting Mode:** Press the **MODE** button repeatedly until the desired operating mode (e.g., Cool, Heat) is displayed on the remote's screen.
- 3. **Adjusting Temperature:** Use the **TEMP ▲** or **TEMP ▼** buttons to set your preferred temperature.
- 4. **Setting Fan Speed:** Press the **FAN SPEED** button to cycle through available fan speeds.

4. MAINTENANCE

4.1. Battery Replacement

Replace batteries when the remote control's display becomes dim or when the remote no longer responds to button presses. Refer to Section 2.1 for detailed battery installation instructions. Always replace both batteries at the same time with new ones of the appropriate type.

4.2. Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed immediately by a dry cloth. Do not use abrasive cleaners, solvents, or immerse the remote in water, as this can damage the electronic components.

4.3. Storage

If the remote control will not be used for an extended period, it is recommended to remove the batteries to prevent leakage and potential damage to the remote. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote control not working.	Dead or incorrectly installed batteries.	Replace batteries, ensuring correct polarity (+/-).
Remote control range is poor.	Weak batteries; Obstruction between remote and AC unit; Remote not pointed directly at AC unit.	Replace batteries; Remove obstructions; Ensure direct line of sight to AC unit's receiver.
Air conditioner does not respond to commands.	Remote control not compatible with AC unit; AC unit is off or unplugged; AC unit's receiver is faulty.	Verify compatibility with your specific Panasonic AC model; Check AC unit's power supply; Consult AC unit's manual or service technician.
Remote display is dim or blank.	Low battery power.	Replace batteries.

6. SPECIFICATIONS

Feature	Detail
Brand	Calvas
Model Number	CLS-D41D8CD98F00B204E9800998ECF8427E

Feature	Detail
Compatible Devices	Panasonic Air Conditioners (CS-E9CKP, CS-E15CKP, CWA75C258, CWA75C377, CWA75C376)
Connectivity Technology	Infrared (IR)
Wireless Communication	IR
Frequency	433 MHz
Channel	1
Max Number of Supported Devices	1
Item Weight	99.8 g (approx.)
Material	Other
Item Package Quantity	1
Special Features	Infrared, Universal, Wireless
Battery Description	Lithium (<i>Note: Typically uses AAA/AA. Please check remote's battery compartment for specific type.</i>)

7. WARRANTY INFORMATION

This product comes with a **90-day warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. Please retain your proof of purchase for warranty claims. For specific terms and conditions, or to initiate a warranty claim, please contact your retailer or the manufacturer.

8. SUPPORT

For further assistance, troubleshooting not covered in this manual, or inquiries regarding your Calvas Fetcus remote control, please contact the seller or the manufacturer directly. Refer to your purchase documentation for contact details. You may also visit the product page on Amazon.ca for additional information or customer service options.

Product Link: <https://www.amazon.ca/Calvas-RemoteControl-Panasonic-CS-E15CKP-Conditioner/dp/B07R6X7KZL>