

## LASER X 88042

# LASER X Morph Blasters Instruction Manual

Model: 88042

## 1. INTRODUCTION

The LASER X Morph Blasters offer a real-life infrared gaming experience. These compact, 5-inch blasters feature state-of-the-art lighting and sound effects, bringing the excitement of a laser tag arena to your home. No receiver vests are needed as a receiver is built directly into each blaster. With a blasting range of up to 100 feet, Micro B2 Blasters are compatible with all other Laser X gear. Games can include an unlimited number of players, allowing for one-on-one play, team battles, or a "rogue" mode where every player competes individually.

## 2. SAFETY INFORMATION

- **Adult Supervision:** Recommended for players aged 6 and above. Adult supervision is advised during play.
- **Battery Safety:** Requires 6 "AAA" (1.5V) batteries (not included). Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries. Insert batteries with correct polarity. Remove exhausted batteries promptly. Do not short-circuit supply terminals.
- **Eye Safety:** Do not aim directly at eyes. The blasters use infrared light, not actual lasers.
- **Choking Hazard:** Keep small parts away from young children.

## 3. PACKAGE CONTENTS

- 2 x Laser X Morph Blasters
- Instruction Manual

## 4. SETUP

### 4.1 Battery Installation

1. Locate the battery compartment on the blaster handle.
2. Using a Phillips head screwdriver, unscrew the battery compartment cover.
3. Insert 3 "AAA" (1.5V) batteries into each blaster, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.

**Note:** A total of 6 "AAA" batteries are required for two blasters (3 per blaster).



Figure 1: Battery compartment location on the blaster.

## 5. OPERATING INSTRUCTIONS

### 5.1 Powering On and Team Selection

1. Locate the ON/OFF switch on the blaster. Slide it to the ON position.
2. The blaster will emit a startup sound and lights will illuminate.
3. To select your team color (Red, Blue, or Rogue/White), use the team selector dial located on the side of the blaster. Rotate the dial to cycle through available colors.
4. The blaster's lights will change to reflect your selected team color.



Figure 2: Blaster features including team indicator and blast indicator.

## 5.2 Firing and Reloading

- To fire, aim your blaster at an opponent's blaster receiver and press the trigger.
- Each blaster has a limited number of shots before needing to reload.
- To reload, hold down the trigger for approximately 3 seconds until you hear a reloading sound.

## 5.3 Scoring Hits

- When an opponent's blaster is hit, their blaster will register the hit with sound and light effects.
- The blaster's health indicator (located on the bottom) will change color from green to yellow, then to red as health decreases.
- Once a player is out of health, their blaster will indicate they are out of the game. To restart, turn the blaster OFF and then ON again.



Figure 3: Blaster-to-Blaster play mode.

## 6. GAME MODES

The Laser X Morph Blasters offer versatile play options:

### 6.1 Blaster-to-Blaster Mode

Players aim and shoot directly at each other's blasters. The built-in receiver registers hits. This mode is ideal for head-to-head competition or team play.

### 6.2 Blaster-to-Game Target Mode

The blaster can transform into a game target. Players can practice their aim and speed by shooting at the transformed target. This mode is excellent for solo training or competitive challenges.



Figure 4: Blaster-to-Game Target play mode.

### 6.3 Blaster-to-Receiver Mode

Players can wear the receiver on their arm (or chest if using compatible gear) and aim for the receiver to score hits. This mode allows for more dynamic movement and strategic play.



Figure 5: Blaster-to-Receiver play mode.

## 6.4 Rogue Mode

In Rogue Mode, every player is on their own. There are no teams, and every player aims to be the last one standing. Select the white/rogue team color using the dial.

## 7. MAINTENANCE

- **Cleaning:** Wipe the blasters with a dry, soft cloth. Do not immerse in water or use harsh chemicals.
- **Storage:** Store blasters in a cool, dry place away from direct sunlight when not in use. Remove batteries if storing for extended periods to prevent leakage.

## 8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Blaster not turning on.	Batteries are dead or incorrectly installed.	Check battery polarity and replace with fresh batteries.
Blaster not registering hits.	Obstruction between blasters or out of range.	Ensure clear line of sight and reduce distance between players.

Problem	Possible Cause	Solution
Blaster not reloading.	Trigger not held long enough.	Hold the trigger down for the full 3 seconds until reloading sound completes.

## 9. SPECIFICATIONS

---

- **Model Number:** 88042
- **Product Dimensions:** 18.23 x 2.09 x 7.99 inches
- **Item Weight:** 2.2 pounds
- **Blasting Range:** Up to 100 feet
- **Power Source:** 3 x "AAA" (1.5V) batteries per blaster (6 total, not included)
- **Recommended Age:** 6+ years
- **Manufacturer:** GAXIWILO

## 10. OFFICIAL PRODUCT VIDEO

---

Your browser does not support the video tag.

Video: Laser X 2019 Edition from NSI International. This video provides an overview of the Laser X system, demonstrating its features and gameplay.

## 11. WARRANTY AND SUPPORT

---

For warranty information or customer support, please refer to the contact details provided on the product packaging or visit the official LASER X website. Keep your purchase receipt as proof of purchase.